

Configuration reference guide MMI user interface




Table of contents

1	About this document	6
2	Possible screens: Overview	7
2.1	Home screen	7
2.2	Energy flow – System overview screen.....	9
2.3	Main menu screen.....	11
2.4	Setpoint screen.....	12
3	Schedules	13
3.1	Using and programming schedules.....	13
3.2	Schedule screen: Example.....	19
4	Weather-dependent curve	24
4.1	What is a weather-dependent curve?	24
4.2	Using weather-dependent curves.....	24
5	Energy prices	27
5.1	Energy price considered.....	27
5.2	To set the fixed electricity price (no scheduling).....	27
5.3	To set the scheduled electricity baseline price	28
5.4	To set the electricity price schedule	28
5.5	To set the gas price	28
5.6	About energy prices in case of an incentive per kWh renewable energy.....	29
5.6.1	To set the gas price in case of an incentive per kWh renewable energy	29
5.6.2	To set the electricity price in case of an incentive per kWh renewable energy	29
5.6.3	Example.....	29
6	Domestic hot water control	30
6.1	About domestic hot water control	30
6.2	Reheat mode	30
6.3	Schedule and reheat mode	32
6.4	Scheduled mode.....	34
6.5	Single heat-up.....	35
6.5.1	Manual mode.....	35
6.5.2	Powerful heating mode	35
6.6	Additional heat source for DHW	36
7	Modbus TCP/IP for Daikin Altherma	38
7.1	Modbus protocol.....	38
7.2	Modbus registers.....	38
7.2.1	Holding registers.....	40
7.2.2	Input registers.....	43
7.2.3	Discrete input registers.....	47
7.2.4	Coil registers	47
7.3	Connecting the electrical wiring	48
7.3.1	To connect the electrical wiring	48
7.4	Third-party Modbus integrations.....	48
7.5	Smart Grid for utilities.....	49
7.6	Energy buffering with Smart Grid	49
7.6.1	Buffering in case [1-12] = 0 [LWT control]	52
8	Cloud for Daikin Altherma	53
8.1	Third-party Cloud integrations.....	53
9	Other functionalities	56
9.1	To set Time/date	56
9.2	Using quiet mode	56
9.3	Using holiday mode.....	58
9.4	Using WLAN.....	59
10	Settings	62
[1]	Main zone.....	62
[1.1]	Room setpoint.....	62
[1.2]	Heating schedule enable	63
[1.3]	Heating schedule	63
[1.4]	Cooling schedule	64
[1.5]	Heating setpoint mode.....	64

[1.6] Setpoint range.....	64
[1.7] Cooling setpoint mode.....	66
[1.8] Heating WD curve.....	66
[1.9] Cooling WD curve.....	67
[1.10] Hysteresis.....	67
[1.11] Emitter type.....	68
[1.12] Control.....	69
[1.13] External room thermostat.....	69
[1.14] Delta T heating.....	71
[1.15] NOT USED.....	71
[1.16] Cooling allowance.....	71
[1.17] Enable zone.....	72
[1.18] Delta T cooling.....	72
[1.19] Overheating water circuit.....	72
[1.20] Undercooling water circuit.....	73
[1.21] Zone name.....	73
[1.22] Antifrost.....	73
[1.23] Cooling schedule enable.....	74
[1.24] Leaving water shift heating schedule.....	74
[1.25] Leaving water shift cooling schedule.....	75
[1.26] Increase around 0°C.....	76
[1.27] Leaving water shift heating.....	76
[1.28] Leaving water shift cooling.....	76
[1.29] Heating comfort setpoint.....	76
[1.30] Cooling comfort setpoint.....	77
[1.31] Daikin room thermostat.....	77
[1.32] Room enable.....	77
[1.33] External room sensor offset.....	78
[1.34] Heating target baseline.....	78
[1.35] Cooling target baseline.....	78
[1.36] Scheduled WD LWT shift for heating.....	78
[1.37] Scheduled WD LWT shift for cooling.....	79
[1.38] Thermostat sensor offset.....	79
[1.39] Leaving water temp. heating.....	79
[1.40] NOT USED.....	79
[1.41] NOT USED.....	79
[1.42] Leaving water temp. cooling.....	79
[2] Additional zone.....	80
[2.1] NOT USED.....	80
[2.2] Heating schedule enable.....	80
[2.3] Heating schedule.....	81
[2.4] Cooling schedule.....	81
[2.5] Heating setpoint mode.....	81
[2.6] Setpoint range.....	82
[2.7] Cooling setpoint mode.....	83
[2.8] Heating WD curve.....	83
[2.9] Cooling WD curve.....	84
[2.10] NOT USED.....	84
[2.11] Emitter type.....	84
[2.12] Control.....	85
[2.13] External room thermostat.....	85
[2.14] Delta T heating.....	86
[2.15] Enable zone.....	86
[2.16] NOT USED.....	86
[2.17] Delta T cooling.....	86
[2.18] Leaving water shift heating schedule.....	87
[2.19] Leaving water shift cooling schedule.....	87
[2.20] Increase around 0°C.....	88
[2.21] Zone name.....	88
[2.22] Leaving water shift heating.....	88
[2.23] Leaving water shift cooling.....	89
[2.24] NOT USED.....	89
[2.25] NOT USED.....	89
[2.26] NOT USED.....	89
[2.27] Cooling schedule enable.....	89
[2.28] NOT USED.....	89
[2.29] NOT USED.....	89
[2.30] Leaving water temp. heating.....	89
[2.31] Scheduled WD LWT shift for heating.....	90

[2.32] Scheduled WD LWT shift for cooling.....	90
[2.33] Cooling allowance.....	90
[2.34] NOT USED.....	91
[2.35] NOT USED.....	91
[2.36] Leaving water temp. cooling.....	91
[3] Space heating/cooling.....	92
[3.1] Operation range.....	92
[3.2] Operation mode.....	92
[3.3] NOT USED.....	94
[3.4] Antifrost.....	94
[3.5] Operation mode schedule.....	94
[3.6] Additional zone.....	94
[3.7] Max. heating overshoot LWT.....	95
[3.8] Averaging time.....	96
[3.9] Max. cooling undershoot LWT.....	96
[3.10] NOT USED.....	96
[3.11] Undercooling setpoint.....	96
[3.12] Overheating setpoint.....	97
[3.13] Bizone kit.....	97
[3.14] Room thermostat present.....	99
[3.15] Heatpump minimum on time.....	99
[4] Domestic hot water.....	100
[4.1] Single heat-up.....	100
[4.2] NOT USED.....	100
[4.3] Manual setpoint.....	100
[4.4] Powerful operation setpoint.....	101
[4.5] Reheat setpoint.....	101
[4.6] Single heat-up schedule.....	101
[4.7] Heat up mode.....	101
[4.8] NOT USED.....	103
[4.9] Clear disinfection malfunction.....	103
[4.10] Disinfection / [4.18] Disinfection enable.....	103
[4.11] Operation range.....	105
[4.12] Hysteresis.....	106
[4.13] DHW pump.....	106
[4.14] Booster heater.....	106
[4.15] NOT USED.....	107
[4.16] Add. source take over during SH/C.....	107
[4.17] Add. source DHW always on request.....	108
[4.18] Disinfection enable.....	108
[4.19] Reheat Trigger Threshold.....	108
[4.20] NOT USED.....	109
[4.21] NOT USED.....	109
[4.22] NOT USED.....	109
[4.23] Offset BSH setpoint.....	109
[4.24] Enable reheat schedule.....	109
[4.25] Reheat schedule.....	109
[4.26] DHW pump schedule.....	109
[5] Settings.....	110
[5.1] Forced defrost.....	110
[5.2] Quiet operation.....	111
[5.3] Time/date.....	111
[5.4] Breadcrumbs.....	111
[5.5] Backup heater.....	111
[5.6] Capacity shortage.....	113
[5.7] Overview field settings.....	114
[5.8] NOT USED.....	114
[5.9] Location and language.....	114
[5.10] Timezone.....	114
[5.11] Reset fan operation hours.....	114
[5.12] Keyboard lay-out.....	115
[5.13] Advanced settings.....	115
[5.14] Bivalent.....	115
[5.15] NOT USED.....	119
[5.16] NOT USED.....	119
[5.17] Display brightness.....	119
[5.18] System restart.....	119
[5.19] NOT USED.....	119
[5.20] NOT USED.....	119

[5.21] NOT USED	119
[5.22] External ambient sensor offset	119
[5.23] Emergency selection	121
[5.24] Advanced log level	121
[5.25] NOT USED	122
[5.26] Display inactivity timer	122
[5.27] Holiday	122
[5.28] Balancing	122
[5.29] Refrigerant recovery mode	124
[5.30] Emergency acknowledgement	124
[5.31] Tank energy for space heating during defrost	124
[5.32] Tank boiler present	125
[5.33] Tank boiler covers heat demand	125
[5.34] Maximum capacity	126
[5.35] Pump limitation service	126
[5.36] Water pipe freeze prevention	126
[5.37] Bivalent present	126
[5.38] Tank support	127
[6] Information	128
[6.1] NOT USED	128
[6.2] Dealer information	128
[6.3] Sensors	128
[6.4] Actuators	128
[6.5] Operation modes	128
[6.6] About	129
[6.7] Indoor unit model name / [6.8] Indoor unit serial number	129
[7] Maintenance mode	130
[8] Connectivity	131
[8.1] TCP/IP configuration	131
[8.2] Connection status	131
[8.3] Wireless gateway	131
[8.4] Connection details	131
[8.5] Daikin Home Controls	132
[8.6] Safe removal USB drive	132
[8.7] Modbus TCP/IP (502)	132
[8.8] Modbus TCP/IP TLS (802)	133
[9] Energy	134
[9.1] Electricity price	134
[9.2] Electricity price baseline	134
[9.3] Electricity price schedule enable	134
[9.4] Electricity price schedule	135
[9.5] Gas price	135
[9.6] NOT USED	135
[9.7] NOT USED	135
[9.8] NOT USED	135
[9.9] NOT USED	135
[9.10] NOT USED	135
[9.11] Boiler efficiency	135
[9.12] PE factor	135
[9.13] Energy price considered	136
[9.14] Demand response	136
[10] Configuration wizard	143
[11] Malfunctioning	145
To display the help text in case of a malfunction	145
[12] NOT USED	146
[13] Field IO	147

1 About this document

Target audience

Authorised installers

Documentation set

This document is part of a documentation set. The complete set consists of:

- **This configuration reference guide:**

- This configuration reference guide is applicable for all models that are operated via the Daikin Altherma 4 MMI (user interface of the unit).
- Format: Digital files on <https://www.daikin.eu>. Use the search function 🔍 to find your model.

- **For other applicable manuals:**

See the installer reference guide of your model.

The latest revision of the supplied documentation is published on the regional Daikin website and is available via your dealer.

The original instructions are written in English. All other languages are translations of the original instructions.

2 Possible screens: Overview



INFORMATION


Some functions are visualised on the user interface, but are not available for your system.

The most common screens are as follows:

- Home screen
- Energy flow – System overview screen
- Main screen (two screens)
- Setpoint screen

2.1 Home screen

The home screen gives an overview of the unit configuration and the room and setpoint temperatures. Only symbols applicable for your configuration are visible on the home screen.




Item	Description	
a	Spaces Shortcut to setting [3.2].	
	a1	Climate control ON / OFF
	a2	Operation mode:
		Heating
		Cooling
b	b1	Automatic
		Heat emitter type:
		Underfloor heating
		Heat pump convector
		Radiator
	b2	Backup heater ON
	b3	Measured temperature (Main zone)

Item		Description
c	Additional zone This zone can be renamed in Zone name [2.21])	
	c1	Heat emitter type:
		 Underfloor heating
		 Heat pump convector
		 Radiator
	c2	 Backup heater ON
	c3	 Measured temperature (Additional zone)
d	Domestic hot water Shortcut to setting [4.1].	
	d1	 Domestic hot water ON / OFF
	d2	Powerful operation mode:
		 Powerful operation mode ON
		 Powerful operation mode OFF
	d3	 Domestic hot water ON
	d4	 Booster heater (in case of wall-mounted units) or backup heater (in case of floor-standing or ECH ₂ O units) ON
	d5	DHW operation mode:
		 Disinfection mode active
		 Manual mode ON
		 Powerful operation mode ON
		 Reheat mode active
		 Schedule and reheat mode active
		 Scheduled reheat mode active
	d6	 Measured tank temperature
e	Outdoor Shortcut to setting [5.2].	
	e1	 Outdoor unit
	e2	Quiet operation:
		 Off
		 Manual
		 Scheduled
	e3	Quiet operation level:
		 Quiet
		 More quiet
		 Most quiet
	e4	 Measured outdoor temperature

Item		Description
f	Status icons	
	f1	 A warning occurred.
	f2	 An error occurred.
	f3	WiFi
		 WiFi connected
		 WiFi disconnected
	f4	 LAN connected
	f5	Daikin ONECTA
		 Connected
		 Not connected
	f6	Daikin HomeHub
		 Connected
		 Not connected
		 Warning
	f7	 Smart energy enabled
	f8	 Demo mode active
g	Clock	
h	Special functions	
	h1	 Safety valve closed
	h2	 Holiday
	h3	 Antifrost
	h4	 Emergency
	h5	 Outdoor unit is in locked state. Note: Unlocking can only be performed by a trained installer.
i	Installer switch. To switch between user and installer mode.	
		User mode
		Installer mode
j	Navigation / pagination	

2.2 Energy flow – System overview screen

Starting from the home screen, tap the left arrow to view the system overview screen.




Item		Description
a	Heat pump	Shows the status of the heat pump (On/Off).
b	Backup heater	Shows the active capacity of the backup heater. (⚡ = electrical heater)
c	Booster heater	Shows the status of the booster heater (if applicable) (On/Off). (⚡ = electrical heater)
d	Shows the demand response status (limiting status) of each actuator:	
	⊗	The actuator is actively forced OFF via demand response.
	⊕ (red)	The limit is active but overruled.
	⊕ (blue)	The limit is active and the actuator is actively limited (this can also mean that the heat source is completely switched OFF by the limit).
	⊕ (black)	The limit is active but not limiting.
	No symbol	No limit active.
e	Demand response	Shows the current demand response mode: When [9.14.1] = Smart grid ready contacts , following modes are possible: ▪ Free ▪ Forced off ▪ Forced on ▪ Recommended on When [9.14.1] = Smart Meter Contact , following mode is shown: ▪ Reduced

Item		Description
f	Imposed system limit	▪ Greyed out: Not active. ▪ Not greyed out: A maximum limit to the power consumption of the heat pump and the electrical heat sources is active. The limit is shown here (in kW). However, this limit can be ignored when the unit runs protective functions: - Defrost - Water pipe freeze prevention - Start-up control - Maintenance mode


2.3 Main menu screen

Starting from the home screen, tap the right arrow to view the first main menu screen. Tap the right arrow a second time to view the second main menu screen. From the main menu screens, you can access the different setpoint screens and submenus.

Main menu screen 1:



Main menu screen 2:




Submenu		Description
[11]	 Malfunctioning	Restriction: Only displayed if a malfunction occurs. See "To display the help text in case of a malfunction" [► 145] for more information.
[1]	 Main zone	Shows the applicable symbol for your main zone emitter type. Set the leaving water temperature for the main zone.
[2]	 Additional zone	Shows the applicable symbol for your additional zone emitter type. Set the leaving water temperature for the main zone.

Submenu		Description
[3]	 Space heating/ cooling	Shows the applicable symbol for your unit. Put the unit in heating mode or cooling mode. You cannot change the mode on heating only models.
[4]	 Domestic hot water	Restriction: Only displayed if a domestic hot water tank is present. Set the domestic hot water tank temperature.
[5]	 Settings	Settings for user and installer. Installer settings are only shown in the installer mode (the installer switch is in the  position)
[6]	 Information	Displays data and information about the indoor unit.
[7]	 Maintenance mode	Restriction: Only for the installer. Perform tests and maintenance.
[8]	 Connectivity	Restriction: Only for the installer. Gives access to advanced settings.
[9]	 Energy	Shows the electricity consumption.
[10]	 Configuration wizard	Restriction: Only for the installer. For setting the most important initial settings.
[12]	NOT USED	
[13]	 Field IO	Restriction: Only for the installer. Terminal pin mapping for certain functions.

2.4 Setpoint screen

The setpoint screen is displayed for screens describing system components that need a setpoint value.



Item	Description
a	Desired temperature.
b	Tap the up/down arrows in this area to increase/decrease the temperature.

3 Schedules



3.1 Using and programming schedules

About schedules

Depending on your system layout and installer configuration, schedules for multiple controls may be available.

You can...	See...
Set if a specific control needs to act according to a schedule.	" Activation screen " in " Possible schedules " [▶ 13]
Select which schedule you currently want to use for a specific control. The system contains some predefined schedules. You can:	
Consult which schedule is currently selected.	" Schedule/Control " in " Possible schedules " [▶ 13]
Select another schedule if needed.	" To select which schedule you currently want to use " [▶ 13]
Program your own schedules if the predefined schedules are not satisfactory. The actions you can program are control specific.	"Possible actions" in "Possible schedules" [▶ 13] "3.2 Schedule screen: Example" [▶ 19]

To select which schedule you currently want to use

1	Go to the schedule related to the specific control. For an overview, see " Possible schedules " [▶ 13]. Example: [1.3] Main zone > Heating schedule. [1.4] Main zone > Cooling schedule
2	Select the schedule that you currently want to use. 
3	Tap the Activate button. 
4	Confirm with the ✓ button.


Possible schedules



The table contains the following information:


- **Schedule/Control:** This column shows you where you can consult the currently selected schedule for the specific control. If needed, you can:
 - Select another schedule. See ["To select which schedule you currently want to use"](#) [► 13].
 - Program your own schedule. See ["3.2 Schedule screen: Example"](#) [► 19].
- **Predefined schedules:** Number of available predefined schedules in the system for the specific control. If needed, you can program your own schedule.
- **Activation screen:** For most controls, a schedule is only effective if it is activated in its corresponding activation screen. This entry shows you where to activate it.
- **Possible actions:** Actions you can use when programming a schedule.

Schedule/Control	Description
[1.3] Main zone > Heating schedule	Predefined schedules: 3 Activation: [1.2] Heating schedule enable Possible actions: Temperatures within range Restriction: Not for external room thermostat control. Schedule for the main zone in heating mode to set the desired leaving water or room temperature (depending on the installed system). Note: In case of room temperature scheduling, the baseline temperature will be used at times when no temperature is scheduled (i.e. in between the schedule blocks). To set the baseline temperature, go to [1.34] Main zone > Heating target baseline Note: In case of LWT scheduling, operation will be OFF when no temperature is scheduled. The influence of the LWT setpoint mode [1.5] is as follows: ▪ In Fixed LWT setpoint mode, the LWT schedules need to be selected. Note: When Fixed setpoint mode is selected, the shift schedules are available, but will NOT have any effect. ▪ In Weather dependent LWT setpoint mode, the shift schedules need to be selected. Note: When Weather dependent setpoint mode is selected, the fixed schedules are available but will NOT have any effect.

Schedule/Control	Description
[1.4] Main zone > Cooling schedule Schedule for the main zone in cooling mode to set the desired leaving water or room temperature (depending on the installed system).	Predefined schedules: 1 Activation: [1.23] Cooling schedule enable Possible actions: Temperatures within range Restriction: Not for external room thermostat control. Note: In case of room temperature scheduling, the baseline temperature will be used at times when no temperature is scheduled (i.e. in between the schedule blocks). To set the baseline temperature, go to [1.35] Main zone > Cooling target baseline Note: In case of LWT scheduling, operation will be OFF when no temperature is scheduled. The influence of the LWT setpoint mode [1.5] is as follows: - In Fixed LWT setpoint mode, the LWT schedules need to be selected. Note: When Fixed setpoint mode is selected, the shift schedules are available, but will NOT have any effect. - In Weather dependent LWT setpoint mode, the shift schedules need to be selected. Note: When Weather dependent setpoint mode is selected, the fixed schedules are available but will NOT have any effect.
[2.3] Additional zone > Heating schedule Schedule for the additional zone in heating mode to set the desired leaving water temperature.	Predefined schedules: 3 Activation: [2.2] Heating schedule enable Possible actions: Leaving water temperatures within range Restriction: Only for LWT control. Note: In case of LWT scheduling, operation will be OFF when no temperature is scheduled. The influence of the LWT setpoint mode [2.5] is as follows: - In Fixed LWT setpoint mode, the LWT schedules need to be selected. Note: When Fixed setpoint mode is selected, the shift schedules are available, but will NOT have any effect. - In Weather dependent LWT setpoint mode, the shift schedules need to be selected. Note: When Weather dependent setpoint mode is selected, the fixed schedules are available but will NOT have any effect.

Schedule/Control	Description
[2.4] Additional zone > Cooling schedule Schedule for the additional zone in cooling mode to set the desired leaving water temperature.	Predefined schedules: 1 Activation: [2.27] Cooling schedule enable Possible actions: Leaving water temperatures within range Restriction: Only for LWT control. Note: In case of LWT scheduling, operation will be OFF when no temperature is scheduled. The influence of the LWT setpoint mode [2.5] is as follows: - In Fixed LWT setpoint mode, the LWT schedules need to be selected. Note: When Fixed setpoint mode is selected, the shift schedules are available, but will NOT have any effect. - In Weather dependent LWT setpoint mode, the shift schedules need to be selected. Note: When Weather dependent setpoint mode is selected, the fixed schedules are available but will NOT have any effect.
[1.24] Main zone > Leaving water shift heating schedule	Predefined schedules: 3 Activation: [1.36] Scheduled WD LWT shift for heating Possible actions: Leaving water shift temperatures on the weather dependent curve. Note: Only in case weather-dependent curve is used (see "4 Weather-dependent curve" [► 24]) and only for LWT control. Remark: In case of LWT shift scheduling, there will be NO operation at times when no temperature shift is scheduled. Example:  —: Shifted leaving water temperature target -----: Weather-dependent curve +5: Temperature shift value

Schedule/Control	Description
[1.25] Main zone > Leaving water shift cooling schedule	Predefined schedules: 1 Activation: [1.37] Scheduled WD LWT shift for cooling Possible actions: Leaving water shift temperatures on the weather-dependent curve. Note: Only in case weather-dependent curve is used (see "4 Weather-dependent curve" [▶ 24]) and only for LWT control. Remark: In case of LWT shift scheduling, there will be NO operation at times when no temperature shift is scheduled. Example:  —: Shifted leaving water temperature target -----: Weather-dependent curve +5: Temperature shift value
[2.18] Additional zone > Leaving water shift heating schedule	Predefined schedules: 3 Activation: [2.31] Scheduled WD LWT shift for heating Possible actions: Leaving water shift temperatures on the weather-dependent curve. Note: Only in case weather-dependent curve is used (see "4 Weather-dependent curve" [▶ 24]) and only for LWT control. Remark: In case of LWT shift scheduling, there will be NO operation at times when no temperature shift is scheduled. Example:  —: Shifted leaving water temperature target -----: Weather-dependent curve +5: Temperature shift value

Schedule/Control	Description
[2.19] Additional zone > Leaving water shift cooling schedule	Predefined schedules: 1 Activation: [2.32] Scheduled WD LWT shift for cooling Possible actions: Leaving water shift temperatures on the weather-dependent curve. Note: Only in case weather-dependent curve is used (see "4 Weather-dependent curve" [▶ 24]) and only for LWT control. Remark: In case of LWT shift scheduling, there will be NO operation at times when no temperature shift is scheduled. Example:  —: Shifted leaving water temperature target -----: Weather-dependent curve +5: Temperature shift value
[3.5] Space heating/cooling > Operation mode schedule Schedule (per month) for when to operate the unit in heating mode and when in cooling mode.	See " To set the space operation mode " [▶ 93].
[4.6] Domestic hot water > Single heat-up schedule Schedule for the domestic hot water tank temperature for your normal domestic hot water needs.	Predefined schedules: 1 Activation: Not applicable. This schedule is automatically activated if [4.7] Heat up mode is one of the two following settings: ▪ Schedule only ▪ Schedule and reheat Note: In Schedule and reheat mode, the tank also heats up according to the [4.5] Reheat setpoint.
[4.25] Domestic hot water > Reheat schedule This allows for the DHW reheat setpoint to change according to a schedule, instead of using the fixed setpoint [4.5] Reheat setpoint	Activation: [4.24] Enable reheat schedule

Schedule/Control	Description
[4.26] Domestic hot water > DHW pump schedule Schedule for the DHW pump for instant hot water (if installed).	Program a schedule for the DHW pump. Program a domestic hot water pump schedule to determine when to turn on and off the pump. When turned on, the pump runs and makes sure hot water is instantly available at the tap. To save energy, only turn on the pump during periods of the day when instant hot water is necessary.
[5.2.2] Settings > Quiet operation > Schedule OR from the home screen: tap on the Outdoor bar, and tap on Schedule. Schedule for when the unit has to use which quiet mode level.	Predefined schedules: 1 Activation: To activate, choose the option Scheduled and confirm. See "To program a quiet mode schedule" [▶ 57].
[9.4] User settings > Electricity price schedule Schedule for when a certain electricity tariff is valid.	Predefined schedules: 1 Activation: [9.3] Electricity price schedule enable Possible actions: You can enter the price per kWh. See "5 Energy prices" [▶ 27].

3.2 Schedule screen: Example


This example shows how to set a room temperature schedule in heating mode for the main zone.



INFORMATION

The procedures to program other schedules are similar.

To program the schedule: overview



Prerequisite: Room temperature scheduling is only possible if room thermostat control is active. If LWT control is active, the schedule applies to the LWT instead.


Prerequisite: Scheduling is not possible when using an external room thermostat.

- 1 Go to the schedule.
- 2 (optional) Clear the content of the whole week schedule or the content of a selected day schedule.
- 3 Program the schedule for the weekdays.
- 4 Program the schedule for the weekend.



5 Give the schedule a name.

Note: You can set one time block for multiple days by selecting any day, workweek, weekend or every day.



To go to the schedule


1	Go to [1.2] Main zone > Heating schedule enable.
2	Switch scheduling ON: 
3	Go to [1.3] Main zone > Heating schedule.

To clear the content of the week schedule



1	Go to the schedule you want to clear: 
2	Tap the  button to delete the schedule: 
3	Confirm with the  button.

To clear the content of a time block in a schedule

1	Go to the schedule you want to edit. 
2	Tap the  button to edit the time blocks of the schedule: 



3	Select the time block you want to clear: 
4	Tap the  button to clear the time block.
5	Confirm with the  button.

To add time blocks



1	Tap the  button to add a time block.
2	Select one or more days for the time block to apply to: 
3	Tap the Next button.
4	Set the first schedule starting and ending time for the time block:  - Change the time entries directly by swiping up/down or tapping the +/- signs. - OR use the bar, by dragging the starting time point and ending time point.
5	Tap the Next button.
6	Set the desired temperature.
7	Confirm with the  button.
8	Add more time blocks if needed. Note: In case of room temperature scheduling, the baseline temperature will be used at times when no temperature is scheduled. To set the baseline temperature, go to: [1.34] Main zone > Heating target baseline [1.35] Main zone > Cooling target baseline Remark: In case of LWT scheduling and LWT shift scheduling, there will be NO operation at times when no temperature is scheduled.

To edit a time block



1	Tap the  button to edit a time block.
---	--

2	Select the time block you want to edit: 
3	Tap the Next button.
4	Set the first schedule starting and ending time for the time block:  - Change the time entries directly by swiping up/down or tapping the +/- signs. - OR use the bar, by dragging the starting time point and ending time point.
5	Tap the Next button.
6	Set the desired temperature.
7	Confirm with the ✓ button.

To rename a schedule

1	Go to the schedule you want to rename: 
2	Tap the  icon next to the schedule name to rename the schedule: 
3	Rename the schedule using the on-screen keyboard.
4	Confirm with the ✓ button.

To activate a schedule

1	Select the schedule: 
2	Tap the Activate button:  Note: In the schedule overview, the active schedule will be marked with 'Active'.
4	Confirm with the ✓ button.

Usage example: You work in a 3-shift system

If you work in a 3-shift system, you can do the following:

- 1 Program 3 room temperature schedules and give them appropriate names.
Example: EarlyShift, DayShift and LateShift
- 2 Select the schedule that you currently want to use.

4 Weather-dependent curve

4.1 What is a weather-dependent curve?

Weather-dependent operation

The unit operates 'weather-dependent' if the desired leaving water temperature is determined automatically by the outdoor temperature. It therefore is connected to a temperature sensor on the North wall of the building. If the outdoor temperature drops or rises, the unit compensates instantly. Thus, the unit does not have to wait for feedback by the thermostat to increase or decrease the temperature of the leaving water. Because it reacts more quickly, it prevents high rises and drops of the indoor temperature and water temperature at tap points.

Advantage

Weather-dependent operation reduces energy consumption.

Weather-dependent curve

To be able to compensate for differences in temperature, the unit relies on its weather-dependent curve. This curve defines how much the temperature of the leaving water must be at different outdoor temperatures. Because the slope of the curve depends on local circumstances such as climate and the insulation of the building, the curve can be adjusted by an installer or user.

Type of weather-dependent curve

The type of weather-dependent curve is "2-points curve".

Availability

The weather-dependent curve is available for:

- Main zone - Heating
- Main zone - Cooling
- Additional zone - Heating
- Additional zone - Cooling

4.2 Using weather-dependent curves

Related screens

The following table describes:

- Where you can define the different weather-dependent curves
- When the curve is used (restriction)

To define the curve, go to...	Curve is used when...
[1.8] Main zone > Heating WD curve	[1.5] Heating setpoint mode = Weather dependent
[1.9] Main zone > Cooling WD curve	[1.7] Cooling setpoint mode = Weather dependent
[2.8] Additional zone > Heating WD curve	[2.5] Heating setpoint mode = Weather dependent
[2.9] Additional zone > Cooling WD curve	[2.7] Cooling setpoint mode = Weather dependent




INFORMATION

Maximum and minimum setpoints


You cannot configure the curve with temperatures that are higher or lower than the set maximum and minimum setpoints for that zone. When the maximum or minimum setpoint is reached, the curve flattens out.

To define a weather-dependent curve

Define the weather-dependent curve using two setpoints (**b, c**). **Example:**



Item	Description
a	Selected weather-dependent curve: [1.8] Main zone – Heating (☀) [1.9] Main zone – Cooling (❄) [2.8] Additional zone – Heating (☀) [2.9] Additional zone – Cooling (❄)
b, c	Setpoint 1 and setpoint 2. You can change them: - By dragging the setpoint. - By tapping the setpoint, and then using the – / + buttons in d, e.
d, e	Values of the selected setpoint. You can change the values using the – / + buttons.

Item	Description
f	Restriction: Only shown if an increase was already selected via [1.26] for main zone, or [2.20] for additional zone. Increase around 0°C (same as setting [1.26] for main zone, and [2.20] for additional zone). Use this setting to compensate for possible heat losses of the building due to the evaporation of melted ice or snow. (e.g. in cold region countries). In heating operation, the desired leaving water temperature is locally increased around an outdoor temperature of 0°C.  L: Increase; R: Span; X: Outdoor temperature; Y: Leaving water temperature Possible values: ▪ No ▪ increase 2°C, span 4°C ▪ increase 2°C, span 8°C ▪ increase 4°C, span 4°C ▪ increase 4°C, span 8°C
X-axis	Outdoor temperature.
Y-axis	Leaving water temperature for the selected zone. The icon corresponds to the heat emitter for that zone: ▪ : Underfloor heating ▪ : Heat pump convector ▪ : Radiator

To fine-tune a weather-dependent curve

The following table describes how to fine-tune the weather-dependent curve of a zone:

You feel...		Fine-tune with setpoints:			
At regular outdoor temperatures ...	At cold outdoor temperatures ...	Setpoint 1 (b)		Setpoint 2 (c)	
		X	Y	X	Y
OK	Cold	↑	↑	—	—
OK	Hot	↓	↓	—	—
Cold	OK	—	—	↑	↑
Cold	Cold	↑	↑	↑	↑
Cold	Hot	↓	↓	↑	↑
Hot	OK	—	—	↓	↓
Hot	Cold	↑	↑	↓	↓
Hot	Hot	↓	↓	↓	↓

5 Energy prices

In the system, you can set the following energy prices:

- a fixed gas price (only shown in case bivalent or tank boiler is present)
- three electricity price levels
- a weekly schedule timer for electricity prices.

Example: How to set the energy prices on the user interface?

Price	Value in breadcrumb
Gas: 5.3 euro cents/kWh	[9.5]=5.3
Electricity: 12 euro cents/kWh	[9.1]=12

5.1 Energy price considered

About the setting

Restriction: The [9.13] **Energy price considered** setting is only shown in case bivalent or tank boiler is present.

If an external heat source is available, the main heat source will be chosen based on a comparison between both efficiencies of the heat sources.

The decision on which source to select depends on the setting [9.13] **Energy price considered**. This setting defines if the energy prices are considered or not.

- **When considered**, the main heat source will be decided based on the bivalent changeover condition decided by the energy prices with dedicated ambient boundaries selected by the installer
- **When NOT considered**, the main heat source will be decided based on the ambient boundaries selected by the installer without taking into account the energy prices. This case is mainly capacity driven, where below the selected boundaries, the boiler will cover the space heating.

For more information, see "[9.13] **Energy price considered**" [▶ 136] and "[5.14] **Bivalent**" [▶ 115].

To go to [9.13] Energy price considered

1	Go to [9.13] Energy > Energy price considered .
2	Switch the setting ON or OFF: 

5.2 To set the fixed electricity price (no scheduling)

1	Go to [9.1] Energy > Electricity price
2	Select the correct electricity price.
3	Confirm with the ✓ button.

Note: When no schedule is set for the electricity price, this price will be taken into account.

**INFORMATION**

Price value ranging from 0.00~5000 valuta/kWh (with 2 significant values).

5.3 To set the scheduled electricity baseline price

Restriction: Only shown when bivalent or tank boiler is present.

When [9.4] **Electricity price schedule** is ON, the electric price follows a block based schedule. The **Electricity price baseline** will be used at times when no electricity price is scheduled (i.e. in between the schedule blocks).

1	Go to [9.2] Energy > Electricity price baseline
2	Select the correct electricity price baseline.
3	Confirm with the ✓ button.


**INFORMATION**

Price value ranging from 0.00~5000 valuta/kWh (with 2 significant values).

5.4 To set the electricity price schedule

1	Go to [9.4] Energy > Electricity price schedule .
2	Program the selection using the scheduling screen. See " 3.2 Schedule screen: Example " [▶ 19].
3	Confirm with the ✓ button.

To enable the schedule:

1	Go to [9.3] Energy > Electricity price schedule enable .
2	Switch Electricity price schedule enable ON: 

5.5 To set the gas price

Restriction: Only when bivalent or tank boiler is present.

1	Go to [9.5] Energy > Gas price .
2	Select the correct gas price.
3	Confirm with the ✓ button.

**INFORMATION**

Price value ranging from 0.00~5000 valuta/kWh (with 2 significant values).

5.6 About energy prices in case of an incentive per kWh renewable energy

An incentive can be taken into account when setting the energy prices. Although the running cost can increase, the total operation cost, taking into account the reimbursement will be optimized.



NOTICE

Make sure to modify the setting of the energy prices at the end of the incentive period.

5.6.1 To set the gas price in case of an incentive per kWh renewable energy

Calculate the value for the gas price with the following formula:

- Actual gas price+(Incentive/kWh×0.9)

For the procedure to set the gas price, see ["5.5 To set the gas price"](#) [▶ 28].

5.6.2 To set the electricity price in case of an incentive per kWh renewable energy

Calculate the value for the electricity price with following formula:

- Actual electricity price+Incentive/kWh

For the procedure to set the electricity price, see:

- ["5.2 To set the fixed electricity price \(no scheduling\)"](#) [▶ 27]
- ["5.3 To set the scheduled electricity baseline price"](#) [▶ 28]
- ["5.4 To set the electricity price schedule"](#) [▶ 28]

5.6.3 Example

This is an example and the prices and/or values used in this example are NOT accurate.

Data	Price/kWh
Gas price	4.08
Electricity price	12.49
Renewable heat incentive per kWh	5

Calculation of the gas price

Gas price=Actual gas price+(Incentive/kWh×0.9)

Gas price=4.08+(5×0.9)

Gas price=8.58

Calculation of the electricity price

Electricity price=Actual electricity price+Incentive/kWh

Electricity price=12.49+5

Electricity price=17.49

Price	Value in breadcrumb
Gas: 4.08 /kWh	[9.5]=8.6
Electricity: 12.49 /kWh	[9.1]=17

6 Domestic hot water control

6.1 About domestic hot water control

In case of ECH₂O units: The DHW tank heat up mode is always **Reheat** (no installer setting). There are two possibilities to use the **Reheat** mode:

- **Reheat** mode: the DHW tank continuously heats up to the temperature shown on the home screen (example: 45°C).
- **Reheat** mode with schedule: the DHW tank set temperature varies according to the schedule.

In case of floor-standing or wall-mounted units: Depending on the DHW tank heat up mode (installer setting), you use a different domestic hot water control:

- **Reheat** (no scheduled reheat possible)
- **Scheduled**
- **Schedule and reheat**

To determine which DHW heat up mode you are using (method 1)

Check the installer settings table filled in by the installer.

To determine which DHW heat up mode you are using (method 2)

1	Go to [4.7] Domestic hot water > Heat up mode .
2	Check which setting is displayed: ▪ Reheat ▪ Scheduled ▪ Schedule and reheat

6.2 Reheat mode

In case of floor-standing or wall-mounted units: In **Reheat** mode, the DHW tank continuously heats up to the temperature shown on the home screen (example: 45°C) when the temperature drops below a certain value.

In case of ECH₂O units: There are two possibilities to use the **Reheat** mode:

- **Reheat** mode: the DHW tank continuously heats up to the temperature shown on the home screen (example: 45°C).
- **Reheat** mode with schedule: the DHW tank set temperature varies according to the schedule.

Heat-up of the DHW tank is controlled by two triggers:

1 [4.12] **Hysteresis**:

This trigger compensates for natural heat losses and intermittent DHW usage. The system continuously monitors for heat loss, and when the tank temperature drops below "[4.5] **Reheat setpoint** – [4.12] **Hysteresis**", it starts determining when reheating is necessary.

This trigger ensures that the system maintains sufficient hot water availability before temperatures fall too low for user demand.

2 [4.19] Reheat Trigger Threshold:

Only applicable for DHW consumption (rapid decrease of temperature). The tank heats up when the temperature drops below a predefined value. The threshold is set with sufficient spare capacity to prevent an immediate shortage of hot water for the end user.


It ensures that the system maintains a reliable supply while avoiding unnecessary reheating cycles.

Note: Only available in **Advanced settings** mode.

Note: Always make sure to use a value lower than [4.5] Reheat setpoint.

By using these two triggers, the system efficiently balances energy consumption while ensuring a reliable supply of hot water when needed.

Example:



INFORMATION


Risk of space heating capacity shortage for domestic hot water tank without internal booster heater: In case of frequent domestic hot water operation, frequent and long space heating/cooling interruption will happen when selecting **Operation mode = Reheat** (only reheat operation allowed for the tank).

To set the DHW Reheat mode

1	Go to [4.7] Domestic hot water > Heat up mode.
2	Set Heat up mode to Reheat.

To change the tank temperature setpoint

In **Reheat** and **Schedule and reheat** mode, you can use the tank temperature setpoint screen to adjust the domestic hot water temperature.

1	Go to [4.5]: Domestic hot water > Reheat setpoint.
2	Adjust the domestic hot water temperature: 


Reheat mode with schedule

In reheat mode with schedule, the DHW tank set temperature varies depending on the reheat setpoint defined in the schedule. DHW tank set temperature can be adjusted to the best possible requirement on the daily demand. The hysteresis and the trigger threshold for reheating are the same as for reheating without a schedule.

Note: The hysteresis value is always the same for each defined reheat setpoint.

1	Go to: [4.24] Domestic hot water > Enable reheat schedule
2	Switch scheduling ON (or OFF): Enable reheat schedule ☒
3	Go to: [4.24] Domestic hot water > Reheat schedule
4	Program the Reheat schedule (see "3.1 Using and programming schedules" [▶ 13]).

Example:



In the example 2 reheat setpoints are defined.

- At first, the reheat setpoint is programmed as **45°C**.
- Then at 14:00, the value is increased to **60°C**.
- And later at 21:00, it is lowered back to **45°C**.

With the higher temperature in the afternoon and evening, more hot water is available.

During the night and the morning where no high demand is needed, the temperature is lower.

When the temperature drops below the reheat trigger threshold, the heat pump will heat up to the reheat setpoint programmed at this time block.

6.3 Schedule and reheat mode

This topic is not applicable for ECH₂O units, for which the DHW tank heat up mode is always **Reheat**.

In **Schedule and reheat** mode, the domestic hot water control is the same as in scheduled mode. However, when the DHW tank temperature drops below a value, the DHW tank heats up until it reaches the reheat setpoint (example: 45°C). This ensures that a minimum amount of hot water is available at all times.

See "3.2 Schedule screen: Example" [▶ 19] for an example how to set up a schedule.

For **Schedule and reheat**, the heat-up of the DHW tank is controlled by three triggers:

1 [4.6] **Single heat-up schedule**:

The tank heats up according to the time and temperature as scheduled.

2 [4.12] **Hysteresis**:

This trigger compensates for natural heat losses and intermittent DHW usage. The system continuously monitors for heat loss, and when the tank temperature drops below "[4.5] **Reheat setpoint** – [4.12] **Hysteresis**", it starts determining when reheating is necessary.

This trigger ensures that the system maintains sufficient hot water availability before temperatures fall too low for user demand.

3 [4.19] **Reheat Trigger Threshold**:

Only applicable for DHW consumption (rapid decrease of temperature). The tank heats up when the temperature drops below a predefined value. The threshold is set with sufficient spare capacity to prevent an immediate shortage of hot water for the end user.


It ensures that the system maintains a reliable supply while avoiding unnecessary reheating cycles.

Note: Only available in **Advanced settings** mode.

Note: Always make sure to use a value lower than [4.5] **Reheat setpoint**.

By using these three triggers, the system efficiently balances energy consumption while ensuring a reliable supply of hot water when needed.

Example:



To set up a schedule

See "3.2 **Schedule screen: Example**" [▶ 19] for an example how to set up a schedule.

To set the Schedule and reheat mode

1	Go to [4.7] Domestic hot water > Heat up mode .
2	Set Heat up mode to Schedule and reheat .

To change the tank temperature setpoint

In **Reheat** and **Schedule and reheat** mode, you can use the tank temperature setpoint screen to adjust the domestic hot water temperature.

1	Go to [4.5]: Domestic hot water > Reheat setpoint .
---	---

2

Adjust the domestic hot water temperature:

Reheat setpoint
Set temperature to...

50.0 °C

⬆

⬇

⏪

⏩

✓

Note: In **Schedule** and **reheat** mode, the **Reheat setpoint** is used in between the scheduled heat-ups (to the temperature that is set in the schedule).


6.4 Scheduled mode

This topic is not applicable for ECH₂O units, for which the DHW tank heat up mode is always **Reheat**.

In **Scheduled** mode, the DHW tank produces hot water corresponding to a schedule.

For **Scheduled**, the heat-up of the DHW tank is triggered by [4.6] **Single heat-up schedule**. The tank heats up according to the time and temperature as scheduled.

Example:



- Initially, the DHW tank temperature is the same as the temperature of the domestic water entering the DHW tank (example: **15°C**).
- At 00:00 the DHW tank is programmed to heat up the water to **55°C**.
- During the morning, you consume hot water and the DHW tank temperature decreases.
- At 14:00 the DHW tank is programmed to heat up the water to **45°C**. Hot water is available again.
- During the afternoon and evening, you consume hot water again and the DHW tank temperature decreases again.
- At 00:00 the next day, the cycle repeats.

To set up a schedule

See "3.2 Schedule screen: Example" [▶ 19] for an example how to set up a schedule.

To set the DHW Scheduled mode

1	Go to [4.7] Domestic hot water > Heat up mode.
2	Set Heat up mode to Scheduled.

6.5 Single heat-up

Single heat-up immediately starts heating up the DHW tank using one of the following two modes:

- **Manual**
- **Powerful operation**

Manual mode

The tank heats up in an efficient way.

Powerful operation mode

In case of floor-standing or wall-mounted units: The tank heats up using the backup heater or booster heater. For more information, see "[6.5.2 Powerful heating mode](#)" [▶ 35].

In case of ECH₂O units: The tank heats up using the backup heater or tank boiler. For more information, see "[6.5.2 Powerful heating mode](#)" [▶ 35].

6.5.1 Manual mode

About Manual mode

Manual immediately starts the domestic hot water heat-up, but in a more efficient way than the **Powerful heating**.

Use this mode on days when there is more hot water usage than usual, and more hot water is needed in an efficient way. **Manual** heat-up can take longer than using **Powerful heating**.

To check if Manual heat-up is active

If  is displayed on the home screen, DHW tank heat-up is ongoing. However, to see if **Manual** operation is active, you can follow the activate/deactivate steps as described below.

Activate or deactivate **Manual** as follows:

1	Go to [4.1] Domestic hot water > Single heat-up . Note: Tap on the Domestic hot water bar from the home screen to quickly access [4.1].
2	Turn Single heat-up ON using the  button, and select Manual .
3	Confirm with the  button.

Or alternatively:

1	Go to [4.3] Manual setpoint .
2	Press the Start button to activate the heat-up process.

Note: To stop an ongoing heat-up process, tap on the **Domestic hot water** bar from the home screen and press the  button.

6.5.2 Powerful heating mode

About Powerful heating

Powerful heating starts the domestic hot water heat-up immediately. To speed up the heat-up, the additional heat source will assist the heat pump when the heat pump has passed its start-up phase, and is operating at maximum capacity.

- In case of floor-standing or wall-mounted units: additional heat source = backup heater or booster heater
- In case of ECH₂O units: additional heat source = backup heater or tank boiler

Use this mode on days when there is more hot water usage than usual, and more hot water is needed quickly.

The **Powerful heating** mode will consume more energy than the **Manual** mode.

To check if Powerful heating is active

If  is displayed on the home screen, **Powerful heating** is active.

Activate or deactivate **Powerful heating** as follows:

1	Go to [4.1] Domestic hot water > Single heat-up . Note: Tap on the Domestic hot water bar from the home screen to quickly access [4.1].
2	Turn Single heat-up ON using the  button, and select Powerful heating .
3	Confirm with the  button.

Or alternatively:

1	Go to [4.4] Powerful operation setpoint .
2	Press the Start button to activate the heat-up process.

Note: To stop an ongoing heat-up process, tap on the **Domestic hot water** bar from the home screen and press the  button.

Usage example: You immediately need more hot water

You are in the following situation:

- You already consumed most of your domestic hot water.
- You cannot wait for the next scheduled action to heat up the domestic hot water tank.



INFORMATION

When powerful operation is active, the risk of space heating/cooling and capacity shortage comfort problems is significant. In case of frequent domestic hot water operation, frequent and long space heating/cooling interruptions will happen.

6.6 Additional heat source for DHW

Additional heat source take-over during space heating/cooling

In case of wall-mounted units: When this setting is enabled, the booster heater will be used for tank heat-up if the unit is balancing between space heating/cooling and tank heat-up.

In case of ECH₂O units: When this setting is enabled, the tank boiler will be used for tank heat-up if the unit is balancing between space heating/cooling and tank heat-up.

1	Go to [4.16] Domestic hot water > Add. source take over during SH/C
----------	---

2	Switch Add. source take over during SH/C ON: Add. source take over during SH/C 
---	---

Note: Default setting is OFF.

Note: When ON, energy consumption can be higher.

Additional heat source DHW always on request

In case of wall-mounted units: When this setting is enabled, the booster heater will be used together with the heat pump during a tank heat-up, even when the unit is not balancing between space heating/cooling and tank heat-up.

In case of ECH₂O units: When this setting is enabled, the tank boiler will be used together with the heat pump during a tank heat-up, even when the unit is not balancing between space heating/cooling and tank heat-up.

1	Go to [4.17] Domestic hot water > Add. source DHW always on request
2	Switch Add. source DHW always on request ON: Add. source DHW always on request 

Note: Default setting is OFF.

Note: When ON, energy consumption will be higher.

7 Modbus TCP/IP for Daikin Altherma

7.1 Modbus protocol

The following Modbus protocol can be used:

- Modbus TCP/IP

Modbus TCP/IP

Parameter	Value
Network	Ethernet
Port	▪ No encryption: 502 ▪ TLS encryption: 802
IP address	IP address of Daikin Altherma 4

The Modbus algorithm is change based. This means the unit is only updated if a change in configuration is detected. To prevent changes being lost due to communication outages, it is recommended to periodically refresh the state from client side.



INFORMATION

A total of 3 concurrent connections is possible.

Example: 3x using the 502 port, 3x using the 802 port, or a combination of both, e.g. 1x 502 and 2x 802.

7.2 Modbus registers

There are 4 types of registers:

- holding registers,
- input registers,
- discrete input registers,
- coil registers.

Register type	Access
Holding register	Read/Write
Input register	Read-only
Discrete input register	Read-only
Coil registers	Read/Write

Modbus addressing model

Data model numbering (register offset) is 1-based while PDU addressing is 0-based.

Example: To access register 1, you have to use PDU address 0.

The Modbus registers return data in the following formats:

Data type	Signed	Bits	Scaling	Range
Temp16	Signed, two's complement	16	/100	–327.68~327.67°C
Int16			—	–32768~32767
Text16	Unsigned			2 ASCII characters
Pow16	Signed, two's complement		/100	–327.68~327.67 kW




INFORMATION

- Temperature sensor values are returned in Modbus using the Temp16 data format. To convert the value to centigrade, read the Modbus register as a signed 16-bit value and then divide by 100.
- Power values are returned in Modbus using the Pow16 data format. To convert the value to kilowatts (kW), read the Modbus register as a signed 16-bit value and then divide by 100. To write a value in the Modbus register, first multiply your power value in kW with 100.



INFORMATION

Unit error codes are returned in Modbus using the Text16 data format. The 16-bit register value MUST be converted to an error code consisting of 2 ASCII characters. Both the high byte value and the low byte value of the 16-bit value represent an ASCII character. Combined, the 2 ASCII characters form the unit error code.



7.2.1 Holding registers

Register offset	Name	Type	Range
1	Leaving water Main Heating setpoint	Int16	0~100°C
2	Leaving water Main Cooling setpoint		0~100°C
3 ^(a)	Operation mode		0: Auto 1: Heating 2: Cooling
4	Space heating/cooling ON/OFF		0: OFF 1: ON
6	Room thermostat control Heating setpoint Main		12~30°C
7	Room thermostat control Cooling setpoint Main		12~35°C
9	Quiet mode operation		0: OFF 1: ON (Automatic) 2: ON (Manual)
10	DHW reheat setpoint ^(b)		30~85°C
13	DHW booster mode ON/OFF (Powerful)		0: OFF 1: ON
14	DHW boost setpoint (Powerful)	Temp16	30~85°C
15	DHW Single heat-up ON/OFF (Manual)	Int16	0: OFF 1: ON
16	DHW Single heat-up setpoint (Manual)	Temp16	30~85°C
54	Weather-dependent mode Main LWT Heating setpoint offset	Int16	-10~10°C
55	Weather-dependent mode Main LWT Cooling setpoint offset		-10~10°C
56	Smart Grid operation mode		0: Free running 1: Forced off 2: Recommended on 3: Forced on
58	Imposed power limit	Pow16	0~20 kW

Register offset	Name	Type	Range
63	Leaving water Add Heating setpoint	Int16	3~85°C
64	Leaving water Add Cooling setpoint		3~85°C
66	Weather-dependent mode Add LWT Heating setpoint offset		-10~10°C
67	Weather-dependent mode Add LWT Cooling setpoint offset		-10~10°C
68	Weather-dependent mode Heating Main		0: Fixed 1: Weather dependent
69	Weather-dependent mode Cooling Main		0: Fixed 1: Weather dependent
71	Weather-dependent mode Heating Add		0: Fixed 1: Weather dependent
72	Weather-dependent mode Cooling Add		0: Fixed 1: Weather dependent
74	Thermostat request Main		0: None 1: Heating 2: Cooling
75	Thermostat request Add		0: None 1: Heating 2: Cooling
76	Room thermostat control Heating setpoint Main	Temp16	12.00~30.00°C
77	Room thermostat control Cooling setpoint Main		12.00~35.00°C
78	Room thermostat control Heating setpoint Add		12.00~30.00°C
79	Room thermostat control Cooling setpoint Add		12.00~35.00°C
80	DHW mode setting	Int16	0: Reheat 1: Schedule and reheat 2: Scheduled

^(a) For heating only units, the register will show 32766.

^(b) The DHW setpoint register is only propagated when the following conditions apply:

- Tank operation is enabled
- Heat pump mode is set to **Reheat** only
- Setpoint mode is set to **Fixed**



INFORMATION

The available range for setpoint registers is determined by the Minimum and Maximum Setpoint of the function defined in the Daikin Altherma system field settings. See the operation manual of the Daikin Altherma for the setpoint ranges.

**INFORMATION**

If a write to a setpoint register is outside of the configured range of the register, the setpoint will be set to the nearest valid minimum or maximum value. For all other registers, if a value outside of the register range is written, then the register value is NOT updated.

**NOTICE**

External room thermostat requests. You can define the external room thermostat requests in different ways:

1. Via hardware:

- Install an external room thermostat.
- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Hardware**.
- In the selection box **Connection type**, select which external room thermostat type you used (**Single contact** or **Dual contact**).

2. Via Modbus:

- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Modbus**.
- Main zone: Use holding register 74: Thermostat request Main.
- Additional zone: Use holding register 75: Thermostat request Add.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikineurope.com>.

- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Cloud**.
- Use the ONECTA cloud API to adjust the external room thermostat requests.

**NOTICE**

Smart Grid operation mode. You can define the Smart Grid operation mode in different ways:

1. Via hardware:

- Install 2 incoming Smart Grid contacts.
- Set [9.14.1] = **Smart grid ready contacts**.
- In the selection box **Connection type**, select **Hardware**.
- Use the 2 incoming Smart Grid contacts to define the mode.

2. Via Modbus:

- Set [9.14.1] = **Smart grid ready contacts**.
- In the selection box **Connection type**, select **Modbus**.
- Use holding register 56: Smart Grid operation mode.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikineurope.com>.

- Set [9.14.1] = **Smart grid ready contacts**.
- In the selection box **Connection type**, select **Cloud**.
- Use the ONECTA cloud API to adjust the Smart Grid operation mode.

**NOTICE**

Imposed power limit. You can define a maximum limit to the power consumption of the heat pump and the electrical heat sources in different ways.

1. Via hardware contact:

- Install a Smart Grid meter.
- Set [9.14.1] = **Smart Meter Contact**.
- Define the imposed power limit in [9.14.7] **Smart meter limit**.

2. Via Modbus:

- Use holding register 58: Imposed power limit.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikineurope.com>.

- Use the ONECTA cloud API to define the imposed power limit.

Note:

- The imposed power limit can be ignored when the unit runs protective functions (defrost, water pipe freeze prevention, start-up control, maintenance mode).
- If the power limit is too strict to allow start-up or defrost operation, the heat pump will not operate.
- If the power limit is not too strict to allow start-up or defrost operation, the heat pump will operate. However, if the limit is exceeded for too long during operation modes other than start-up or defrost, the unit will stop operating.
- If the backup heater needs to support for protective reasons, the backup heater will kick in with at least a capacity of 2 kW (to ensure reliable operation) even if the power limit would be exceeded.

7.2.2 Input registers

Register offset	Name	Type	Range
21	Unit abnormality	Int16	▪ 0: No error ▪ 1: Fault ▪ 2: Warning
22	Unit abnormality code	Text16	2 ASCII characters

Register offset	Name	Type	Range
23	Unit abnormality sub code	Int16	- If no error: 32766 - If unit error: 0~99
30	Circulation pump running		0: OFF 1: ON
31	Compressor run		0: OFF 1: ON
32	Booster heater run		0: OFF 1: ON
33	Disinfection operation		0: OFF 1: ON
35	Defrost/Restart		0: OFF 1: ON
36	Hot start		0: OFF 1: ON
37	3-way valve		0: Space heating 1: DHW
38	Operation mode		0: None 1: Heating 2: Cooling
40	Leaving water temperature PHE (plate heat exchanger)	Temp16	-100.00~100.00°C
41	Leaving water temperature BUH (backup heater)		-100.00~100.00°C
42	Return water temperature		-100.00~100.00°C
43	Domestic Hot Water temperature		-100.00~100.00°C
44	Outside air temperature		-100.00~100.00°C
45	Liquid refrigerant temperature		-100.00~100.00°C
49	Flow rate	Int16	0~100 litres/minute
50	Remote controller room temperature (Main)	Temp16	-100.00~100.00°C
51	Heat pump power consumption	Pow16	0~20.00 kW
52	DHW normal operation	Int16	0: Idle/Buffering 1: Operation
53	Space heating/cooling normal operation		0: Idle/Buffering 1: Operation

Register offset	Name	Type	Range
54	Leaving water Main Heating setpoint Lower limit	Temp16	15~85°C
55	Leaving water Main Heating setpoint Upper limit		15~85°C
56	Leaving water Main Cooling setpoint Lower limit		5~22°C
57	Leaving water Main Cooling setpoint Upper limit		5~22°C
58	Leaving water Add Heating setpoint Lower limit		15~85°C
59	Leaving water Add Heating setpoint Upper limit		15~85°C
60	Leaving water Add Cooling setpoint Lower limit		5~22°C
61	Leaving water Add Cooling setpoint Upper limit		5~22°C
63	Disinfection state	Int16	0: Unsuccessful 1: Successful 2: Maintain 3: Heat Up
64	Holiday mode		0: OFF 1: ON
65	Demand response mode		0: Free 1: Forced Off 2: Forced On 3: Recommended On 4: Reduced
66	Bypass valve position		0~100%
67	Tank valve position		0~100%
68	Circulation pump speed		0~100 litres/minute
69	Mixed pump PWM in mixing kit		0~100%
70	Direct pump PWM in mixing kit		0~100%
71	Mixing valve position in mixing kit		0~100%

Register offset	Name	Type	Range
72	Mixing Leaving water temperature in mixing kit	Temp16	–100.00~100.00°C
73	Space heating/cooling target for Main zone in mixing kit		–100.00~100.00°C
74	Leaving water temperature pre-PHE outdoor		–128.99~128.99°C
75	Leaving water temperature Tank valve		–127.00~127.00°C
76	Domestic Hot Water Upper temperature		–127.00~127.00°C
77	Domestic Hot Water Lower temperature		–127.00~127.00°C
78	Remote controller room temperature (Add)		–100.00~100.00°C
79	Water pressure	Int16	10~600 bar
80	Space heating/cooling target for Main zone	Temp16	–127.00~127.00°C
81	Space heating/cooling target for Add zone		–127.00~127.00°C
82	Abnormality counter (user)	Int16	0~200
83	Unit operation mode		▪ 0: Stop ▪ 1: Tank Heat Up ▪ 2: Space heating ▪ 3: Space cooling ▪ 4: Actuator
84	Room Heating setpoint Lower limit	Temp16	12.00~30.00°C
85	Room Heating setpoint Upper limit		12.00~30.00°C
86	Room Cooling setpoint Lower limit		12.00~35.00°C
87	Room Cooling setpoint Upper limit		12.00~35.00°C

7.2.3 Discrete input registers

Register offset	Name	Type	Range
1	Shut-off valve	Bit	0~1
2	Backup heater relay 1		0~1
3	Backup heater relay 2		0~1
4	Backup heater relay 3		0~1
5	Backup heater relay 4		0~1
6	Backup heater relay 5		0~1
7	Backup heater relay 6		0~1
8	Booster heater		0~1
9	Tank boiler		0~1
10	Bivalent		0~1
11	Compressor run		0~1
12	Quiet mode active		0~1
13	Holiday active		0~1
14	Antifrost status		0~1
15	Water pipe freeze prevention status		0~1
16	Disinfection operation		0~1
17	Defrost		0~1
18	Hot start		0~1
19	DHW running		0~1
20	Main zone running		0~1
21	Additional zone running		0~1
22	Powerful tank heat up request		0~1
23	Manual tank heat up request		0~1
24	Emergency active		0~1
25	Circulation pump running		0~1


7.2.4 Coil registers

Register offset	Name	Type	Range
1	Domestic Hot Water ON/OFF	Bit	0~1
2	Main zone ON/OFF		0~1
3	Additional zone ON/OFF		0~1

7.3 Connecting the electrical wiring

7.3.1 To connect the electrical wiring

Modbus TCP/IP for Daikin Altherma




- a** Outdoor unit
- b** Daikin Altherma
- c** Internet router
- d** Home Energy Manager (HEM) or Energy Utility Controller

7.4 Third-party Modbus integrations

This use case makes it possible for a third-party Home Energy Manager (HEM) to communicate with the heat pump. Through the home router, they can execute a range of commands, for example changing the setpoint of the heat pump. For the full list of possible commands, see ["7.2 Modbus registers" \[▶ 38\]](#).

This use case is compatible with the Modbus IP standards.



- a** Outdoor unit
- b** Daikin Altherma
- c** Solar inverter
- d** Solar panels
- e** Home router
- f** Home Energy Manager (HEM)
- g** Home automation app
- h** Electrical grid
- i** Smart window blinds
- j** Smart lighting



INFORMATION

Any power limitation is applied to the whole system. This can affect the system performances.


The functionality of the system CAN also be compromised in case of:

- Power loss of the unit,
- Network communication delays.

7.5 Smart Grid for utilities

This use case makes it possible for energy utilities to communicate with the heat pump. Through the home router, they can balance the grid and avoid peaks by enforcing a Smart Grid (SG) operation mode. The SG operation mode adjusts the settings of the heat pump by turning it on/off. In parallel, the power of the heat pump can be adjusted by increasing or decreasing the power limit. For the full list of possible commands, see ["7.2 Modbus registers" \[▶ 38\]](#).

This use case is compatible with the Modbus IP standards.



INFORMATION

Any power limitation is applied to the whole system. This can affect the system performances.

The functionality of the system CAN also be compromised in case of:

- Power loss of the unit,
- Network communication delays.

7.6 Energy buffering with Smart Grid

The home router allows a third party (e.g. an energy utility) to set a Smart Grid operation mode. In parallel, the power of the heat pump system can be adjusted by increasing or decreasing the power limit. Both actions help to balance the grid and avoid peaks.

There are 4 possible Smart Grid operation mode requests. Depending on Smart Grid operation mode, eneenergy buffering either happens in the domestic hot water only, or in the domestic hot water tank and in the room.

Free running (normal operation)

There is no interference with the normal operation of the unit, except that the power consumption is limited to the Modbus imposed power limit (register 58).

Forced off (blocked operation)

The unit is forced to stop (except during protective functions: defrost, water pipe freeze prevention, start-up control, maintenance mode). See also [" \[9.14\] Demand response" \[▶ 136\]](#):

- [9.14.2] SH heater take-over during forced off
- [9.14.3] DHW heater take-over during forced off

Forced on

If the unit is operating in normal space heating/cooling or DHW mode, it continues in this mode. If the unit is idle, it is activated to store energy (either in the DHW storage tank or the room). The rate at which the unit consumes energy (both during buffering and normal operation) is limited to the Modbus imposed power limit (register 58).

Energy buffering	System requirements	Description
Domestic hot water tank	- Make sure a domestic hot water tank is part of the system. See " [9.14] Demand response" [▶ 136] for more details about settings. - Unit control method (user interface setting [1.12]): no requirements, but mind the information below.	The system produces domestic hot water. The tank heats up the water up to the maximum tank temperature (depending on the tank type and set by [4.11]). The electrical heaters will assist with the buffering of energy in the domestic hot water tank.
Room (heating)	Unit control method: on the user interface, make sure [1.12] = 2 (room thermostat control)	The system heats up the room up to the comfort setpoint. ^(a)
Room (cooling)	Unit control method: on the user interface, make sure [1.12] = 2 (room thermostat control)	The system cools down the room down to the comfort setpoint. ^(b)

^(a) In case the actual room temperature is below the comfort heating setpoint.

^(b) In case the actual room temperature is above the comfort cooling setpoint.

Recommended on

If the unit is operating in normal space heating/cooling or DHW mode, it continues in this mode. If the unit is idle, it is activated to store energy. Contrary to **Forced on**, the energy storage during **Recommended on** can be controlled with the allowance flags for room buffering and electrical heaters. The rate at which the unit consumes energy during normal operation is limited to the Modbus imposed power limit (register 58).

Energy buffering	System requirements	Description
Domestic hot water tank	- Make sure a domestic hot water tank is part of the system. See "[9.14] Demand response" [▶ 136] for more details about settings. - Unit control method (user interface setting [1.12]): no requirements, but mind the information below.	The system produces domestic hot water. The tank heats up the water up to the maximum tank temperature, depending on the tank type and set by [4.11]. If tank buffering is done without electrical heaters, the target temperature is the highest temperature achievable by the heat pump. See also [9.14.6] BUH+BSH support during DHW recommended on.
Room (heating)	- Allow for buffering in the room - Unit control method: on the user interface, make sure [1.12] = 2 (room thermostat control)	The system heats up the room up to the comfort setpoint.^(a) See also: [9.14.4] Allow buffering space H/C [9.14.5] BUH support during SH recommended on
Room (cooling)	- Allow for buffering in the room - Unit control method: on the user interface, make sure [1.12] = 2 (room thermostat control)	The system cools down the room down to the comfort setpoint.^(b) See also [9.14.4] Allow buffering space H/C.

^(a) In case the actual room temperature is below the comfort heating setpoint.

^(b) In case the actual room temperature is above the comfort cooling setpoint.



NOTICE

If the water/tank temperature is too low to allow heat pump operation, and setting [9.14.5] **BUH support during SH recommended on** / [9.14.6] **BUH+BSH support during DHW recommended on** is set to OFF (not allowed), then the electrical heaters will NOT push the heat pump into the operation range (because the electrical heaters are then not allowed).



NOTICE

In case of removing the DHW tank from a wall-mounted unit set-up, you **MUST** follow the configuration wizard.

**INFORMATION**

Room buffering is ONLY possible if the unit control method [1.12] = 2 (room thermostat control). This means that if an external room thermostat (Daikin or third party) is configured for the main zone, room buffering is ONLY possible in the additional zone.

**INFORMATION****Tank/room buffering priority:**

- The system starts tank buffering first. When tank buffering is at its maximum capacity, then the system switches to room buffering (if enabled).
- Tank buffering can switch to room buffering prior to reaching the maximal capacity because of internal unit logic. In normal operation, the maximum running time for domestic hot water is applicable. See the installer reference guide of the indoor unit for more details.
- When room buffering is ongoing and the tank drops below its maximum capacity (e.g. someone takes a shower), then the system stays at room buffering for a certain amount of time before it switches back to tank buffering.

7.6.1 Buffering in case [1-12] = 0 [LWT control]

When, on the user interface, [1.12] = 0 (the unit control method is leaving water temperature control), the system is constantly working in normal operation to keep the leaving water at a constant temperature. Energy buffering can only happen in the domestic hot water tank, and only when the system is NOT in normal operation. This is the case in the following two separate cases:


- Space heating/cooling operation is turned OFF

OR

- During space heating operation:
 - Outdoor temperature > space heating setting [3.1]
 - Room frost protection is not active
- During space cooling operation:
 - Outdoor temperature < space cooling setting [3.1]

8 Cloud for Daikin Altherma

8.1 Third-party Cloud integrations



For individual developers

We offer basic functionality to monitor and control your Daikin Altherma via the ONECTA cloud API. For more information, see <https://developer.cloud.daikineurope.com>.

Note: For this feature to work, your Daikin Altherma needs to be connected to the ONECTA cloud by using the ONECTA application.

Note: This feature is not meant for regular end users (they can use the ONECTA app instead), but for private or open-source developers:

- Ideal for developers building integrations for personal use or for a group of users.
- Developers or users of the integration must obtain individual API credentials via the self-service feature on the developer portal.
- Daikin does not provide dedicated support to private or open-source developers.

For enterprises or energy integrators

We offer more functionality. For more information, see <https://developer.cloud.daikineurope.com>.

Note: This feature is not meant for regular end users (they can use the ONECTA app instead), but for Business Partners:

- As a Business Partner, you represent a company that focuses on Home Automation, Energy Management, or Demand Response Solutions and creates an integration for your customers.
- API credentials for your integration can be retrieved via the developer portal. Business Partners must have their integration validated and sign a license agreement before distributing it to ONECTA-connected customers. These customers will not need to obtain API credentials individually.

For some of the functionality to work (see notices below: "**3. Via Cloud**"), you will need to do some settings on the user interface before you can adjust the settings via API.

**NOTICE**

External room thermostat requests. You can define the external room thermostat requests in different ways:

1. Via hardware:

- Install an external room thermostat.
- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Hardware**.
- In the selection box **Connection type**, select which external room thermostat type you used (**Single contact** or **Dual contact**).

2. Via Modbus:

- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Modbus**.
- Main zone: Use holding register 74: Thermostat request Main.
- Additional zone: Use holding register 75: Thermostat request Add.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikineurope.com>.

- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Cloud**.
- Use the ONECTA cloud API to adjust the external room thermostat requests.

**NOTICE**

Smart Grid operation mode. You can define the Smart Grid operation mode in different ways:

1. Via hardware:

- Install 2 incoming Smart Grid contacts.
- Set [9.14.1] = **Smart grid ready contacts**.
- In the selection box **Connection type**, select **Hardware**.
- Use the 2 incoming Smart Grid contacts to define the mode.

2. Via Modbus:

- Set [9.14.1] = **Smart grid ready contacts**.
- In the selection box **Connection type**, select **Modbus**.
- Use holding register 56: Smart Grid operation mode.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikineurope.com>.

- Set [9.14.1] = **Smart grid ready contacts**.
- In the selection box **Connection type**, select **Cloud**.
- Use the ONECTA cloud API to adjust the Smart Grid operation mode.

**NOTICE**

Imposed power limit. You can define a maximum limit to the power consumption of the heat pump and the electrical heat sources in different ways.

1. Via hardware contact:

- Install a Smart Grid meter.
- Set [9.14.1] = **Smart Meter Contact**.
- Define the imposed power limit in [9.14.7] **Smart meter limit**.

2. Via Modbus:

- Use holding register 58: Imposed power limit.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikineurope.com>.

- Use the ONECTA cloud API to define the imposed power limit.

Note:

- The imposed power limit can be ignored when the unit runs protective functions (defrost, water pipe freeze prevention, start-up control, maintenance mode).
- If the power limit is too strict to allow start-up or defrost operation, the heat pump will not operate.
- If the power limit is not too strict to allow start-up or defrost operation, the heat pump will operate. However, if the limit is exceeded for too long during operation modes other than start-up or defrost, the unit will stop operating.
- If the backup heater needs to support for protective reasons, the backup heater will kick in with at least a capacity of 2 kW (to ensure reliable operation) even if the power limit would be exceeded.

9 Other functionalities

9.1 To set Time/date

- | | |
|----------|--|
| 1 | Go to [5.3] Settings > Time/date . |
|----------|--|

Note: If your region observes daylight saving time, you can switch [5.3] **Daylight savings time** ON.

9.2 Using quiet mode

About quiet mode

You can use quiet mode to decrease the sound of the outdoor unit. However, this also decreases the heating/cooling capacity of the system. There are multiple quiet mode levels.

The user can:

- Completely deactivate quiet mode (user)
- Manually activate a quiet mode level (user)
- Program a quiet mode schedule (advanced user)

The installer can:

- Configure restrictions based on local regulations



INFORMATION

If the outdoor temperature is below zero, we recommend to NOT use the most quiet level.

To check if quiet mode is active

If one of the following icons is displayed on the home screen, quiet mode is active:

- : Quiet
- : More quiet
- : Most quiet

To completely deactivate quiet mode

(required permission level = user)

- | | |
|----------|--|
| 1 | Go to [5.2] Settings > Quiet operation .
Note: Tap on the Outdoor bar from the home screen to quickly access [5.2]. |
| 2 | Tap Off . |
| 3 | Confirm with the button.
Result: The unit never runs in quiet mode. |

To manually activate a quiet mode level

(required permission level = user)

- | | |
|----------|--|
| 1 | Go to [5.2] Settings > Quiet operation .
Note: Tap on the Outdoor bar from the home screen to quickly access [5.2]. |
|----------|--|

2	Tap Manual .
3	Confirm with the ✓ button.
4	In [5.2.1] Quiet mode - Manual , select the applicable quiet mode level. Possible values: ▪ Off ▪ Quiet ▪ More quiet ▪ Most quiet
5	Confirm with the ✓ button. Result: The unit always runs in the selected quiet mode level.

To program a quiet mode schedule

(required permission level = advanced user)

1	Go to [5.2] Settings > Quiet operation . Note: Tap on the Outdoor bar from the home screen to quickly access [5.2].
2	Tap Scheduled . Result: The following buttons appear: ▪ Schedule ▪ Restrictions (only for installers)
3	Tap Schedule .
4	In [5.2.2] Quiet operation schedule , program when the unit has to use which quiet mode level. For more information about scheduling, see " 3.1 Using and programming schedules " [▶ 13].
5	Confirm with the ✓ button. Result: You return to the previous screen.
6	In [5.2] Quiet operation , confirm again with the ✓ button. Result: The possible outcomes for the quiet mode differ depending on the schedule (if programmed) and the restrictions (if defined). See below.

To configure restrictions based on local regulations

(required permission level = installer)

1	Go to [5.2] Settings > Quiet operation . Note: Tap on the Outdoor bar from the home screen to quickly access [5.2].
2	Tap Scheduled . Result: The following buttons appear: ▪ Schedule ▪ Restrictions (only for installers)
3	Tap Restrictions .

4	In [5.2.8] Restrictions , define the restrictions (when day/night starts, and which quiet mode level to use during day/night):	
	▪ [5.2.9] AM Restricted time	Start of Day. Example: : At 6 a.m.
	▪ [5.2.10] AM Restricted level	Level used during the Day. Example: More quiet
	▪ [5.2.11] PM Restricted time	Start of Night. Example: : At 10 p.m.
	▪ [5.2.12] PM Restricted level	Level used during the Night. Example: Most quiet
5	Confirm and return with the ↩ button. Result: You return to the previous screen.	
6	In [5.2] Quiet operation , confirm again with the ✓ button. Result: The possible outcomes for the quiet mode differ depending on the schedule (if programmed) and the restrictions (if defined). See below.	

Possible outcomes when quiet mode is set to Scheduled

If...		Then quiet mode =...
Restrictions (time + level) defined?	Schedule programmed?	
No	No	OFF
	Yes	Follows schedule
Yes	No	Follows restriction
	Yes	The applicable level will be the most stringent one, which could either be the user-defined level in the schedule or the installer-defined restriction (e.g. 'most quiet' > 'quiet').

9.3 Using holiday mode

About holiday mode

During your holiday, you can use the holiday mode to deviate from your normal schedules without having to change them. While holiday mode is active, space heating/cooling operation and domestic hot water operation will be turned off. Room frost protection, water pipe freeze prevention and disinfection operation will remain active.

Typical workflow

Using holiday mode typically consists of the following stages:


- 1 Activating the holiday mode.
- 2 Setting the starting date and ending date of your holiday.

To check if holiday mode is activated and/or running

If  is displayed on the home screen, holiday mode is active.

To configure the holiday

Go to [5.27] **Settings > Holiday**, and do the following:

1	To activate the holiday mode, switch [5.27.1] Holiday mode ON: 
2	To define the holiday period: - Go to [5.27.2] Holiday period. - Under From, set the first day of your holiday. - Under Till, set the last day of your holiday. - Confirm with the  button. Note: The holiday period starts at noon (12h00) of the first day, and ends at noon (12h00) of the last day.

9.4 Using WLAN




INFORMATION

Restriction: WLAN settings are only visible when a WLAN cartridge is inserted in the user interface.

About the WLAN cartridge

The WLAN cartridge connects the system to the internet. As user you can then control the system via the ONECTA app.

This needs the following components:



a	WLAN cartridge	The WLAN cartridge needs to be inserted in the user interface.
b	Router	Field supply.
c	Smartphone + app 	The ONECTA app needs to be installed on the user's smartphone. See: http://www.onlinecontroller.daikineurope.com/ 

Configuration

To configure the ONECTA app, follow the in-app instructions. While doing this, the following actions and information are needed on the user interface:

- [8.3] Wireless gateway
 - [8.3.1] Wireless gateway (ON/OFF)
 - [8.3.2] Enable AP mode
 - [8.3.3] Reboot the gateway
 - [8.3.4] WPS
 - [8.3.5] Remove from cloud
 - [8.3.6] Home network connection
 - [8.3.7] Reset to factory default

[8.3.1] Wireless gateway

1	Go to [8.3.1]: Wireless gateway > Wireless gateway .
2	Remark: Wireless gateway MUST stay in the OFF position, even when WLAN is installed: Wireless gateway  Keeping the switch in OFF position will not impact WLAN functionality.

[8.3.2] Enable AP mode

Make the WLAN cartridge active as access point:

1	Go to [8.3.2]: Wireless gateway > Enable AP mode .
2	This setting generates a random SSID and key (+ QR code) needed by the ONECTA app: AP mode enabled  SSID DaikinAPXXXXX Key XYZ12345   Press one of the buttons to exit the screen.

[8.3.3] Reboot the gateway

Reboot the WLAN cartridge:

1	Go to [8.3.3]: Wireless gateway > Reboot the gateway .
2	In the Reboot the gateway screen, choose Confirm to reboot.

[8.3.4] WPS

Connect the WLAN cartridge to the router:

i INFORMATION You can only use this function if it is supported by the software version of the WLAN, and the software version of the ONECTA app.	
1	Go to [8.3.4]: Wireless gateway > WPS .
2	Switch WPS ON: WPS 

[8.3.5] Remove from cloud

Remove the WLAN cartridge from the cloud:

1	Go to [8.3.5]: Wireless gateway > Remove from cloud .
2	In the Remove from cloud screen, choose Confirm to remove the WLAN from the cloud.

[8.3.6] Home network connection

Read out the status of the connection to the home network:

1	Go to [8.3.6]: Wireless gateway > Home network connection .
2	Read out the connection status: ▪ Disconnected from [WLAN_SSID] ▪ Connected to [WLAN_SSID]

[8.3.7] Reset to factory default

Trigger to reset the WLAN cartridge to factory default (forget all network data):

1	Go to [8.3.7]: Wireless gateway > Reset to factory default .
2	Please confirm to reset to factory default. This action cannot be undone.

10 Settings

[1] Main zone

Main zone (mixed zone) = Zone with the lowest design temperature in heating, and the highest design temperature in cooling.

In this chapter

[1.1] Room setpoint	62
[1.2] Heating schedule enable.....	63
[1.3] Heating schedule	63
[1.4] Cooling schedule	64
[1.5] Heating setpoint mode	64
[1.6] Setpoint range.....	64
[1.7] Cooling setpoint mode	66
[1.8] Heating WD curve	66
[1.9] Cooling WD curve	67
[1.10] Hysteresis.....	67
[1.11] Emitter type	68
[1.12] Control.....	69
[1.13] External room thermostat	69
[1.14] Delta T heating.....	71
[1.15] NOT USED	71
[1.16] Cooling allowance	71
[1.17] Enable zone.....	72
[1.18] Delta T cooling.....	72
[1.19] Overheating water circuit.....	72
[1.20] Undercooling water circuit.....	73
[1.21] Zone name	73
[1.22] Antifrost.....	73
[1.23] Cooling schedule enable.....	74
[1.24] Leaving water shift heating schedule	74
[1.25] Leaving water shift cooling schedule	75
[1.26] Increase around 0°C.....	76
[1.27] Leaving water shift heating.....	76
[1.28] Leaving water shift cooling.....	76
[1.29] Heating comfort setpoint	76
[1.30] Cooling comfort setpoint	77
[1.31] Daikin room thermostat.....	77
[1.32] Room enable.....	77
[1.33] External room sensor offset.....	78
[1.34] Heating target baseline.....	78
[1.35] Cooling target baseline.....	78
[1.36] Scheduled WD LWT shift for heating.....	78
[1.37] Scheduled WD LWT shift for cooling.....	79
[1.38] Thermostat sensor offset	79
[1.39] Leaving water temp. heating.....	79
[1.40] NOT USED	79
[1.41] NOT USED	79
[1.42] Leaving water temp. cooling.....	79

[1.1] Room setpoint

Restriction: Only applicable if [1.12] = Room.

Setpoint for the room temperature of the main zone. See "[2.4 Setpoint screen](#)" [▶ 12].

⚙️[N/A]	Based on the active operation mode selected in [3.2] Operation mode, the room setpoint for either Heating or Cooling will be visible. Note: In case the Automatic operation mode is selected, the schedule defined in [3.5] Operation mode schedule will be followed. For more details, see " [3.2] Operation mode" [▶ 92] and " [3.5] Operation mode schedule" [▶ 94].
---------	--

[1.2] Heating schedule enable

⚙️[N/A]	Activation screen for [1.3] Heating schedule .
▪ If [1.12] = Leaving water, only the leaving water temperature schedule can be enabled/disabled: - OFF (disabled) - ON (enabled) The influence of the LWT setpoint mode [1.5] is as follows: ▪ In Fixed LWT setpoint mode, the LWT schedules need to be selected. For more details, see " [1.3] Heating schedule" [▶ 63]. Note: When Fixed setpoint mode is selected, the shift schedules are available, but will NOT have any effect. ▪ In Weather dependent LWT setpoint mode, the shift schedules need to be selected. For more details, see " [1.24] Leaving water shift heating schedule" [▶ 74]. Note: When Weather dependent setpoint mode is selected, the fixed schedules are available but will NOT have any effect.	
▪ If [1.12] = External room thermostat: - No schedule is enabled.	
▪ If [1.12] = Room, only the room temperature schedule can be enabled/disabled: - OFF: Room temperature is directly controlled by the user. - ON: Room temperature is controlled by a schedule and can be modified by the user.	

[1.3] Heating schedule

⚙️[N/A]	Applicable for all models. Restriction: Only applicable if [1.12] = Leaving water or Room. Schedule for the main zone in heating mode to set the desired leaving water or room temperature (depending on the installed system).
---------	---

Predefined schedules: 3

Activation screen: [1.2] Heating schedule enable

Possible actions: Temperatures within range.

Note: In case of room temperature scheduling, the baseline temperature will be used at times when no temperature is scheduled (i.e. in between the schedule blocks). To set the baseline temperature, go to [1.34] **Main zone > Heating target baseline**.

Note: In case of LWT scheduling, operation will be OFF when no temperature is scheduled.

[1.4] Cooling schedule

⚙️[N/A]

Restriction: Only applicable for reversible models.

Restriction: Only applicable if [1.12] = **Leaving water** or **Room**.

Schedule for the main zone in cooling mode to set the desired leaving water or room temperature (depending on the installed system).

Predefined schedules: 1

Activation screen: [1.23] Cooling schedule enable

Possible actions: Temperatures within range.

Note: In case of room temperature scheduling, the baseline temperature will be used at times when no temperature is scheduled (i.e. in between the schedule blocks). To set the baseline temperature, go to [1.35] **Main zone > Cooling target baseline**.

Note: In case of LWT scheduling, operation will be OFF when no temperature is scheduled.

[1.5] Heating setpoint mode

⚙️[N/A]

Defines the setpoint mode for the main zone during space heating operation.

- 0: **Fixed:** The desired leaving water temperature does NOT depend on the outdoor ambient temperature.
- 1: **Weather dependent:** The desired leaving water temperature depends on the outdoor ambient temperature.

When weather-dependent operation is active, low outdoor temperatures will result in warmer water and vice versa. During weather-dependent operation, the user can shift the water temperature up or down by a maximum of 10°C. For more details, see "[1.27] Leaving water shift heating" [▶ 76].

[1.6] Setpoint range

To prevent wrong (i.e. too hot or too cold) temperatures, you can limit the range of desired leaving water temperatures that users can set for the main zone.

⚙️[053]	Heating maximum^(a): ▪ If [1.11] = Radiator: [054]°C~75°C ▪ Else: [054]°C~55°C Note: The temperature of the additional zone needs to be higher than the temperature of the main zone. If the heating maximum for the additional zone is lower, the main zone temperature will follow. For more details, see the field settings table of the installer reference guide.
⚙️[054]	Heating minimum: ▪ 15°C~[053]°C
⚙️[055]	Cooling maximum: ▪ [056]°C~22°C
⚙️[056]	Cooling minimum^(b): ▪ 7°C~[055]°C

^(a) For more details, see " [3.12] Overheating setpoint" [▶ 97] and the field settings table of the installer reference guide.


^(b) For more details, see " [3.11] Undercooling setpoint" [▶ 96] and the field settings table of the installer reference guide.

The maximum setpoint range depends on the emitter type when a mixing kit or a bizon unit is connected. For more details, see " [1.11] Emitter type" [▶ 68].

The minimum leaving water target for the heat pump and the backup heater is determined by the minimum water temperature required to initiate defrost. Even if a lower setpoint is selected, the minimum active setpoint will always be the defrost start temperature and the maximum target delta T.

The maximum delta T is defined by the delta T of the main zone and the additional zone (see " [1.14] Delta T heating" [▶ 71] and " [2.14] Delta T heating" [▶ 86]).

The values in the below graph are examples. For the details about the minimum required water temperature to start defrost, go to <https://daikintechdatahub.eu/> to see the actual operation range drawing.



NOTICE

In case of a floor heating application it is important to limit the:


- maximum leaving water temperature at heating operation according to the specifications of the floor heating installation.
- the minimum leaving water temperature at cooling operation to 18~20°C to prevent condensation on the floor.



NOTICE

- When adjusting the leaving water temperature ranges, all desired leaving water temperatures are also adjusted to guarantee they are between the limits.
- Always balance between the desired leaving water temperature with the desired room temperature and/or the capacity (according to the design and selection of the heat emitters). The desired leaving water temperature is the result of several settings (preset values, shift values, weather-dependent curves, modulation). As a result, too high or too low leaving water temperatures could occur which lead to overtemperatures or capacity shortage. By limiting the leaving water temperature range to adequate values (depending on the heat emitter), such situations can be avoided.

Example: In heating mode, leaving water temperatures must be sufficiently higher than the room temperatures. To avoid that the room cannot heat up as desired, set the minimum leaving water temperature to 28°C.



[1.7] Cooling setpoint mode


⚙️[N/A]	Defines the setpoint mode for the main zone during space cooling operation.
▪ 0: Fixed: The desired leaving water temperature does NOT depend on the outdoor ambient temperature. ▪ 1: Weather dependent: The desired leaving water temperature depends on the outdoor ambient temperature.	

When weather-dependent operation is active, low outdoor temperatures will result in warmer water and vice versa. During weather-dependent operation, the user can shift the water temperature up or down by a maximum of 10°C. For more details, see "[1.28\] Leaving water shift cooling](#)" [▶ 76].

[1.8] Heating WD curve

⚙️[N/A]	Defines the weather-dependent curve used to determine the leaving water temperature of the main zone in space heating operation. Restriction: The curve is only used when [1.5] = Weather dependent .
See " 4 Weather-dependent curve " [▶ 24].	

The weather-dependent heating can be configured according to the figure below.




T_t Target leaving water temperature (main zone)

- T_a** Outdoor temperature
- a** Low outdoor ambient temperature. $-40^{\circ}\text{C}\sim+5^{\circ}\text{C}$
- b** High outdoor ambient temperature. $5^{\circ}\text{C}\sim25^{\circ}\text{C}$
- c** Desired leaving water temperature when the outdoor temperature equals or drops below the low ambient temperature. $[054]^{\circ}\text{C}\sim[053]^{\circ}\text{C}$
Note: This value should be higher than (d) as for low outdoor temperatures warmer water is required.
- d** Desired leaving water temperature when the outdoor temperature equals or rises above the high ambient temperature. $[054]^{\circ}\text{C}\sim[053]^{\circ}\text{C}$
Note: This value should be lower than (c) as for high outdoor temperatures less warm water is required.

[1.9] Cooling WD curve

[N/A]	Defines the weather-dependent curve used to determine the leaving water temperature of the main zone in space cooling operation. Restriction: The curve is only used when [1.7] = Weather dependent .
See " 4 Weather-dependent curve " [▶ 24].	

The weather-dependent cooling can be configured according to the figure below.



- T_t** Target leaving water temperature (main zone)
- T_a** Outdoor temperature
- a** Low outdoor ambient temperature. $10^{\circ}\text{C}\sim25^{\circ}\text{C}$
- b** High outdoor ambient temperature. $25^{\circ}\text{C}\sim43^{\circ}\text{C}$
- c** Desired leaving water temperature when the outdoor temperature equals or drops below the low ambient temperature. $[056]^{\circ}\text{C}\sim[055]^{\circ}\text{C}$
Note: This value should be higher than (d) as for low outdoor temperatures less cold water is required.
- d** Desired leaving water temperature when the outdoor temperature equals or rises above the high ambient temperature. $[056]^{\circ}\text{C}\sim[055]^{\circ}\text{C}$

[1.10] Hysteresis

[N/A]	Restriction: Only applicable if [1.12] = Room . Hysteresis on the room target temperature used to restart the request for space heating or cooling.
- The hysteresis band around the desired room temperature can be adjusted. $0.5^{\circ}\text{C}\sim10^{\circ}\text{C}$ Note: It is recommended NOT to change the room temperature hysteresis as it is set for optimal use of the system.	

Example:

If...	Then...
- Room heating target: 20°C - Hysteresis value: 0.5°C	- Operation starts at: 19.5°C - Operation stops at: 20.5°C
- Room cooling target: 18°C - Hysteresis value: 0.5°C	- Operation starts at: 18.5°C - Operation stops at: 17.5°C

[1.11] Emitter type

⚙️[N/A]	Must match your system layout. Emitter type of the main zone.
▪ 0: Under floor heating ▪ 1: Heat pump convector ▪ 2: Radiator	

The setting **Emitter type** influences the space heating setpoint range and the target delta T in heating as follows:

Emitter type Main zone	Space heating setpoint range [054]~[053] ^(a)	Target delta T in heating
0: Under floor heating	Maximum 55°C	3°C~10°C (see " [1.14] Delta T heating" [▶ 71], ⚙️ [169])
1: Heat pump convector	Maximum 55°C	3°C~10°C (see " [1.14] Delta T heating" [▶ 71], ⚙️ [169])
2: Radiator	Maximum 75°C	10°C~20°C (see " [1.14] Delta T heating" [▶ 71], ⚙️ [170])

^(a) This column only explains the maximum setpoint range. For more details about the setpoint range, see " [1.6] Setpoint range" [▶ 64].

Remark: When changing the emitter type from **Under floor heating** or **Heat pump convector** to **Radiator**, the maximum setpoint range will NOT automatically adapt to 75°C. If required, it needs to be manually increased again.

**INFORMATION**

The setpoint of the main zone is limited by the setpoint of the additional zone during heating operation. The setpoint of the main zone can NEVER be higher than the setpoint of the additional zone.

Heating up or cooling down the main zone can take longer. This depends on:

- The water volume of the system
- The heater emitter type of the main zone

The setting **Emitter type** can compensate for a slow or a quick heating/cooling system during the heat up/cool down cycle.

It is important to set **Emitter type** correctly and in accordance with your system layout. The target delta T for the main zone depends on it.

**NOTICE**

NOT configuring the system in the following way can cause damage to the heat emitters. If there are 2 zones, it is important that in heating:

- the zone with the lowest water temperature is configured as the main zone, and
- the zone with the highest water temperature is configured as the additional zone.

**NOTICE**

If there are 2 zones and the emitter types are wrongly configured, water of high temperature can be sent towards a low temperature emitter (underfloor heating). To avoid this:

- Install an aquastat/thermostatic valve to avoid too high temperatures towards a low temperature emitter.
- Make sure you set the emitter types for the main zone [1.11] and for the additional zone [2.11] correctly in accordance with the connected emitter.

**NOTICE**

Average emitter temperature = Leaving water temperature – (Delta T)/2

This means that for a same leaving water temperature setpoint, the average emitter temperature of radiators is lower than that of underfloor heating because of a bigger delta T.

Example radiators: $40 - 10 / 2 = 35^{\circ}\text{C}$

Example underfloor heating: $40 - 5 / 2 = 37.5^{\circ}\text{C}$

To compensate, you can increase the weather-dependent curve desired temperatures.

[1.12] Control

⚙️[041]	Defines the unit control method for the main zone.
▪ 0: Leaving water: Unit operation is decided based on the leaving water temperature regardless the actual room temperature and/or heating or cooling demand of the room. ▪ 1: External room thermostat: Unit operation is decided by the external thermostat or equivalent (e.g. heat pump convector). In case of external room thermostat control, you must also set the external room thermostat type with setting [1.13] (see " [1.13] External room thermostat" ▶ 69)). ▪ 2: Room: Unit operation is decided based on the ambient temperature of the dedicated Human Comfort Interface (BRC1HHDA used as room thermostat).	

[1.13] External room thermostat

Note: To be used in combination with [1.12] = External room thermostat.

**NOTICE**

External room thermostat requests. You can define the external room thermostat requests in different ways:

1. Via hardware:

- Install an external room thermostat.
- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Hardware**.
- In the selection box **Connection type**, select which external room thermostat type you used (**Single contact** or **Dual contact**).

2. Via Modbus:

- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Modbus**.
- Main zone: Use holding register 74: Thermostat request Main.
- Additional zone: Use holding register 75: Thermostat request Add.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikin-europe.com>.

- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Cloud**.
- Use the ONECTA cloud API to adjust the external room thermostat requests.

Input source

⚙️[180]	Must match your system layout. Input source of the external room thermostat for the main zone.
▪ 0: Hardware ▪ 1: Cloud ▪ 2: Modbus	

Connection type

⚙️[042]	Restriction: Only applicable if [1.13] Input source = Hardware . Must match your system layout. External room thermostat type for the main zone.
▪ 1: Single contact: The used external room thermostat can only send a thermo ON/OFF condition. There is no separation between heating or cooling demand. Select this value in case of a connection to the heat pump convector (FWX*). ▪ 0: Dual contact: The used external room thermostat can send a separate heating/cooling thermo ON/OFF condition. Select this value in case of connection to multi-zoning wired controls, wired room thermostats (EKRTWA) or wireless room thermostats (EKRTTB).	

**NOTICE**

If an external room thermostat is used, the external room thermostat will control the room frost protection.

[1.14] Delta T heating

A minimum temperature difference is required for proper operation of heat emitters in heating mode.

⚙️[169]	▪ If [1.11] = Under floor heating or Heat pump convector , the range is 3°C~10°C.
⚙️[170]	▪ If [1.11] = Radiator , the range is 10°C~20°C.

About delta T

In heating for the main zone, the target delta T (temperature difference) depends on the selected emitter type for the main zone.

Delta T is the absolute value of the temperature difference between the leaving water and entering water.

The unit is designed to support underfloor loops operation. The recommended leaving water temperature for underfloor loops is 35°C. In such case, the unit will realize a temperature difference of 5°C, which means that the entering water temperature is around 30°C.

Depending on the installed type of heat emitters (radiators, heat pump convector, underfloor loops) or situation, you can change the difference between entering and leaving water temperature.

Note: The pump will regulate its flow to keep the delta T. In some special cases, the measured delta T can differ from the set value.

**INFORMATION**

In heating, the target delta T will only be achieved after some operation time, when the setpoint is being reached, because of the big difference between leaving water temperature setpoint and inlet temperature at startup.

**INFORMATION**

If the main zone or the additional zone has a heating demand, and this zone is equipped with radiators, then the target delta T that the unit will use in heating operation will be within the 10°C~20°C range.

[1.15] NOT USED

[1.16] Cooling allowance

⚙️[050]	Allows/disallows cooling operation in the main zone.
▪ 0: No (disallowed): The cooling request for the main zone will be ignored. - If a shut-off valve is connected to the main zone, it will close. - If an external pump is connected to the main zone, it will be switched OFF during cooling operation preventing cold water from entering the main zone. ▪ 1: Yes (allowed): The cooling request for the main zone is NOT influenced. - If a shut-off valve is connected to the main zone, it will remain open. - If an external pump is connected to the main zone, it will remain operational during cooling operation.^(a)	

^(a) The external pump or the pump connected to the mixing kit of the main zone will stop if the request of that zone drops or if cooling is requested. For more details, see "[13] Field IO" [▶ 147] and the application guidelines chapter of the installer reference guide.

Shut-off valve or pump use cases

For more information about shut-off valve or pump use cases, see the application guidelines chapter of the installer reference guide.

To connect the shut-off valve or the pump

For more information about how to connect the shut-off valve or the pump, see "[13] Field IO" [▶ 147] and the electrical installation chapter of the installer reference guide.

For more details about the configuration per setup type, see the application guidelines chapter of the installer reference guide.

[1.17] Enable zone

⚙️[N/A]	Restriction: Only applicable if [1.12] = Leaving water . Turns ON/OFF the main zone and allows space heating operation.
▪ OFF (disabled) ▪ ON (enabled)	

[1.18] Delta T cooling

⚙️[174]	A minimum temperature difference is required for proper operation of heat emitters in cooling mode.
▪ 3°C~10°C	

About delta T

Delta T is the absolute value of the temperature difference between the leaving water and entering water.

The unit is designed to support underfloor loops operation. The recommended leaving water temperature for underfloor loops is around 18°C~20°C. In such case, the unit will realize a temperature difference of 5°C, which means that the entering water temperature is around 23°C~25°C.

Note: Make sure that the setpoint temperature remains above the dew point to prevent condensation and potential moisture damage to the floor.

Depending on the installed type of heat emitters (radiators, heat pump convactor, underfloor loops) or situation, you can change the difference between entering and leaving water temperature.

Note: The pump will regulate its flow to keep the delta T. In some special cases, the measured delta T can differ from the set value.



INFORMATION

In cooling, the target delta T will only be achieved after some operation time, when the setpoint is being reached, because of the big difference between leaving water temperature setpoint and inlet temperature at startup.

[1.19] Overheating water circuit

⚙️[048]	Restriction: Only applicable if [3.13.5] = Yes. Defines the maximum leaving water temperature in the main zone with respect to the installed emitter.
▪ 20°C~80°C	

**INFORMATION**

The maximum leaving water temperature is decided based on setting [3.12] **Overheating setpoint**. This limit defines the maximum leaving water **in the system**. Depending on the value of this setting, the maximum LWT setpoint will also be reduced by 5°C to allow stable control towards the setpoint.

The maximum leaving water temperature **in the main zone** is decided based on setting [1.19] **Overheating water circuit**, only in case [3.13.5] **Bizone kit installed** is enabled. This limit defines the maximum leaving water **in the main zone**. Depending on the value of this setting, the maximum LWT setpoint will also be reduced by 5°C to allow stable control towards the setpoint.

[1.20] Undercooling water circuit

[049]

Restriction: Only applicable if [3.13.5] = Yes.

Defines the minimum leaving water temperature in the main zone with respect to the installed emitter.

- 3°C~35°C

**INFORMATION**

The minimum leaving water temperature is decided based on setting [3.11] **Undercooling setpoint**. This limit defines the minimum leaving water **in the system**. Depending on the value of this setting, the minimum LWT setpoint will also be increased by 4°C to allow stable control towards the setpoint.

The minimum leaving water temperature **in the main zone** is decided based on setting [1.20] **Undercooling water circuit**, only in case [3.13.5] **Bizone kit installed** is enabled. This limit defines the minimum leaving water **in the main zone**. Depending on the value of this setting, the minimum LWT setpoint will also be increased by 4°C to allow stable control towards the setpoint.

[1.21] Zone name

[N/A]

Use this setting to change the name of the main zone.

- The zone name is limited to 16 characters.

[1.22] Antifrost

Antifrost prevents the room from getting too cold.

In all cases, for the main and additional zone, **Antifrost** will heat the space heating water to a reduced setpoint when the outdoor temperature is lower than 6°C. This will be decided by the lowest ambient temperature measured by the external outdoor ambient temperature sensor or if connected, an optional ambient temperature sensor.

For the main zone: when [3.4] is enabled, antifrost prevents the room from getting below the [1.22] **Antifrost** setpoint. This setting is applicable when [1.12] **Control** = **Room**, but also offers functionality for leaving water temperature control and external room thermostat control.

Note: In case of thermostat cable breakdown, room frost protection cannot be guaranteed.

Note: In all cases the antifrost can be activated via breadcrumb [3.4] (also for **Leaving water** or **External room thermostat** control).

[1.12] Main zone > Control	Description
Leaving water	Room frost protection is guaranteed via reduced leaving water temperature setpoint, in case the water zone is switched OFF.
External room thermostat	Room frost protection is guaranteed via reduced leaving water temperature setpoint when there is a thermostat request, in case the water zone is switched OFF.
Room (main zone only)	Allow for the dedicated Human Comfort Interface (BRC1HHDA used as room thermostat) to take care of room frost protection: Set the temperature of the antifrost function in [1.22] Antifrost .

[1.23] Cooling schedule enable

⚙️[N/A]	Activation screen for [1.4] Cooling schedule .
▪ If [1.12] = Leaving water, only the leaving water temperature schedule can be enabled/disabled: ▪ OFF (disabled) ▪ ON (enabled) The influence of the LWT setpoint mode [1.7] is as follows: ▪ In Fixed LWT setpoint mode, the LWT schedules need to be selected. For more details, see " [1.4] Cooling schedule " [▶ 64]. ▪ Note: When Fixed setpoint mode is selected, the shift schedules are available, but will NOT have any effect. ▪ In Weather dependent LWT setpoint mode, the shift schedules need to be selected. For more details, see " [1.25] Leaving water shift cooling schedule " [▶ 75]. ▪ Note: When Weather dependent setpoint mode is selected, the fixed schedules are available but will NOT have any effect.	
▪ If [1.12] = External room thermostat: - No schedule is enabled.	
▪ If [1.12] = Room, only the room temperature schedule can be enabled/disabled: - OFF: Room temperature is directly controlled by the user. - ON: Room temperature is controlled by a schedule and can be modified by the user.	


[1.24] Leaving water shift heating schedule

⚙️[N/A]	Restriction: Only applicable if: ▪ [1.12] = Leaving water, and ▪ [1.5] = Weather dependent. Schedule of the leaving water temperature target shift on the weather-dependent curve during space heating operation in the main zone.
---------	--

- **Predefined schedules:** 3
 - **Activation:** [1.36] Scheduled WD LWT shift for heating
 - **Possible actions:** Leaving water shift temperatures on the weather-dependent curve.
- Note:** Only in case weather-dependent curve is used (see "[4 Weather-dependent curve](#)" [▶ 24]).
- You can schedule 10 actions per day.

This setting enables to apply a temperature shift for a certain time during space heating operation in the main zone. Its value will increase or decrease the value of the weather-dependent curve according to a value selected in a schedule.

Example:




Remark: In case of LWT shift scheduling, there will be **NO operation** at times when no temperature shift is scheduled.

[1.25] Leaving water shift cooling schedule

⚙️[N/A]	Restriction: Only applicable if: ▪ [1.12] = Leaving water, and ▪ [1.7] = Weather dependent. Schedule of the leaving water temperature target shift on the weather-dependent curve during space cooling operation in the main zone.
▪ Predefined schedules: 1 ▪ Activation: [1.37] Scheduled WD LWT shift for cooling ▪ Possible actions: Leaving water shift temperatures on the weather-dependent curve. Note: Only in case weather-dependent curve is used (see "4 Weather-dependent curve" [▶ 24]). ▪ You can schedule 10 actions per day.	

This setting enables to apply a temperature shift for a certain time during space cooling operation in the main zone. Its value will increase or decrease the value of the weather-dependent curve according to a value selected in a schedule.

Example:



+5 Temperature shift value

Remark: In case of LWT shift scheduling, there will be **NO operation** at times when no temperature shift is scheduled.

[1.26] Increase around 0°C

⚙️[052]	For main zone. Use this setting to compensate for possible heat losses of the building due to the evaporation of melted ice or snow. (e.g. in cold region countries). In heating operation, the desired leaving water temperature is locally increased around an outdoor temperature of 0°C. This compensation can be selected when using an absolute or a weather-dependent desired temperature (see illustration below). a: Absolute desired leaving water temperature b: Weather-dependent desired leaving water temperature L: Increase; R: Span; X: Outdoor temperature; Y: Leaving water temperature
0: No 1: increase 2°C, span 4°C 2: increase 2°C, span 8°C 3: increase 4°C, span 4°C 4: increase 4°C, span 8°C	

[1.27] Leaving water shift heating

⚙️[N/A]	Restriction: Only applicable if [1.5] = Weather dependent. The shift of the selected setpoint to the weather-dependent curve for the leaving water temperature of the main zone in heating operation.
-10°C~10°C	Remark: This setting can overrule [1.24] Leaving water shift heating schedule until the next scheduled shift trigger occurs.

[1.28] Leaving water shift cooling

⚙️[N/A]	Restriction: Only applicable if [1.7] = Weather dependent. The shift of the selected setpoint to the weather-dependent curve for the leaving water temperature of the main zone in cooling operation.
-10°C~10°C	Remark: This setting can overrule [1.25] Leaving water shift cooling schedule until the next scheduled shift trigger occurs.

[1.29] Heating comfort setpoint

Restriction: Only applicable if:

- [1.12] = Room, and

- Smart Grid is enabled [9.14.1] = **Smart grid ready contacts**.

If room buffering is enabled, the extra energy from photovoltaic panels is buffered in the DHW tank and in the space heating/cooling circuit (i.e. heat up or cool down the room). With the room comfort setpoints (cooling/heating) you can modify the maximum/minimum setpoints that will be used when buffering the extra energy in the space heating/cooling circuit.

⚙️[N/A]	Defines the target room temperature that will be used when buffering the extra energy in the space heating/cooling circuit during heating operation.
12°C~30°C	



INFORMATION

During the **Forced on** mode, the room buffering will happen independently from the **Allow buffering space H/C** [9.14.4] setting. During the **Recommended on** mode, the room buffering will only happen when the room buffering is enabled ([9.14.4] = On).

[1.30] Cooling comfort setpoint

Restriction: Only applicable if:

- [1.12] = **Room**, and
- Smart Grid is enabled [9.14.1] = **Smart grid ready contacts**.

If room buffering is enabled, the extra energy from photovoltaic panels is buffered in the DHW tank and in the space heating/cooling circuit (i.e. heat up or cool down the room). With the room comfort setpoints (cooling/heating) you can modify the maximum/minimum setpoints that will be used when buffering the extra energy in the space heating/cooling circuit.

⚙️[N/A]	Defines the target room temperature that will be used when buffering the extra energy in the space heating/cooling circuit during cooling operation.
15°C~35°C	



INFORMATION

During the **Forced on** mode, the room buffering will happen independently from the **Allow buffering space H/C** [9.14.4] setting. During the **Recommended on** mode, the room buffering will only happen when the room buffering is enabled ([9.14.4] = On).

[1.31] Daikin room thermostat

⚙️[158]	Indicates whether the room thermostat is installed or not.
0: No 1: Yes	

This setting is automatically enabled when the room thermostat is connected. It should be disabled when the room thermostat is removed from the setup.

[1.32] Room enable

⚙️[N/A]	Enables/disables the room temperature control in the main zone.
---------	---

- OFF (disabled)
- ON (enabled)

[1.33] External room sensor offset

⚙️[N/A]	Restriction: Only applicable if [1.12] = Room. Optional offset that can be applied to the room temperature target, measured by the optional sensor in the main zone. Same as setting [5.22] External ambient sensor offset > Room.
▪ -5~5°C	It is linked to the external room sensor selected via [13] Field IO . For more information, see "[13] Field IO " [▶ 147] and the installer reference guide.

[1.34] Heating target baseline

⚙️[N/A]	Restriction: Only applicable if [1.12] = Room. Setpoint for the room target baseline temperature for the room schedule during space heating operation in the main zone.
▪ If [1.2] = ON, the room target temperature will follow a block-based schedule set in [1.3] (see "[1.3] Heating schedule " [▶ 63]). When no temperature is scheduled, the room target temperature will follow the baseline temperature.	
▪ If [1.2] = OFF, the room target temperature will follow the room setpoint set in [1.1].	

[1.35] Cooling target baseline

⚙️[N/A]	Restriction: Only applicable if [1.12] = Room. Setpoint for the room target baseline temperature for the room schedule during space cooling operation in the main zone.
▪ If [1.2] = ON, the room target temperature will follow a block-based schedule set in [1.4] (see "[1.4] Cooling schedule " [▶ 64]). When no temperature is scheduled, the room target temperature will follow the baseline temperature.	
▪ If [1.2] = OFF, the room target temperature will follow the room setpoint set in [1.1].	

[1.36] Scheduled WD LWT shift for heating

⚙️[N/A]	Restriction: Only applicable if: ▪ [1.12] = Leaving water, and ▪ [1.5] = Weather dependent. Activation screen for [1.24] Leaving water shift heating schedule (see "[1.24] Leaving water shift heating schedule " [▶ 74]). Enables/disables a temperature shift on the weather-dependent leaving water target during space heating operation in the main zone.
---------	--

- ON (enabled)
- OFF (disabled)

Note: When the weather-dependent setpoint mode is active, the fixed schedules remain selectable, but will NOT have any effect. The leaving water temperature is then NOT controlled by the setting [1.39] **Leaving water temp. heating**.

[1.37] Scheduled WD LWT shift for cooling

⚙️[N/A]	Restriction: Only applicable if: ▪ [1.12] = Leaving water, and ▪ [1.7] = Weather dependent. Activation screen for [1.25] Leaving water shift cooling schedule (see "[1.25] Leaving water shift cooling schedule" [▶ 75]). Enables/disables a temperature shift on the weather-dependent leaving water target during space cooling operation in the main zone.
	▪ ON (enabled) ▪ OFF (disabled) Note: When the weather-dependent setpoint mode is active, the fixed schedules remain selectable, but will NOT have any effect. The leaving water temperature is then NOT controlled by the setting [1.42] Leaving water temp. cooling.

[1.38] Thermostat sensor offset

⚙️[N/A]	Restriction: Only applicable if [1.12] = Room. Offset on the room temperature on the Human Comfort Interface in the main zone.
	▪ -5°C~5°C

For more information, see also "[1.31] **Daikin room thermostat**" [▶ 77].

[1.39] Leaving water temp. heating

⚙️[N/A]	Setpoint for the desired leaving water temperature during space heating of the main zone. Note: In case of weather-dependent mode, LWT is not controlled by this setting.
	[054]°C~[053]°C

[1.40] NOT USED

[1.41] NOT USED

[1.42] Leaving water temp. cooling

⚙️[N/A]	Setpoint for the desired leaving water temperature during space cooling of the main zone. Note: In case of weather-dependent mode, LWT is not controlled by this setting.
	[056]°C~[055]°C

[2] Additional zone

Additional zone (direct zone) = Zone with the highest design temperature in heating, and the lowest design temperature in cooling.

Restriction: You can configure the settings for the additional zone ONLY after enabling the additional zone with setting [3.6] = Yes.

In this chapter

[2.1] NOT USED	80
[2.2] Heating schedule enable.....	80
[2.3] Heating schedule	81
[2.4] Cooling schedule	81
[2.5] Heating setpoint mode	81
[2.6] Setpoint range.....	82
[2.7] Cooling setpoint mode	83
[2.8] Heating WD curve	83
[2.9] Cooling WD curve	84
[2.10] NOT USED	84
[2.11] Emitter type	84
[2.12] Control.....	85
[2.13] External room thermostat	85
[2.14] Delta T heating.....	86
[2.15] Enable zone.....	86
[2.16] NOT USED	86
[2.17] Delta T cooling.....	86
[2.18] Leaving water shift heating schedule	87
[2.19] Leaving water shift cooling schedule	87
[2.20] Increase around 0°C.....	88
[2.21] Zone name	88
[2.22] Leaving water shift heating.....	88
[2.23] Leaving water shift cooling.....	89
[2.24] NOT USED	89
[2.25] NOT USED	89
[2.26] NOT USED	89
[2.27] Cooling schedule enable.....	89
[2.28] NOT USED	89
[2.29] NOT USED	89
[2.30] Leaving water temp. heating.....	89
[2.31] Scheduled WD LWT shift for heating.....	90
[2.32] Scheduled WD LWT shift for cooling.....	90
[2.33] Cooling allowance	90
[2.34] NOT USED	91
[2.35] NOT USED	91
[2.36] Leaving water temp. cooling.....	91

[2.1] NOT USED

[2.2] Heating schedule enable

⚙️[N/A]	Restriction: Only applicable if [1.12] = Leaving water. Activation screen for [2.3] Heating schedule.
---------	---

The influence of the LWT setpoint mode [2.5] is as follows:

- In **Fixed** LWT setpoint mode, the LWT schedules need to be selected. For more details, see "[\[2.3\] Heating schedule](#)" [▶ 81].

Note: When **Fixed** setpoint mode is selected, the shift schedules are available, but will NOT have any effect.

- In **Weather dependent** LWT setpoint mode, the shift schedules need to be selected. For more details, see "[\[2.18\] Leaving water shift heating schedule](#)" [▶ 87].

Note: When **Weather dependent** setpoint mode is selected, the fixed schedules are available but will NOT have any effect.

[2.3] Heating schedule

⚙️[N/A]	Restriction: Only applicable if [1.12] = Leaving water . Schedule for the additional zone in heating mode to set the desired leaving water temperature.
Predefined schedules: 3 Activation screen: [2.2] Heating schedule enable Possible actions: Leaving water temperatures within range. Note: In case of LWT scheduling, operation will be OFF when no temperature is scheduled.	

[2.4] Cooling schedule

⚙️[N/A]	Restriction: Only applicable if [1.12] = Leaving water . Schedule for the additional zone in cooling mode to set the desired leaving water temperature.
Predefined schedules: 1 Activation screen: [2.27] Cooling schedule enable Possible actions: Leaving water temperatures within range. Note: In case of LWT scheduling, operation will be OFF when no temperature is scheduled.	

[2.5] Heating setpoint mode

⚙️[N/A]	Defines the setpoint mode for the additional zone in space heating operation, which can be set independently from the setpoint mode for the main zone.
▪ 0: Fixed: The desired leaving water temperature does NOT depend on the outdoor ambient temperature. ▪ 1: Weather dependent: The desired leaving water temperature depends on the outdoor ambient temperature.	

When weather-dependent operation is active, low outdoor temperatures will result in warmer water and vice versa. During weather-dependent operation, the user can shift the water temperature up or down by a maximum of 10°C. For more details, see "[\[2.22\] Leaving water shift heating](#)" [▶ 88].

[2.6] Setpoint range

To prevent wrong (i.e. too hot or too cold) temperatures, you can limit the range of desired leaving water temperatures that users can set for the additional zone.	
⚙️[060]	Heating maximum ^(a) : ▪ If [2.11] = Radiator: [061]°C~75°C ▪ Else: [061]°C~55°C
⚙️[061]	Heating minimum: ▪ 20°C~[060]°C
⚙️[062]	Cooling maximum: ▪ [063]°C~22°C
⚙️[063]	Cooling minimum ^(b) : ▪ 7°C~[062]°C

^(a) For more details, see "[3.12] Overheating setpoint" [▶ 97] and the field settings table of the installer reference guide.


^(b) For more details, see "[3.11] Undercooling setpoint" [▶ 96] and the field settings table of the installer reference guide.

The maximum setpoint range depends on the emitter type when a mixing kit or a bizon unit is connected. For more details, see "[2.11] Emitter type" [▶ 84].

The minimum leaving water target for the heat pump and the backup heater is determined by the minimum water temperature required to initiate defrost. Even if a lower setpoint is selected, the minimum active setpoint will always be the defrost start temperature and the maximum target delta T.

The maximum delta T is defined by the delta T of the main zone and the additional zone (see "[1.14] Delta T heating" [▶ 71] and "[2.14] Delta T heating" [▶ 86]).

The values in the below graph are examples. For the details about the minimum required water temperature to start defrost, go to <https://daikintechdatahub.eu/> to see the actual operation range drawing.



NOTICE

In case of a floor heating application it is important to limit the:

- maximum leaving water temperature at heating operation according to the specifications of the floor heating installation.
- the minimum leaving water temperature at cooling operation to 18~20°C to prevent condensation on the floor.

**NOTICE**

- When adjusting the leaving water temperature ranges, all desired leaving water temperatures are also adjusted to guarantee they are between the limits.
- Always balance between the desired leaving water temperature with the desired room temperature and/or the capacity (according to the design and selection of the heat emitters). The desired leaving water temperature is the result of several settings (preset values, shift values, weather-dependent curves, modulation). As a result, too high or too low leaving water temperatures could occur which lead to overtemperatures or capacity shortage. By limiting the leaving water temperature range to adequate values (depending on the heat emitter), such situations can be avoided.

[2.7] Cooling setpoint mode


⚙️[N/A]	Defines the setpoint mode for the additional zone in space cooling operation, which can be set independently from the setpoint mode for the main zone.
▪ 0: Fixed: The desired leaving water temperature does NOT depend on the outdoor ambient temperature. ▪ 1: Weather dependent: The desired leaving water temperature depends on the outdoor ambient temperature.	

When weather-dependent operation is active, low outdoor temperatures will result in warmer water and vice versa. During weather-dependent operation, the user can shift the water temperature up or down by a maximum of 10°C. For more details, see "[2.23] Leaving water shift cooling" [▶ 89].

[2.8] Heating WD curve

⚙️[N/A]	Defines the weather-dependent curve used to determine the leaving water temperature of the additional zone in space heating operation. Restriction: The curve is only used when [2.5] = Weather dependent .
See "[4 Weather-dependent curve]" [▶ 24].	

The weather-dependent heating can be configured according to the figure below.



T_t Target leaving water temperature (additional zone)

T_a Outdoor temperature

a Low outdoor ambient temperature. -40°C~+5°C

b High outdoor ambient temperature. 5°C~25°C

c Desired leaving water temperature when the outdoor temperature equals or drops below the low ambient temperature. [061]°C~[060]°C

Note: This value should be higher than (d) as for low outdoor temperatures warmer water is required.


d Desired leaving water temperature when the outdoor temperature equals or rises above the high ambient temperature. [061]°C~[060]°C

Note: This value should be lower than (c) as for high outdoor temperatures less warm water is required.

[2.9] Cooling WD curve

⚙️[N/A]	Defines the weather-dependent curve used to determine the leaving water temperature of the additional zone in space cooling operation. Restriction: The curve is only used when [2.7] = Weather dependent .
See " 4 Weather-dependent curve " [▶ 24].	

The weather-dependent cooling can be configured according to the figure below.



T_t Target leaving water temperature (additional zone)

T_a Outdoor temperature

a Low outdoor ambient temperature. 10°C~25°C

b High outdoor ambient temperature. 25°C~43°C

c Desired leaving water temperature when the outdoor temperature equals or drops below the low ambient temperature. [063]°C~[062]°C

Note: This value should be higher than (d) as for low outdoor temperatures less cold water is required.

d Desired leaving water temperature when the outdoor temperature equals or rises above the high ambient temperature. [063]°C~[062]°C

[2.10] NOT USED

[2.11] Emitter type

⚙️[N/A]	Must match your system layout. Emitter type of the additional zone.
▪ 0: Under floor heating ▪ 1: Heat pump convector ▪ 2: Radiator	

The setting **Emitter type** influences the space heating setpoint range and the target delta T in heating as follows:

Emitter type Main zone	Space heating setpoint range [060]~[061] ^(a)	Target delta T in heating
0: Under floor heating	Maximum 55°C	3°C~10°C (see " [2.14] Delta T heating " [▶ 86])
1: Heat pump convector	Maximum 55°C	3°C~10°C (see " [2.14] Delta T heating " [▶ 86])
2: Radiator	Maximum 75°C	10°C~20°C (see " [2.14] Delta T heating " [▶ 86])

^(a) This column only explains the maximum setpoint range. For more details about the setpoint range, see "[\[2.6\] Setpoint range](#)" [▶ 82].

Remark: When changing the emitter type from **Under floor heating** or **Heat pump convector** to **Radiator**, the maximum setpoint range will NOT automatically adapt to 75°C. If required, it needs to be manually increased again.

[2.12] Control

⚙️[057]	Shows (read-only) the unit control method for the additional zone.
This setting is determined by the unit control method for the main zone (see "[1.12] Control" [▶ 69]): ▪ 0: Leaving water if the unit control method for the main zone selected in [1.12] is Leaving water. ▪ 1: External room thermostat if the unit control method for the main zone selected in [1.12] is: - External room thermostat, or - Room In case of external room thermostat control, you must also set the external room thermostat type with setting [2.13] (see "[2.13] External room thermostat" [▶ 85]).	

[2.13] External room thermostat

Note: To be used in combination with [2.12] = **External room thermostat**.



NOTICE

External room thermostat requests. You can define the external room thermostat requests in different ways:

1. Via hardware:

- Install an external room thermostat.
- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Hardware**.
- In the selection box **Connection type**, select which external room thermostat type you used (**Single contact** or **Dual contact**).

2. Via Modbus:

- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Modbus**.
- Main zone: Use holding register 74: Thermostat request Main.
- Additional zone: Use holding register 75: Thermostat request Add.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikineurope.com>.

- Go to **External room thermostat** ([1.13] for main zone or [2.13] for additional zone).
- Set **Input source** = **Cloud**.
- Use the ONECTA cloud API to adjust the external room thermostat requests.

Input source

⚙️[181]	Must match your system layout. Input source of the external room thermostat for the additional zone.
▪ 0: Hardware ▪ 1: Cloud ▪ 2: Modbus	

Connection type

⚙️[146]	Restriction: Only applicable if [2.13] Input source = Hardware . Must match your system layout. External room thermostat type for the additional zone.
▪ 1: Single contact: The used external room thermostat can only send a thermo ON/OFF condition. There is no separation between heating or cooling demand. Select this value in case of a connection to the heat pump convector (FWX*). ▪ 0: Dual contact: The used external room thermostat can send a separate heating/cooling thermo ON/OFF condition. Select this value in case of connection to multi-zoning wired controls, wired room thermostats (EKRTWA) or wireless room thermostats (EKRTTB).	

[2.14] Delta T heating

Delta T target for the additional zone during space heating operation. A minimum temperature difference is required for proper operation of heat emitters in heating mode.	
⚙️[171]	▪ If [2.11] = Under floor heating or Heat pump convector, the range is 3°C~10°C.
⚙️[172]	▪ If [2.11] = Radiator, the range is 10°C~20°C.

For more information about **Delta T heating**, see " [\[1.14\] Delta T heating](#)" [▶ 71].

[2.15] Enable zone

⚙️[N/A]	Restriction: Only applicable if [1.12] = Leaving water . Turns ON/OFF the additional zone and allows space heating operation.
▪ OFF (disabled) ▪ ON (enabled)	

[2.16] NOT USED**[2.17] Delta T cooling**


⚙️[148]	Delta T target for the additional zone during space cooling operation. A minimum temperature difference is required for proper operation of heat emitters in cooling mode.
▪ 3°C~10°C	

For more information about **Delta T cooling**, see " [\[1.18\] Delta T cooling](#)" [▶ 72].

[2.18] Leaving water shift heating schedule

⚙️[N/A]	Restriction: Only applicable if: ▪ [1.12] = Leaving water, and ▪ [2.5] = Weather dependent. Schedule of the leaving water temperature target shift on the weather-dependent curve during space heating operation in the additional zone.
	▪ Predefined schedules: 3 ▪ Activation: [2.31] Scheduled WD LWT shift for heating ▪ Possible actions: Leaving water shift temperatures on the weather-dependent curve. Note: Only in case weather-dependent curve is used (see "4 Weather-dependent curve" [▶ 24]). ▪ You can schedule 10 actions per day.

This setting enables to apply a temperature shift for a certain time during space heating operation in the additional zone. Its value will increase or decrease the value of the weather-dependent curve according to a value selected in a schedule.

Example:


Remark: In case of LWT shift scheduling, there will be **NO operation** at times when no temperature shift is scheduled.

[2.19] Leaving water shift cooling schedule

⚙️[N/A]	Restriction: Only applicable if: ▪ [1.12] = Leaving water, and ▪ [2.7] = Weather dependent. Schedule of the leaving water temperature target shift on the weather-dependent curve during space cooling operation in the additional zone.
	▪ Predefined schedules: 1 ▪ Activation: [2.32] Scheduled WD LWT shift for cooling ▪ Possible actions: Leaving water shift temperatures on the weather-dependent curve. Note: Only in case weather-dependent curve is used (see "4 Weather-dependent curve" [▶ 24]). ▪ You can schedule 10 actions per day.

This setting enables to apply a temperature shift for a certain time during space cooling operation in the additional zone. Its value will increase or decrease the value of the weather-dependent curve according to a value selected in a schedule.

Example:



Remark: In case of LWT shift scheduling, there will be **NO operation** at times when no temperature shift is scheduled.

[2.20] Increase around 0°C

⚙️[059]

For additional zone.

Use this setting to compensate for possible heat losses of the building due to the evaporation of melted ice or snow. (e.g. in cold region countries). In heating operation, the desired leaving water temperature is locally increased around an outdoor temperature of 0°C. This compensation can be selected when using an absolute or a weather-dependent desired temperature (see illustration below).

a

b

a: Absolute desired leaving water temperature
b: Weather-dependent desired leaving water temperature
L: Increase; R: Span; X: Outdoor temperature; Y: Leaving water temperature

- 0: No
- 1: increase 2°C, span 4°C
- 2: increase 2°C, span 8°C
- 3: increase 4°C, span 4°C
- 4: increase 4°C, span 8°C

[2.21] Zone name

⚙️[N/A]

Use this setting to change the name of the additional zone.

- The zone name is limited to 16 characters.

[2.22] Leaving water shift heating

⚙️[N/A]

Restriction: Only applicable if [2.5] = **Weather dependent**.

The shift of the selected setpoint to the weather-dependent curve for the leaving water temperature of the additional zone in heating operation.

- -10°C~10°C

Remark: This setting can overrule [2.18] **Leaving water shift heating schedule** until the next scheduled shift trigger occurs.

[2.23] Leaving water shift cooling

⚙️[N/A]	Restriction: Only applicable if [2.7] = Weather dependent . The shift of the selected setpoint to the weather-dependent curve for the leaving water temperature of the additional zone in cooling operation.
■ -10°C~10°C Remark: This setting can overrule [2.19] Leaving water shift cooling schedule until the next scheduled shift trigger occurs.	

[2.24] NOT USED

[2.25] NOT USED

[2.26] NOT USED

[2.27] Cooling schedule enable

⚙️[N/A]	Restriction: Only applicable if [1.12] = Leaving water . Activation screen for [2.4] Cooling schedule .
The influence of the LWT setpoint mode [2.7] is as follows: ■ In Fixed LWT setpoint mode, the LWT schedules need to be selected. For more details, see " [2.4] Cooling schedule " ▶ 81]. Note: When Fixed setpoint mode is selected, the shift schedules are available, but will NOT have any effect. ■ In Weather dependent LWT setpoint mode, the shift schedules need to be selected. For more details, see " [2.19] Leaving water shift cooling schedule " ▶ 87]. Note: When Weather dependent setpoint mode is selected, the fixed schedules are available but will NOT have any effect.	

[2.28] NOT USED

[2.29] NOT USED

[2.30] Leaving water temp. heating

⚙️[N/A]	Setpoint for the desired leaving water temperature during space heating of the additional zone. Note: In case of weather-dependent mode, LWT is not controlled by this setting.
[061]°C~[060]°C	

[2.31] Scheduled WD LWT shift for heating

⚙️[N/A]	Restriction: Only applicable if: ▪ [1.12] = Leaving water, and ▪ [2.5] = Weather dependent. Activation screen for [2.18] Leaving water shift heating schedule (see "[2.18] Leaving water shift heating schedule" [▶ 87]). Enables/disables a temperature shift on the weather-dependent leaving water target during space heating operation in the additional zone.
▪ ON (enabled) ▪ OFF (disabled) Note: When the weather-dependent setpoint mode is active, the fixed schedules remain selectable, but will NOT have any effect. The leaving water temperature is then NOT controlled by the setting [2.30] Leaving water temp. heating.	

[2.32] Scheduled WD LWT shift for cooling

⚙️[N/A]	Restriction: Only applicable if: ▪ [1.12] = Leaving water, and ▪ [2.7] = Weather dependent. Activation screen for [2.19] Leaving water shift cooling schedule (see "[2.19] Leaving water shift cooling schedule" [▶ 87]). Enables/disables a temperature shift on the weather-dependent leaving water target during space cooling operation in the additional zone.
▪ ON (enabled) ▪ OFF (disabled) Note: When the weather-dependent setpoint mode is active, the fixed schedules remain selectable, but will NOT have any effect. The leaving water temperature is then NOT controlled by the setting [2.36] Leaving water temp. cooling.	

[2.33] Cooling allowance

⚙️[147]	Allows/disallows cooling operation in the additional zone.
▪ 0: No (disallowed): The cooling request for the additional zone will be ignored. - If a shut-off valve is connected to the additional zone, it will close. - If an external pump is connected to the additional zone, it will be switched OFF during cooling operation preventing cold water from entering the additional zone. ▪ 1: Yes (allowed): The cooling request for the additional zone is NOT influenced. - If a shut-off valve is connected to the additional zone, it will remain open. - If an external pump is connected to the additional zone, it will remain operational during cooling operation.	

For more details, see "[1.16] **Cooling allowance**" [▶ 71].

[2.34] NOT USED

[2.35] NOT USED

[2.36] Leaving water temp. cooling

⚙️[N/A]	Setpoint for the desired leaving water temperature during space cooling of the additional zone. Note: In case of weather-dependent mode, LWT is not controlled by this setting.
[063]°C~[062]°C	

[3] Space heating/cooling

In this chapter

[3.1] Operation range.....	92
[3.2] Operation mode.....	92
[3.3] NOT USED	94
[3.4] Antifrost.....	94
[3.5] Operation mode schedule.....	94
[3.6] Additional zone.....	94
[3.7] Max. heating overshoot LWT	95
[3.8] Averaging time.....	96
[3.9] Max. cooling undershoot LWT.....	96
[3.10] NOT USED	96
[3.11] Undercooling setpoint.....	96
[3.12] Overheating setpoint	97
[3.13] Bizone kit.....	97
[3.14] Room thermostat present.....	99
[3.15] Heatpump minimum on time.....	99

[3.1] Operation range

⚙️[N/A]	Defines the average outdoor temperature above/below which the operation of the unit in space heating/cooling is prohibited. These settings are also used in automatic heating/cooling changeover.
▪ Space heating: When the averaged outdoor temperature rises above this value, space heating is turned OFF. 14~35°C ▪ Space cooling: When the averaged outdoor temperature drops below this value, space cooling is turned OFF. 10~35°C ▪ Confirm with the ✓ button.	

[3.2] Operation mode

⚙️[N/A]	Sets the space operation mode.
▪ Heating ▪ Cooling ▪ Automatic See below for how to use these settings.	

About space operation modes

Your unit is a heating/cooling model, it can both heat up and cool down a space. You have to tell the system which operation mode to use. There are two possibilities to do so:

If	Then
Possibility 1: In case: ▪ There is only one zone (main zone) ▪ And the main zone is controlled by an external room thermostat ▪ And individual heating/cooling requests are sent to the unit in one of the following ways: - Via hardware (external room thermostats with dual contacts). - Via external communication input, like Modbus or Cloud.	Operation mode is decided by the external room thermostat
Possibility 2: In other cases than possibility 1	Operation mode is decided by settings [3.2], [3.5] (and [3.1])

To check which space operation mode is currently used

The space operation mode is displayed on the home screen:

- When the unit is in heating mode, the ☀ icon is shown.
- When the unit is in cooling mode, the ❄ icon is shown.

The status indicator shows if the unit is currently in operation:

- When the unit is not in operation, the status indicator will show a blue pulsation with an interval of approximately 5 seconds.
- While the unit is in operation, the status indicator will light up blue constantly.

To set the space operation mode

Using settings [3.2], [3.5] (and [3.1]):

1	Go to [3.2]: Space heating/cooling > Operation mode. Note: Tap on the Spaces bar from the home screen for a quick access screen where the Operation mode can be selected.
2	Select one of the following options: ▪ Heating: Result: The operation mode is permanently heating. This procedure is finished. ▪ Cooling: Result: The operation mode is permanently cooling. This procedure is finished. ▪ Automatic: Result: The operation mode depends on a monthly schedule. Go to the next step.
3	Go to [3.5]: Space heating/cooling > Operation mode schedule.
4	Select a month.
5	For each month, select one of the following options: ▪ Heating ▪ Cooling ▪ Automatic

5a	Heating: Use this during cold season (e.g. October, November, December January, February and March). Result: For the selected month, only heating is possible.
5b	Cooling: Use this during warm season (e.g. June, July and August). Result: For the selected month, only cooling is possible.
5c	Automatic: Use this between cold and warm season (e.g. April, May and September). Result: For the selected month, the unit automatically switches between heating and cooling. The changeover depends on: ▪ The outdoor temperature ▪ The setpoints defined in [3.1] Operation Range. The difference between the two setpoints is used like a hysteresis in order to avoid frequent changeover. Note: If changeover occurs too frequent due to direct sunlight on the outdoor unit, the remote outdoor sensor (EKRSCA1) can be installed to improve the system behaviour.
6	Confirm the changes.

[3.3] NOT USED

[3.4] Antifrost

⚙️[N/A]	Enables/disables the room antifrost functionality.
▪ OFF (disabled) ▪ ON (enabled)	

For more details, see " [1.22] Antifrost" [▶ 73].

[3.5] Operation mode schedule

See " [3.2] Operation mode" [▶ 92].

[3.6] Additional zone

⚙️[155]	Must match your system layout. Indicates whether an additional zone is present.
▪ 0: OFF (not present). There is only one leaving water temperature zone. ▪ 1: ON (present). There are two leaving water temperature zones. In heating, the main leaving water temperature zone consists of the lowest temperature heat emitters and a mixing station to achieve the desired leaving water temperature.	

**INFORMATION**

Mixing station. If your system layout contains 2 LWT zones, you can install a mixing station in front of the main LWT zone. However, other dual zone applications with shut-off valves are also possible. For more information, see the application guidelines in the installer reference guide.

**NOTICE**

NOT configuring the system in the following way can cause damage to the heat emitters. If there are 2 zones, it is important that in heating:

- the zone with the lowest water temperature is configured as the main zone, and
- the zone with the highest water temperature is configured as the additional zone.

**NOTICE**

If there are 2 zones and the emitter types are wrongly configured, water of high temperature can be sent towards a low temperature emitter (underfloor heating). To avoid this:

- Install an aquastat/thermostatic valve to avoid too high temperatures towards a low temperature emitter.
- Make sure you set the emitter types for the main zone and for the additional zone correctly in accordance with the connected emitter.

[3.7] Max. heating overshoot LWT

⚙️[017] / [018]	Restriction: This function is only applicable in heating mode. This function defines how much the water temperature may rise above the desired leaving water temperature before the compressor stops. A higher value will result in less start/stop cycles of the heat pump, but could also lead to lesser comfort. The opposite is valid if a lower value is chosen. The compressor will start up again when the leaving water temperature drops below the desired leaving water temperature. Note: The selection in [3.7] will depend on the selected emitter type (see below).
⚙️[017]	Used to calculate the maximum overshoot on the leaving water temperature during space heating for underfloor heating. ▪ 1~7°C
⚙️[018]	Used to calculate the maximum overshoot on the leaving water temperature during space heating for radiators or heat pump convectors. ▪ 1~10°C

[3.8] Averaging time

⚙️[007]	The outdoor temperature is averaged over the selected time period. The average timer corrects the influence of ambient temperature variations. The averaged outdoor temperature will be used by the following functionalities: ▪ weather-dependent curve, ▪ Operation range based on ambient temperature, ▪ during changeover, if Scheduled and Automatic operation modes are active, ▪ Increase around 0°C.
▪ 0: No averaging ▪ 1: 12 hours ▪ 2: 24 hours ▪ 3: 48 hours ▪ 4: 72 hours	

[3.9] Max. cooling undershoot LWT

⚙️[004]	Restriction: This function is only applicable in cooling mode. This function defines how much the water temperature may drop below the desired leaving water temperature before the compressor stops. The compressor will start up again when the leaving water temperature rises above the desired leaving water temperature.
0~10°C	

[3.10] NOT USED

[3.11] Undercooling setpoint

⚙️[014]	This limit prevents too low water temperatures from entering the emitter system. When this limit is reached, the heat pump and the pump will be switched OFF and cold water can no longer enter the emitter circuit. See "INFORMATION" below.
3~35°C	

**INFORMATION**

The minimum leaving water temperature is decided based on setting [3.11] **Undercooling setpoint**. This limit defines the minimum leaving water **in the system**. Depending on the value of this setting, the minimum LWT setpoint will also be increased by 4°C to allow stable control towards the setpoint.

The minimum leaving water temperature **in the main zone** is decided based on setting [1.20] **Undercooling water circuit**, only in case [3.13.5] **Bizone kit installed** is enabled. This limit defines the minimum leaving water **in the main zone**. Depending on the value of this setting, the minimum LWT setpoint will also be increased by 4°C to allow stable control towards the setpoint.

[3.12] Overheating setpoint

⚙️[015]	This limit prevents too high water temperatures from entering the emitter system. When this limit is reached, the heat sources and the pump will be switched OFF and hot water can no longer enter the emitter circuit. See "INFORMATION" below.
20~80°C	



INFORMATION

The maximum leaving water temperature is decided based on setting [3.12] **Overheating setpoint**. This limit defines the maximum leaving water **in the system**. Depending on the value of this setting, the maximum LWT setpoint will also be reduced by 5°C to allow stable control towards the setpoint.

The maximum leaving water temperature **in the main zone** is decided based on setting [1.19] **Overheating water circuit**, only in case [3.13.5] **Bizone kit installed** is enabled. This limit defines the maximum leaving water **in the main zone**. Depending on the value of this setting, the maximum LWT setpoint will also be reduced by 5°C to allow stable control towards the setpoint.

[3.13] Bizone kit


For more details about the correct setting selection, see the application guidelines chapter of the installer reference guide.

Additionally to the settings listed below, make sure to also set [3.6] **Additional zone** = ON (present) when a bizone kit is installed.


[3.13.1] Bizone system type

⚙️[008]	Must match your system layout. Indicates which type of bizone system is installed.
---------	--

▪ 0: Not decoupled



▪ 1: Decoupled. This layout can be made with or without direct pump.



a: Indoor unit; **b:** Mixing station; **c:** Hydraulic separator; **d:** Direct pump

[3.13.2] Add zone pump fixed PWM

⚙️[097] Fixed pump speed for additional (direct) zone.

- If set via breadcrumb: 0~100%
- If set via field code: 0~1 (step: 0.01)

[3.13.3] Main zone pump fixed PWM

⚙️[096] Fixed pump speed for main (mixed) zone.

- If set via breadcrumb: 0~100%
- If set via field code: 0~1 (step: 0.01)

[3.13.4] Mixing valve turning time

⚙️[176] Time in seconds for the mixing valve to turn from one side to the other.
If a third-party mixing valve is installed in combination with controller EKMIKPOA, the valve turning time must be set accordingly.

20~300 seconds



NOTICE

This functionality is NOT available in early versions of the user interface software.

[3.13.5] Bizone kit installed

⚙️[099] Must match your system layout.
Indicates whether a mixing kit is installed in the hydraulic system.

- 0: OFF (not installed)
- 1: ON (installed)

Remark: When connecting and reconnecting the mixing kit, a power reset might be required if the bizon kit is not automatically detected.

[3.14] Room thermostat present

This is the same setting as "[\[1.31\] Daikin room thermostat](#)" [▶ 77](#)].

[3.15] Heatpump minimum on time

⚙️[016]	Minimum time the heat pump will be kept on after operation has been started, except when the leaving water limits are drastically exceeded^(a). This minimum time is used when starting up in space heating/cooling or tank heat-up. When receiving a request to operate the heat pump, there is an initial assessment period of 4 minutes to evaluate the conditions. If the assessment determines that the heat pump should operate, it will run for a minimum time defined by this setting, even if the request drops. If a system, such as the 'Daikin Home Controls system', is installed and capable of closing the emitters via valves, the minimum time defined by this setting must be in line with the opening times of the valves to prevent the heat pump from cycling on and off.
480~1800 seconds (8~30 minutes)	

^(a) For more information about space heating/cooling, see "[\[3.7\] Max. heating overshoot LWT](#)" [▶ 95](#)] and "[\[3.9\] Max. cooling undershoot LWT](#)" [▶ 96](#)]. For tank heat-up, the overshoot depends on an internal limit.

[4] Domestic hot water

In this chapter

- [4.1] Single heat-up..... 100
- [4.2] NOT USED 100
- [4.3] Manual setpoint..... 100
- [4.4] Powerful operation setpoint..... 101
- [4.5] Reheat setpoint..... 101
- [4.6] Single heat-up schedule..... 101
- [4.7] Heat up mode 101
- [4.8] NOT USED 103
- [4.9] Clear disinfection malfunction..... 103
- [4.10] Disinfection/ [4.18] Disinfection enable..... 103
- [4.11] Operation range..... 105
- [4.12] Hysteresis..... 106
- [4.13] DHW pump 106
- [4.14] Booster heater..... 106
- [4.15] NOT USED 107
- [4.16] Add. source take over during SH/C..... 107
- [4.17] Add. source DHW always on request..... 108
- [4.18] Disinfection enable..... 108
- [4.19] Reheat Trigger Threshold 108
- [4.20] NOT USED 109
- [4.21] NOT USED 109
- [4.22] NOT USED 109
- [4.23] Offset BSH setpoint..... 109
- [4.24] Enable reheat schedule..... 109
- [4.25] Reheat schedule..... 109
- [4.26] DHW pump schedule 109

[4.1] Single heat-up

⚙️[N/A]	Single heat-up
▪ Manual: The tank heats up using the heat pump (more efficient) to the temperature setpoint of [4.3] Manual setpoint. ▪ Powerful operation: The tank heats up using the backup heater or booster heater, to the temperature setpoint of [4.4] Powerful operation setpoint.	

Note: This screen can be accessed from the home screen by tapping on the Domestic hot water bar.

[4.2] NOT USED

[4.3] Manual setpoint

⚙️[N/A]	Restriction: Only applicable if [4.1] = Manual. Setpoint for the tank temperature in Manual mode. See "2.4 Setpoint screen" [▶ 12]. Press the Start button to activate the heat-up process. Note: To stop an ongoing heat-up process, tap on the Domestic hot water bar from the home screen and press the ⏻ button.
---------	--

[4.4] Powerful operation setpoint

⚙️[N/A]	Restriction: Only applicable if [4.1] = Powerful operation. Setpoint for the tank temperature in Powerful operation mode. See "2.4 Setpoint screen" [▶ 12]. Press the Start button to activate the heat-up process. Note: To stop an ongoing heat-up process, tap on the Domestic hot water bar from the home screen and press the ⏻ button.
---------	--

[4.5] Reheat setpoint

⚙️[N/A]	In Reheat and Schedule and reheat modes, the domestic hot water tank continuously heats up to this temperature. The heat-up of the DHW tank is controlled by two triggers: ▪ [4.12] Hysteresis ▪ [4.19] Reheat Trigger Threshold
For more information, see " [4.7] Heat up mode " [▶ 101], " 6.2 Reheat mode " [▶ 30] and " 6.3 Schedule and reheat mode " [▶ 32].	

[4.6] Single heat-up schedule

⚙️[N/A]	The tank heats up according to the scheduled time and temperature.
For more information, see " 6.5 Single heat-up " [▶ 35].	

[4.7] Heat up mode

⚙️[N/A]	Restriction: This setting is NOT applicable for ECH₂O units. Defines how the domestic hot water is prepared. The 3 different ways differ from each other by the way the desired tank temperature is set and how the unit acts upon it. For more information, see "6 Domestic hot water control" [▶ 30].
▪ Reheat The tank can ONLY be heated by reheat operation (fixed or scheduled^(a)). Use the following settings: - [4.11] Operation range - [4.12] Hysteresis (see "[4.12] Hysteresis" [▶ 106] and "[4.19] Reheat Trigger Threshold" [▶ 108]) - [4.24] Enable reheat schedule^(a) - In case of fixed: [4.5] Reheat setpoint - In case of scheduled: [4.25] Reheat schedule^(a)	
▪ Schedule and reheat^(b) The tank is heated according to a schedule and between the scheduled heat up cycles, reheat operation is allowed. The settings are the same as for Reheat and for Scheduled.	
▪ Scheduled^(b) The tank can ONLY be heated according to a schedule. Use the following settings: - [4.6] Single heat-up schedule	

^(a) Only applicable for ECH₂O units.

^(b) NOT applicable for ECH₂O units.

Related settings:

Setting	Description
[4.11] Operation range ⚙️[153]	You can set the maximum allowed tank temperature here. This is the maximum temperature that users can select for the domestic hot water. You can use this setting to limit the temperature at the hot water taps.
[4.24] Enable reheat schedule ^(a) ⚙️[N/A] (in case of Reheat)	The reheat setpoint can be: ▪ Fixed (default) ▪ Scheduled You can switch between the two here: ▪ OFF = Fixed. You can now set [4.5]. ▪ ON = Scheduled. You can now set [4.25].
[4.5] Reheat setpoint ⚙️[N/A] (in case of fixed reheat setpoint and in case of Reheat or Schedule and reheat)	You can set the fixed reheat setpoint here. ▪ 20~[4.11]°C
[4.25] Reheat schedule ^(a) ⚙️[N/A] (in case of scheduled reheat setpoint and in case [4.24] = ON)	You can program the reheat schedule here.
[4.12] Hysteresis ⚙️[N/A] (in case of Reheat or Schedule and reheat)	You can set the reheat hysteresis here. When the tank temperature drops below the reheat temperature minus the reheat hysteresis temperature, the tank heats up to the reheat temperature. ▪ 1~40°C
[4.6] Single heat-up schedule ⚙️[N/A] (in case of Scheduled or Schedule and reheat)	You can program and activate a tank schedule here.

^(a) Only applicable for ECH₂O units.



INFORMATION

Limit the maximum hot water temperature according to the applicable legislation.



INFORMATION

Risk of space heating capacity shortage for domestic hot water tank without internal booster heater: In case of frequent domestic hot water operation, frequent and long space heating/cooling interruption will happen when selecting **Operation mode = Reheat** (only reheat operation allowed for the tank).

[4.8] NOT USED

[4.9] Clear disinfection malfunction

**CAUTION**

The disinfection error AH is automatically cleared after a successful disinfection, but you can also manually clear it via [4.9] **Clear disinfection malfunction**.


Beware, the disinfection function will only be repeated upon the next scheduled disinfection block!

[4.10] Disinfection / [4.18] Disinfection enable

The disinfection function disinfects the domestic hot water tank by periodically heating the domestic hot water to a specific temperature.

**CAUTION**

The disinfection function settings **MUST** be configured by the installer according to the applicable legislation.



[4.18] Disinfection enable

[072]	Enables/disables the disinfection function.
0: OFF: Disabled 1: ON: Enabled	

[4.10] Disinfection > Details > Operation day

[150]/[152]	Defines on which day the disinfection function runs.	
[150]	[152]	Operation day
N/A	1	Every day
1	0	Monday
2	0	Tuesday
3	0	Wednesday
4	0	Thursday
5	0	Friday
6	0	Saturday

7	0	Sunday
---	---	--------

[4.10] Disinfection > Details > Start time

⚙️[151]	Defines at which time the disinfection function starts running.
▪ If set via breadcrumb [4.10] Disinfection > Details > Start time: Set the time in the range 00:00~23:59 ▪ If set via field setting ⚙️[151]: Set the time as the amount of minutes counting from 00:00. Example: If you want to start at 01:00, then set ⚙️[151]=60.	

[4.10] Disinfection > Details > Duration

⚙️[074]	Defines how long the disinfection function runs at the target temperature.
▪ For wall-mounted units: 5~60 minutes ▪ For floor-standing and ECH₂O units: 40~60 minutes	

[4.10] Disinfection > Setpoint > Set temperature to...

⚙️[073]	Defines at which temperature the disinfection function runs.
▪ For wall-mounted units: 55°C~[4.11] ▪ For floor-standing and ECH₂O units: 60°C~[4.11]	



WARNING

Be aware that the domestic hot water temperature at the hot water tap will be equal to the value selected in field setting ⚙️[073] after a disinfection operation.

When the high domestic hot water temperature can be a potential risk for human injuries, a mixing valve (field supply) shall be installed at the hot water outlet connection of the domestic hot water tank. This mixing valve shall secure that the hot water temperature at the hot water tap never rises above a set maximum value. This maximum allowable hot water temperature shall be selected according to the applicable legislation.



CAUTION

Make sure that the disinfection function start time with defined duration is NOT interrupted by possible domestic hot water demand.



NOTICE

Disinfection mode. Even if you turn OFF tank heating operation, disinfection mode will remain active (if enabled).



INFORMATION

In case of error code AH and no interruption of the disinfection function occurred due to domestic hot water tapping, following actions are recommended:

- When the **Reheat** or **Scheduled reheat** mode is selected, it is recommended to program the start-up of the disinfection function at least 4 hours later than the last expected large hot water tapping. This start-up can be set by installer settings (disinfection function).
- When the **Scheduled** mode is selected, it is recommended to program a scheduled action 3 hours before the start-up of the disinfection function to preheat the tank.

**INFORMATION**

Heat-up during disinfection restarts when the tank temperature drops 1°C below the disinfection setpoint. The duration time is reset when the tank temperature drops 5°C below the disinfection target setpoint.

**CAUTION**

The disinfection error AH is automatically cleared after a successful disinfection, but you can also manually clear it via [4.9] **Clear disinfection malfunction**.

Beware, the disinfection function will only be repeated upon the next scheduled disinfection block!

[4.11] Operation range

See also "[\[4.7\] Heat up mode](#)" [▶ 101].

[153]	You can set the maximum allowed tank temperature here. This is the maximum temperature that users can select for the domestic hot water. You can use this setting to limit the temperature at the hot water taps.
Maximum temperature for the tank in case of floor-standing units: 65°C	
Maximum temperature for the tank in case of ECH ₂ O units: 75°C	
Maximum temperature for the tank in case of wall-mounted units: ▪ EKHWS/E 1501 (EKHWS/E 150 l) Tank with booster heater installed at side of the tank with a volume of 150 l. Maximum temperature 60°C. ▪ EKHWS/E 1801 (EKHWS/E 180 l) Tank with booster heater installed at side of the tank with a volume of 180 l. Maximum temperature 60°C. ▪ EKHWS/E 2001 (EKHWS/E 200 l) Tank with booster heater installed at side of the tank with a volume of 200 l. Maximum temperature 75°C. ▪ EKHWS/E 2501 (EKHWS/E 250 l) Tank with booster heater installed at side of the tank with a volume of 250 l. Maximum temperature 75°C. ▪ EKHWS/E 3001 (EKHWS/E 300 l) Tank with booster heater installed at side of the tank with a volume of 300 l. Maximum temperature 75°C. ▪ EKHWP/HYC with BSH (EKHWP/HYC with booster heater) Tank with optional booster heater installed at top. Maximum temperature 80°C. ▪ 3rd party small coil Third-party tank with a coil size larger than 1.05 m². Maximum temperature 60°C. ▪ 3rd party big coil Third-party tank with a coil size larger than 1.80 m². Maximum temperature 75°C.	
Maximum temperature for the tank in case of *SU* units (i.e. UK models): 60°C	

[4.12] Hysteresis

⚙️[N/A]	This trigger compensates for natural heat losses and intermittent DHW usage. The system continuously monitors for heat loss, and when the tank temperature drops below "[4.5] Reheat setpoint – [4.12] Hysteresis", it starts determining when reheating is necessary. This trigger ensures that the system maintains sufficient hot water availability before temperatures fall too low for user demand.
For more information, see "6.2 Reheat mode" [▶ 30] and "6.3 Schedule and reheat mode" [▶ 32].	

[4.13] DHW pump

⚙️[149]	Must match your system. If you installed a DHW pump for instant hot water and/or disinfection operation, you must specify its functionality here. Note: The DHW pump is a Field IO connection: [13] Field IO (DHW pump).
▪ 0: None: DHW pump not installed. ▪ 1: Instant hot water: DHW pump installed for instant hot water when water is tapped. The user sets the operation timing of the domestic hot water pump using the schedule. Control of this pump is possible with the user interface. See "[4.26] DHW pump schedule" [▶ 109]. ▪ 2: Disinfection: DHW pump installed for disinfection. It runs when the disinfection function of the domestic hot water tank is running. No further settings are needed. ▪ 3: Both: Combination of Instant hot water and Disinfection. See "[4.26] DHW pump schedule" [▶ 109].	

[4.14] Booster heater

Restriction: Only applicable for wall-mounted units with the DHW tank with the booster heater.

[4.14.1] Booster heater capacity

⚙️[173]	Only applies to domestic hot water tank with an internal booster heater. The capacity of the booster heater at nominal voltage. The capacity of the booster heater must be set for the energy metering and/or power consumption control feature to work properly. When measuring the resistance value of the booster heater, you can set the exact heater capacity and this will lead to more accurate energy data.
1~4 kW	

[4.14.2] NOT USED**[4.14.3] Booster heater delay timer**

⚙️[070]	Delay timer for the additional heat source activation when the heat pump is the main source during tank heat up operation. The delay timer is used to ensure that the heat pump gets enough time to heat up the tank. The additional heat source is triggered when [4.17] Add. source DHW always on request = ON. By adapting the booster heater delay time versus the maximum running time, you can find an optimal balance between the energy efficiency and the heat up time. If the booster heater delay time is set too high, it might take a long time before the domestic hot water reaches its set temperature. Note: The delay timer is not considered (i.e. the additional heat source will immediately assist) in case of: ▪ A powerful request ▪ Space heating priority
	0~5700 seconds

[4.14.4] DHW BSH overshoot temperature

Same as [4.23]. See " [4.23] Offset BSH setpoint" [▶ 109].

[4.15] NOT USED

[4.16] **Add. source take over during SH/C**

⚙️[N/A]	Restriction: Only applicable for wall-mounted units with a single thermistor tank or in case [5.32] Tank boiler present = On. Turns ON/OFF whether an additional heat source is allowed to heat up the tank when the heat pump is running in space heating/cooling. ▪ In case of ECH₂O units, and a tank boiler is selected: Additional heat source = tank boiler ▪ In case of wall-mounted units: Additional heat source = booster heater Note: Turning ON this setting results in extra power consumption.
	▪ OFF ▪ ON

[4.17] Add. source DHW always on request

⚙️[N/A]	Restriction: Only applicable for wall-mounted units with a single thermistor tank or in case [5.32] Tank boiler present = On. Turns ON/OFF whether an additional heat source is immediately allowed to assist the heat pump during tank heat-up operation. ▪ In case of ECH₂O units, and a tank boiler is selected: Additional heat source = tank boiler ▪ In case of wall-mounted units: Additional heat source = booster heater Note: Turning ON this setting results in extra power consumption.
▪ OFF ▪ ON	

[4.18] Disinfection enable

See "[\[4.10\] Disinfection](#) / [\[4.18\] Disinfection enable](#)" [▶ 103].

[4.19] Reheat Trigger Threshold

⚙️[N/A]	Defines the reheat trigger temperature of the domestic hot water tank to ensure sufficient energy is present in the tank. This setting is optimised for sufficient comfort. Only applicable for DHW consumption (rapid decrease of temperature). The tank heats up when the temperature drops below a predefined value. The threshold is set with sufficient spare capacity to prevent an immediate shortage of hot water for the end user. It ensures that the system maintains a reliable supply while avoiding unnecessary reheating cycles. Note: Only available in Advanced settings mode. Note: Always make sure to use a value lower than [4.5] Reheat setpoint.
▪ 10~85°C	

For more information, see "[6.2 Reheat mode](#)" [▶ 30] and "[6.3 Schedule and reheat mode](#)" [▶ 32].

[4.20] NOT USED

[4.21] NOT USED

[4.22] NOT USED

[4.23] Offset BSH setpoint

⚙️[064]	Restriction: Only applicable for wall-mounted units with the booster heater. Setpoint correction for the desired domestic hot water temperature, to be applied: - At low outdoor temperature when space heating priority is enabled, OR - When the unit is balancing space heating/cooling and domestic hot water operation, and [4.16] Add. source take over during SH/C = ON. The corrected (higher) setpoint will make sure that the total heat capacity of the water in the tank remains approximately unchanged, by compensating for the colder bottom water layer of the tank (because the heat exchanger coil is not operational) with a warmer top layer.
▪ 0~20°C	

[4.24] Enable reheat schedule

Restriction: Only applicable for ECH₂O units.

For more information, see " [4.7] **Heat up mode**" [▶ 101] and "6.2 **Reheat mode**" [▶ 30].

[4.25] Reheat schedule

Restriction: Only applicable for ECH₂O units.

For more information, see " [4.7] **Heat up mode**" [▶ 101] and "6.2 **Reheat mode**" [▶ 30].

[4.26] DHW pump schedule

⚙️[N/A]	Schedule for when the DHW pump is turned ON/OFF in case the DHW pump is used for instant hot water (see " [4.13] DHW pump" [▶ 106]). When turned ON, the pump runs and makes sure hot water is instantly available at the tap. To save energy, only turn ON the pump during periods of the day when instant hot water is necessary. Note: This setting is used when [4.13] DHW pump is set to Instant hot water or Both.
	Predefined schedules: 1 Activation: Not applicable. Possible actions: - Off - On

[5] Settings

In this chapter

[5.1] Forced defrost.....	110
[5.2] Quiet operation.....	111
[5.3] Time/date.....	111
[5.4] Breadcrumbs.....	111
[5.5] Backup heater.....	111
[5.6] Capacity shortage.....	113
[5.7] Overview field settings.....	114
[5.8] NOT USED.....	114
[5.9] Location and language.....	114
[5.10] Timezone.....	114
[5.11] Reset fan operation hours.....	114
[5.12] Keyboard lay-out.....	115
[5.13] Advanced settings.....	115
[5.14] Bivalent.....	115
[5.15] NOT USED.....	119
[5.16] NOT USED.....	119
[5.17] Display brightness.....	119
[5.18] System restart.....	119
[5.19] NOT USED.....	119
[5.20] NOT USED.....	119
[5.21] NOT USED.....	119
[5.22] External ambient sensor offset.....	119
[5.23] Emergency selection.....	121
[5.24] Advanced log level.....	121
[5.25] NOT USED.....	122
[5.26] Display inactivity timer.....	122
[5.27] Holiday.....	122
[5.28] Balancing.....	122
[5.29] Refrigerant recovery mode.....	124
[5.30] Emergency acknowledgement.....	124
[5.31] Tank energy for space heating during defrost.....	124
[5.32] Tank boiler present.....	125
[5.33] Tank boiler covers heat demand.....	125
[5.34] Maximum capacity.....	126
[5.35] Pump limitation service.....	126
[5.36] Water pipe freeze prevention.....	126
[5.37] Bivalent present.....	126
[5.38] Tank support.....	127

[5.1] Forced defrost

⚙️[N/A]	Manually start a defrost operation. The forced defrost will only start when at least the following conditions are fulfilled: ▪ Unit is in heating operation and has been running for a few minutes ▪ Outdoor ambient temperature is low enough ▪ Temperature at the outdoor unit heat exchanger coil is low enough
Are you sure that you want to run a forced defrost?	
▪ Cancel: With this button you exit the menu. It does NOT interrupt any ongoing forced defrost (i.e. once a forced defrost is triggered via the user interface, it is NOT possible to stop the request anymore). ▪ Confirm	


[5.2] Quiet operation

⚙️[N/A]	[5.2] Quiet operation ▪ Off ▪ Manual => [5.2.1] Quiet mode - Manual ▪ Scheduled - Schedule => [5.2.2] Quiet operation schedule: Schedule for when the unit has to use which quiet mode level. - Restrictions => [5.2.8] Restrictions: [5.2.9] [5.2.10] [5.2.11] [5.2.12]: Restrictions configured by the installer based on local regulations.
⚙️[138]	[5.2.9] AM Restricted time Start of Day.
⚙️[136]	[5.2.10] AM Restricted level Level used during the Day.
⚙️[139]	[5.2.11] PM Restricted time Start of Night.
⚙️[137]	[5.2.12] PM Restricted level Level used during the Night.
For more information, see "9.2 Using quiet mode" [▶ 56].	

[5.3] Time/date

⚙️[N/A]	Defines the clock settings on the user interface.
▪ Date ▪ Clock format (24 hours or AM/PM) ▪ Time ▪ Daylight savings time (ON/OFF)	

[5.4] Breadcrumbs

⚙️[N/A]	Enables/disables the breadcrumbs. Breadcrumbs help you to locate where you are in the menu structure of the user interface. Example: [3.1]: 
▪ OFF (disabled): This is the default setting for users and advanced users. ▪ ON (enabled)	

[5.5] Backup heater

[5.5] Backup heater > Grid configuration

⚙️[083]	Must match your system layout. Grid connection type of the backup heater.
▪ 0: Single phase ▪ 1: Three phase 3x400V+N ▪ 2: Three phase 3x230V	

[5.5] Backup heater > Fuse >10A

⚙️[154]	Must match your system layout. Overcurrent fuse for the backup heater in the electrical cabinet.
▪ 0: OFF (fuse ≤10 A) ▪ 1: ON (fuse >10 A)	

[5.5] Backup heater > Maximum capacity

⚙️[092]	Defines the maximum capacity of the backup heater. Note: During defrost operation, the backup heater support may go up to the maximum capacity defined here. If needed, you can limit this value (but not lower than 2 kW to ensure reliable operation).
The maximum capacity suggested by the user interface is based on the selected grid configuration and, if applicable, the size of the fuse. An installer can however lower the maximum capacity of the backup heater using the scroll list. The tables below give an overview of the dynamic maximums of the scroll list.	

Maximum capacity in case of floor-standing or wall-mounted units

Grid configuration	Fuse >10A	Maximum capacity	
		4V models	9W models
Single phase	(greyed out)	Limited to 4.5 kW ^(a)	Limited to 6 kW ^(a)
Three phase 3x400V+N	OFF		Limited to 4 kW ^(a)
	ON		Limited to 9 kW ^(a)
Three phase 3x230V	(greyed out)		Limited to 4 kW ^(a)

^(a) But not lower than 2 kW.

Maximum capacity in case of ECH₂O units

Grid configuration	Fuse >10A	Maximum capacity
Single phase	(greyed out) ^(a)	Limited to 6 kW ^(b)
Three phase 3x400V+N	(greyed out) ^{(a)(c)}	Limited to 9 kW ^(b)

^(a) The fuse setting cannot be used (i.e. installing fuses <10A is NOT allowed).

^(b) But not lower than 2 kW.

^(c) This functionality is NOT greyed out in early versions of the user interface software.

[5.6] Capacity shortage

**INFORMATION**

The backup heater logic determines whether to activate the backup heater when the heat pump experiences capacity shortage. The system will ONLY activate the backup heater when:

- The compressor is already running at its maximum capacity, and
- The leaving water temperature setpoint is NOT reached, and
- The leaving water temperature requested at the emitter is NOT reached in a fast enough rate.

[5.6.1] Capacity shortage setting

⚙️[N/A]	Defines whether backup heater operation is allowed when the heat pump experiences capacity shortage.
▪ Never: Never allow backup heater operation when the heat pump experiences capacity shortage. ▪ Always: Always allow backup heater operation when the heat pump experiences capacity shortage. ▪ Below equilibrium: Only allow backup heater operation when the heat pump experiences capacity shortage, and the outdoor temperature is below the equilibrium setpoint.	

[5.6.2] Equilibrium setpoint

⚙️[N/A]	Restriction: Only applicable if [5.6.1] = Below equilibrium. Defines the outdoor temperature below which backup heater operation is allowed when the heat pump experiences capacity shortage. Adjust the equilibrium setpoint based on your building, location, and personal preference to ensure optimal balance and comfort. For more information about the maximum capacity of the heat pump, see https://daikintechdatahub.eu/
-15~35°C	

**NOTICE**

For houses with a similar heat load as the declared heating capacity on the energy label, it is recommended to set the [5.6.2] **Capacity shortage setting** to 2 (**Below equilibrium**) and decrease the equilibrium setpoint [5.6.2] **Equilibrium setpoint** to the declared bivalent temperature of -10°C. (refer to product fiche in accessory bag or the online energy label database (see: <https://daikintechdatahub.eu/>)).

**INFORMATION**

Applicable if [5.6.1] = **Below equilibrium**:

Above 10°C ambient temperature, the heat pump will operate until 70°C. Configuring a higher setpoint with an ambient temperature that is higher than the set equilibrium temperature will prevent the backup heater from assisting. The backup heater will ONLY assist if you increase the equilibrium temperature [5.6.2] to the required ambient temperature you need to reach the higher setpoint.


[5.7] Overview field settings

[N/A]

Almost all settings can be done using the menu structure. If for any reason it is required to change a setting using the overview settings, then the overview of the field settings can be accessed here.

Where applicable, the field setting codes are described in the configuration reference guide, and in the field settings table of the installer reference guide.

Field codes that are not applicable are greyed out.



a Field setting code

b Selected value

c To select the wanted value

d To browse through the different pages

[5.8] NOT USED

[5.9] Location and language

[N/A]

Defines the location and language on the user interface.

- Country
- Language

[5.10] Timezone

[N/A]

Restriction: Only applicable for countries with multiple time zones.

Defines the time zone on the user interface.

UTC (Coordinated Universal Time)

[5.11] Reset fan operation hours

[N/A]

Resets the fan operation hours.

Fan operation hours need to be reset in two cases:

- When warning H7–31 is triggered by the outdoor unit, the fan motor needs to be replaced, and the fan hours need to be reset to clear the warning. This will be indicated on the error screen.
- When the fan motor is replaced for another reason, fan operation hours also need to be reset.

Confirm to reset the fan operation hours.

- Cancel
- Confirm

[5.12] Keyboard lay-out

⚙️[N/A] Defines the keyboard layout on the user interface.

- QWERTY
- AZERTY

[5.13] Advanced settings

⚙️[N/A] There are three permission levels, which define what you can see and do on the user interface:

- User mode
- Advanced user mode
- Installer mode

On the home screen, and most other screens where applicable, you can switch between user and installer mode.

▪  : User mode.

▪  : Installer mode. Pin code: 5678.

Via setting [5.13] you can switch between user mode and advanced user mode.

Note: When you switch from installer mode to user mode while [5.13] was switched ON (advanced user mode), you will have to manually turn OFF—turn ON [5.13] to enable advanced user mode again.

- OFF (user mode)
- ON (advanced user mode)

[5.14] Bivalent

For more information about setting up bivalent heat sources, see the application guidelines chapter in the installer reference guide.



INFORMATION

Bivalent is only possible in case of 1 leaving water temperature zone with:

- room thermostat control, OR
- external room thermostat control.

Applicable settings:


Setting	Applicability	
	If bivalent is present (defined in [5.37] Bivalent present, or in the configuration wizard [10.4] Bivalent)	If tank boiler is present (defined in [5.32] Tank boiler present, or in the configuration wizard [10.6] Tank boiler)
[5.14.6] Post-run timer	Yes	No
[5.14.9] Enable proactive tank heating	No	Yes
[5.14.4] Bivalent hysteresis	Yes	Yes
[5.14.2] Operation range > Upper limit	Yes	Yes
[5.14.2] Operation range > Lower limit	Yes	Yes
[9.3] Electricity price schedule enable	Yes	Yes
[9.13] Energy price considered	Yes	Yes
[9.12] PE factor	No	Yes
[9.11] Boiler efficiency	Yes	Yes
[9.5] Gas price	Yes	Yes

If there is no tank boiler available, or bivalent through headers is not available (fossil heat sources), the heat pump (renewable heat source) will always be decided as the main heat source for space heating and for tank heat-up.

Bivalent for space heating

If bivalent through headers or tank boiler is available, the main heat source will be decided based on a comparison between the efficiencies of both heat sources. The decision on which source to select depends on setting [9.13] **Energy price considered**. This setting defines if the inputted energy prices are considered or not.

When energy prices are considered (i.e. [9.13] Energy price considered = ON):



- a** Fossil heat source
- b** Renewable heat source
- T_{calc}** Changeover temperature calculated by the software.


The main heat source will be decided based on the bivalent changeover condition with dedicated ambient boundaries selected by the installer ([5.14.2] **Operation range**: upper and lower limit).

See selection [5.14.2] **Operation range**. The changeover will happen around that temperature with a dedicated hysteresis ([5.14.4] **Bivalent hysteresis**); standard there will be an minimum hysteresis of 2°C included.

The changeover temperature (T_{calc}) is calculated based on:


- Break-even COP (Coefficient of Performance), which in turn depends on:
 - Ratio of electricity and gas prices
 - Boiler efficiency
- Heat pump efficiency determined by:
 - Outdoor ambient temperature
 - Target leaving water temperature (in case of a bivalent boiler)

When energy prices are NOT considered ([9.13] Energy price considered = OFF)



The main heat source will be decided based on the ambient boundaries selected by the installer ([5.14.2] **Operation range**: Upper and lower limit). This case is mainly capacity driven (where below the ambient condition the boiler will cover the space heating capacity).

Heat source selection for the tank heat-up



If a tank boiler is available, the main heat source will be decided based on a comparison between the efficiencies of both heat sources. The decision on which source to select depends on setting [9.13] **Energy price considered**. This setting defines if the inputted energy prices are considered or not.

When energy prices are considered (i.e. [9.13] Energy price considered = ON):

The changeover temperature (T_{calc}) is calculated based on:

- Break-even COP (Coefficient of Performance), which in turn depends on:
 - Ratio of electricity and gas prices
 - Boiler efficiency
- Heat pump efficiency determined by:
 - Outdoor ambient temperature

When the storage tank temperature reaches T_{calc} (including a hysteresis), the tank boiler is set as primary heat source.

When energy prices are NOT considered ([9.13] Energy price considered = OFF):

If electricity and gas prices are not known, the PE factor (primary energy factor) is used for the calculation of the break-even COP. Lower values of the PE factor result in increased use of the heat pump. Higher values of the PE factor result in increased use of the tank boiler.

[5.14.1] NOT USED**[5.14.2] Operation range**

The lower limit has priority over upper limit.

Upper limit:

⚙️[023]	Defines the upper outdoor temperature limit of the changeover point from heat pump to bivalent/tank boiler.
max([024]+2; -25)~25°C	

Lower limit:

⚙️[024]	Defines the lower outdoor temperature limit of the changeover point from heat pump to bivalent/tank boiler.
-25~25°C	

[5.14.3] NOT USED**[5.14.4] Bivalent hysteresis**

⚙️[021]	Restriction: Only applicable if the setting [9.13] Energy price considered is enabled. Defines the hysteresis on the outdoor temperature for the changeover from heat pump to bivalent.
2~10°C	

[5.14.5] NOT USED**[5.14.6] Post-run timer**

⚙️[025]	Defines the minimum time the bivalent boiler pump in space heating stays on after the request has stopped. This timer is triggered from the moment bivalent is switched OFF. It prevents going to another mode as long as the timer is running. During this time the bivalent bypass valve remains open to ensure flow over the indoor unit. Note: It is possible that when two pumps operate in parallel circuits, one of the two circuits may experience no flow. This setting will have to be adapted according to the post-run timer of the boiler pump when the request stops. Please check with the boiler manufacturer for the correct value.
0~1500 seconds	

[5.14.7] NOT USED**[5.14.8] NOT USED****[5.14.9] Enable proactive tank heating**

⚙️[002]	Restriction: Only applicable for units with tank boiler. Enables/disables the domestic hot water tank to be proactively preheated by the tank boiler to the proactive setpoint. With this high tank temperature, failed defrosts can be avoided as much as possible without any interruption of the space heating operation.
▪ 0: OFF (disabled) ▪ 1: ON (enabled)	

**INFORMATION**

When the setting [5.14.9] **Enable proactive tank heating** is enabled and a very low value in [4.19] **Reheat Trigger Threshold** is set, the heat pump might heat up the tank more frequently.

[5.15] NOT USED

[5.16] NOT USED

[5.17] Display brightness

⚙️[N/A]	Defines the brightness of the user interface.
30~100%	

[5.18] System restart

⚙️[N/A]	Manually restart the system.
Are you sure that you want to restart the entire system? ▪ Cancel ▪ Confirm	

[5.19] NOT USED

[5.20] NOT USED

[5.21] NOT USED

[5.22] External ambient sensor offset

[5.22] External ambient sensor offset > Outdoor

⚙️[175]	Restriction: Only applicable in case an external outdoor ambient temperature sensor is connected. You can calibrate the external outdoor ambient temperature sensor. It is possible to give an offset to the thermistor value. This setting can be used to compensate for situations where the sensor cannot be installed on the ideal installation location. Note: The external outdoor ambient temperature sensor is a Field IO connection: ▪ [13] Field IO (External outdoor sensor)
-5~5°C	

[5.22] External ambient sensor offset > Room

⚙️[N/A]	Restriction: Only applicable if: ▪ [1.12] = Room, and ▪ an external indoor ambient temperature sensor is connected. You can calibrate the external indoor ambient temperature sensor. It is possible to give an offset to the thermistor value. This setting can be used to compensate for situations where the sensor cannot be installed on the ideal installation location. Same as setting [1.33] External room sensor offset. Note: The external indoor ambient temperature sensor is a Field IO connection: ▪ [13] Field IO (External indoor sensor)
-5~5°C	

[5.23] Emergency selection

⚙️[N/A]	When a heat pump failure occurs, then setting [5.23] defines whether the electrical heater (backup heater / booster heater / tank boiler if applicable) can take over the space heating and DHW operation. When there is no automatic full take-over by the electrical heater, a pop-up (with the same content as " [5.30] Emergency acknowledgement" [▶ 124]) appears where you can manually acknowledge that the electrical heater can fully take over (i.e. space heating to normal setpoint and DHW operation = ON). When the house is unattended for longer periods, we recommend to use auto SH reduced/DHW off to keep energy consumption low.	
[5.23]	When heat pump failure occurs, then there is ... by the electrical heater	Full take-over
Manual	No take-over: ▪ Space heating = OFF ▪ DHW operation = OFF	After manual acknowledgment
Automatic	Full take-over: ▪ Space heating to normal setpoint ▪ DHW operation = ON	Automatic
auto SH reduced/DHW on	Partial take-over: ▪ Space heating to reduced setpoint ▪ DHW operation = ON	After manual acknowledgment
auto SH reduced/DHW off	Partial take-over: ▪ Space heating to reduced setpoint ▪ DHW operation = OFF	After manual acknowledgment
auto SH normal/DHW off	Partial take-over: ▪ Space heating to normal setpoint ▪ DHW operation = OFF	After manual acknowledgment

**INFORMATION**

If a heat pump failure occurs and **Emergency selection** is NOT set to **Automatic**, the following functions will remain active even if the user does NOT acknowledge emergency operation:

- Room frost protection
- Underfloor heating screed dryout
- Water pipe freeze prevention
- Disinfection

[5.24] Advanced log level

Do NOT change this setting. It is meant for Daikin personnel only.

[5.25] NOT USED

[5.26] Display inactivity timer

Recommended to NOT change this setting (i.e. leave switched ON). This setting is mainly meant for testing purposes during the development process of the user interface software.


⚙️[N/A]	Enables/disables the inactivity timer. When enabled, the timer is used to automatically: ▪ Return to the home screen ▪ Dim the backlight ▪ Turn OFF the backlight
▪ OFF (disabled) ▪ ON (enabled)	

[5.27] Holiday


⚙️[N/A]	[5.27.1] Holiday mode
⚙️[N/A]	[5.27.2] Holiday period
See "9.3 Using holiday mode" [▶ 58].	

[5.28] Balancing

Balancing space heating



Balancing space cooling



t	Time
T_A	Outdoor temperature
-----	Maximum running time – Space cooling (minimum 30 minutes)
————	Maximum running time – Domestic hot water

[5.28.1] Space heating priority

⚙️[140]	Enables/disables the space heating priority functionality. In case of wall-mounted units: Defines whether domestic hot water is made by booster heater only when outdoor temperature is below the space heating priority temperature (see [5.28.2]). In case of floor-standing units: Defines whether backup heater will assist the heat pump during domestic hot water operation. If there is a parallel bivalent system installed, the bivalent system will take over the heat demand below the space heating priority temperature so the heat pump and backup heater can fully cover the tank heat-up demand. Note: ▪ In case a bivalent system is enabled, the boiler will take over for space heating. ▪ In case a tank boiler is enabled (only for ECH₂O units), the tank boiler will take over the tank heat-up. ▪ In case of wall-mounted units, the booster heater will take over the tank heat-up.
	▪ 0: OFF (disabled) ▪ 1: ON (enabled)

[5.28.2] Priority temperatures

Space heating:

⚙️[019]	Outdoor temperature where the space heating operation timer is at its minimum value. Below this outdoor temperature, the space heating priority function is activated (if enabled).
	–15~35°C

Space cooling:

⚙️[020]	Outdoor temperature where the space cooling operation timer is at its maximum value.
	20~50°C

[5.28.3] Max. space heating timer

⚙️[131]	Time that heat pump is reserved for space heating operation during balancing. Balancing = simultaneous requests for space heating and tank heat-up.
	1800~36000 seconds (step: 60 seconds)

[5.28.4] Max. space cooling timer

⚙️[132]	Time that heat pump is reserved for space cooling operation during balancing. Balancing = simultaneous requests for space cooling and tank heat-up.
---------	---

1800~36000 seconds (step: 60 seconds)

[5.28.5] Max. DHW timer

Lower limit:

⚙️[133]	Time that heat pump is reserved for tank heat-up operation during balancing (lower limit). Balancing = simultaneous requests for space heating/cooling and tank heat-up.
900~18000 seconds (step: 60 seconds)	

Upper limit:

⚙️[134]	Time that heat pump is reserved for tank heat-up operation during balancing (upper limit). Balancing = simultaneous requests for space heating/cooling and tank heat-up.
900~18000 seconds (step: 60 seconds)	

[5.29] Refrigerant recovery mode

⚙️[N/A]	Refrigerant recovery mode. This mode blocks heat pump operation, and opens all valves in the outdoor unit. This enables the installer (with required level of competences to handle R290 refrigerant) to recover all refrigerant from the outdoor unit in a complete and safe way.
For more information about refrigerant recovery, see the disposal chapter in the installer reference guide.	

[5.30] Emergency acknowledgement

⚙️[N/A]	When a heat pump failure occurs, then setting "[5.23] Emergency selection" [▶ 121] defines whether the electrical heater (backup heater and/or booster heater if applicable) can take over the space heating and DHW operation. If manual acknowledgement is needed for full take-over, a pop-up (with same content as [5.30]) appears where you can activate emergency.
Error has led to the malfunction of the heat pump. To ensure normal comfort the electrical heater can take over, after acknowledgement. Attention: Electrical consumption can be increased. ▪ Cancel. No full take-over by the electrical heater (i.e. the unit keeps running in the original state as defined in setting [5.23]). ▪ Activate emergency: Full take-over by the electrical heater (i.e. space heating to normal setpoint and DHW operation = ON).	

[5.31] Tank energy for space heating during defrost

⚙️[N/A]	Restriction: Only applicable for ECH ₂ O units. Defines how the tank can support during defrost operation to compensate for the space heating demand.
---------	--

- **Disabled:** Space heating is interrupted while the heat pump is in defrost operation. If the water temperatures drop below their limits, the plate heat exchanger will be protected by using the energy from the tank.
- **Optimized:** There are 3 possibilities depending on the tank temperature:
 - In case of high tank temperature:
Space heating is provided from energy stored in the tank while the heat pump is in defrost operation (same as **Continuous**)
 - In case of lower tank temperature but above the DHW setpoint:
The defrost energy is compensated with the tank energy.
 - In case of low tank temperature:
Space heating is interrupted, and the energy from the circuit is used to compensate the defrost energy. If the water temperatures drop, it will use the energy from the tank (same as **Disabled**)
- **Continuous:** Space heating is provided from energy stored in the tank while the heat pump is in defrost operation.

[5.32] Tank boiler present

⚙️[078]	Restriction: ▪ Only applicable for EPSXB* units. ▪ This setting cannot be turned ON if [5.37] Bivalent present = ON (installed). Must match your system layout. Defines whether a tank boiler is installed and allowed to operate. For more information about setting up bivalent heat sources, see the application guidelines chapter in the installer reference guide.
▪ 0: OFF (not installed) ▪ 1: ON (installed)	

[5.33] Tank boiler covers heat demand

⚙️[012]	Restriction: Only applicable for EPSXB* units. Enables/disables the tank boiler to become the main heat source during space heating. If the heat pump is forced off by a demand response, the tank boiler will take over. However, if the water temperature in the tank is low, it may take some time to heat up the tank to support space heating. Therefore, only turn ON (enable) this setting if the boiler has a minimum power output of 12 kW.
▪ 0: OFF (disabled): The auxiliary boiler is too small to cover the building demand and is used solely as backup heat source. Therefore, the heat pump is the only available primary heat source. ▪ 1: ON (enabled): The auxiliary boiler is large enough to cover the heat demand of the building and can therefore be considered as additional primary heat source. Therefore, the choice between operation of auxiliary boiler and heat pump should be done by efficiency calculation.	

[5.34] Maximum capacity

⚙️[011]	Restriction: Only applicable for ECH₂O units. Defines the maximum deliverable thermal capacity in the space heating circuit by the domestic hot water tank during tank support. Limiting the capacity used for tank heating support will prevent the heating support function from taking too much energy from the tank in a short time.
4~35 kW	

[5.35] Pump limitation service

This setting is only used for service purposes.

[5.36] Water pipe freeze prevention

⚙️[005]	Only relevant for installations with water piping outdoors. This function protects the outdoor water piping from freezing by activating the pump and, if required, the electrical heater.
▪ 0: Disabled ▪ 1: Continuous: There is a continuous water flow through the system. This setting can be used if the water piping is poorly insulated. ▪ 2: Intermittent: There is an intermittent water flow through the system. This setting can be used if the water piping is well insulated. For information about the correct insulation selection, see the connecting water piping chapter of the installer reference guide.	

**NOTICE**

Do NOT disable water pipe freeze protection as it can lead to the drainage of the system, or even damage to the water pipes.

[5.37] Bivalent present

⚙️[093]	Restriction: This setting cannot be turned ON if [5.32] Tank boiler present = ON (installed). Must match your system layout. Defines whether the additional boiler kit for space heating is installed and allowed to operate. For more information about setting up bivalent heat sources, see the application guidelines chapter in the installer reference guide.
▪ 0: OFF (not installed): Space heating is only done by the heat pump within the operation range. The permission signal for the auxiliary boiler is always inactive. ▪ 1: ON (installed): When the outdoor temperature drops below the bivalent ON temperature (fixed or variable based on energy prices), the space heating by the heat pump stops automatically and the permission signal for the auxiliary boiler is active.	

For more information, see also " [5.14] Bivalent" [▶ 115].

[5.38] Tank support

⚙️[N/A]	Restriction: Only applicable for ECH₂O units. Allows/disallows the domestic hot water tank to support the space heating operation by adding capacity to the space heating circuit. Set this value in case the auxiliary boiler is connected to the storage tank, and the heat generated by the auxiliary boiler has to be used for domestic hot water heating and for space heating support.
▪ OFF (not allowed) ▪ ON (allowed) Note: In case [5.38] is activated and there is a very high space heating setpoint, high tank temperatures might occur allowing the tank valve to open for space heating support when the heat pump is not considered as the main heat source.	

[6] Information

In this chapter

[6.1] NOT USED	128
[6.2] Dealer information	128
[6.3] Sensors	128
[6.4] Actuators	128
[6.5] Operation modes	128
[6.6] About	129
[6.7] Indoor unit model name / [6.8] Indoor unit serial number	129

[6.1] NOT USED

[6.2] Dealer information

⚙️[N/A]	Enables you to enter the dealer's contact details: ▪ Dealer ▪ Phone number ▪ Address ▪ Postal code ▪ City
To edit: 1 Tap . 2 Enter Name of the dealer, and confirm with the ✓ button. 3 Enter Phone number of the dealer, and confirm with the ✓ button. 4 Enter Address of the dealer, and confirm with the ✓ button. 5 Enter Postal code of the dealer, and confirm with the ✓ button. 6 Enter City of the dealer, and confirm with the ✓ button.	

[6.3] Sensors

⚙️[N/A]	Shows (read-only) the readout (temperatures, pressures, flow rates) of each sensor.
---------	---

[6.4] Actuators

⚙️[N/A]	Shows (read-only) the status/mode of each actuator. Example: [6.4.2] DHW pump = Off Note: For the following two pumps, the logic is reversed: 0% means the pump will go to full speed, and 100% means the pump is OFF: ▪ Bizone kit direct pump ▪ Bizone kit mixed pump
---------	---

[6.5] Operation modes

⚙️[N/A]	Shows (read-only) the status of each operation mode. Example: [6.5.1] Disinfection = Successful
---------	---

[6.6] About

⚙️[N/A]	Shows (read-only) information (model names, serial numbers, software versions, ...) about the system.
---------	---

[6.7] Indoor unit model name / [6.8] Indoor unit serial number

⚙️[N/A]	Restriction: These settings are only visible to certified installers (Stand By Me – Certified Partner) when the model name and serial number fields are still empty in the EEPROM. After replacing the interface PCB, the model name and serial number may not always be automatically saved in the hydro software. Check if settings [6.7] and [6.8] are visible. ▪ If not visible, the model name and serial number were automatically saved. ▪ If visible, the model name and serial number were NOT automatically saved. You need to fill in settings [6.7] and [6.8]. Important: ▪ Ensure this information is accurately filled in for the correct functioning of the unit. ▪ Double-check the entries, as incorrect input cannot be corrected and will result in the unit not working.
[6.7] Indoor unit model name ▪ Enter model name (unit identification label) ▪ Confirm with the ✓ button.	
[6.8] Indoor unit serial number ▪ Enter serial number (unit identification label) ▪ Confirm with the ✓ button.	

[7] Maintenance mode

See the commissioning chapter in the installation manual of the indoor unit or the installer reference guide.

[8] Connectivity

In this chapter

[8.1] TCP/IP configuration	131
[8.2] Connection status	131
[8.3] Wireless gateway	131
[8.4] Connection details	131
[8.5] Daikin Home Controls	132
[8.6] Safe removal USB drive	132
[8.7] Modbus TCP/IP (502)	132
[8.8] Modbus TCP/IP TLS (802)	133

[8.1] TCP/IP configuration

⚙️[N/A]	Defines the IP settings. Changes to the IP settings are saved only when the confirm button is pressed. Therefore, when pressing the back or home button, the changes are discarded.
▪ DHCP (ON/OFF) If DHCP = OFF, you can define the following: ▪ TCP/IP address ▪ TCP/IP subnet mask ▪ TCP/IP default gateway ▪ TCP/IP DNS1 ▪ TCP/IP DNS2	

[8.2] Connection status

⚙️[N/A]	Shows (read-only) the connection status of the different external components.
▪ Hydro ▪ Backup heater ▪ Touchscreen ▪ Outdoor unit ▪ Mixing kit ▪ Daikin room thermostat – Main zone ▪ Cloud connection ▪ Wireless gateway ▪ LAN connection ▪ Modbus ▪ Daikin HomeHub	

[8.3] Wireless gateway

⚙️[N/A]	Defines the WLAN settings.
See "9.4 Using WLAN" [▶ 59].	

[8.4] Connection details

⚙️[N/A]	Shows (read-only) an overview of the connection details.
---------	---

- TCP/IP address
- TCP/IP subnet mask
- TCP/IP default gateway
- TCP/IP DNS1
- TCP/IP DNS2
- MAC address

[8.5] Daikin Home Controls

[8.5.1] Daikin Home Controls

⚙️[N/A]	Must match your system layout. Enables/disables Daikin Home Controls.
▪ OFF (disabled) ▪ ON (enabled)	

[8.5.2] Dehumidifier installed

⚙️[N/A]	Must match your system layout. Defines whether a dehumidifier is installed.
▪ OFF (not installed) ▪ ON (installed)	

[8.5.3] Dew sensor installed

⚙️[N/A]	Must match your system layout. Defines whether a dew sensor is installed, and which type.
▪ No: Not installed. ▪ Normally open: Normally open sensor installed. ▪ Normally closed: Normally closed sensor installed.	

[8.5.4] Humidity limit 1

⚙️[N/A]	Defines the humidity limit when a dew sensor is installed.
40~80%	

[8.5.5] Humidity limit 2

⚙️[N/A]	Defines the humidity limit when no dew sensor is installed.
41~80%	

[8.6] Safe removal USB drive

⚙️[N/A]	Enables you to safely unplug a connected USB device.
Removing the USB drive can take several seconds. ▪ OK	

[8.7] Modbus TCP/IP (502)

⚙️[N/A]	Enables the communication between the unit and the Modbus client using the 502 port.
---------	--

- | |
|---|
| <ul style="list-style-type: none">▪ OFF (disabled)▪ ON (enabled) |
|---|

[8.8] Modbus TCP/IP TLS (802)

⚙️[N/A]	Enables the communication between the unit and the Modbus client using the TLS encryption protocol and the 802 port.
▪ OFF (disabled) ▪ ON (enabled)	

[9] Energy

In this chapter

[9.1] Electricity price	134
[9.2] Electricity price baseline	134
[9.3] Electricity price schedule enable	134
[9.4] Electricity price schedule	135
[9.5] Gas price	135
[9.6] NOT USED	135
[9.7] NOT USED	135
[9.8] NOT USED	135
[9.9] NOT USED	135
[9.10] NOT USED	135
[9.11] Boiler efficiency	135
[9.12] PE factor	135
[9.13] Energy price considered	136
[9.14] Demand response	136

[9.1] Electricity price

[N/A]

Restriction: Only applicable if [9.3] **Electricity price schedule enable** is OFF.

When no schedule is set for the electricity price, this price will be taken into account.

For more information, see "[5.2 To set the fixed electricity price \(no scheduling\)](#)" [▶ 27].



INFORMATION

Price value ranging from 0.00~5000 valuta/kWh (with 2 significant values).

[9.2] Electricity price baseline

[N/A]

Restriction: Only applicable if [9.3] **Electricity price schedule enable** is ON.

When the schedule is ON, the electric price follows a block based schedule. The **Electricity price baseline** will be used at times when no electricity price is scheduled (i.e. in between the schedule blocks).

For more information, see "[5.3 To set the scheduled electricity baseline price](#)" [▶ 28].



INFORMATION

Price value ranging from 0.00~5000 valuta/kWh (with 2 significant values).

[9.3] Electricity price schedule enable

[N/A]

Restriction: Only applicable when bivalent or tank boiler is present.

Enables/disables the electricity price schedule.

For more information, see "[5.4 To set the electricity price schedule](#)" [▶ 28].

- ON (enabled)
- OFF (disabled)

[9.4] Electricity price schedule

⚙️[N/A]	Restriction: Only applicable when bivalent or tank boiler is present. You can set a weekly schedule timer for electricity prices. For more information, see "5.4 To set the electricity price schedule" [▶ 28].
---------	--

[9.5] Gas price

⚙️[N/A]	Restriction: Only applicable when bivalent or tank boiler is present. Set the correct gas price. For more information, see "5.5 To set the gas price" [▶ 28].
---------	---

[9.6] NOT USED

[9.7] NOT USED

[9.8] NOT USED

[9.9] NOT USED

[9.10] NOT USED

[9.11] Boiler efficiency

⚙️[026]	Restriction: Only applicable when bivalent or tank boiler is present. Boiler efficiency depends on the used boiler.
■ 0.1~1.0	

[9.12] PE factor

⚙️[141]	Restriction: Only applicable when bivalent or tank boiler is present. PE factor = Primary Energy factor. Compares the primary energy use of the heat pump with that of the boiler.
■ 0~6, step: 0.1 (default: 2.5) The primary energy factor indicates how many units of primary energy (natural gas, crude oil, or other fossil fuels, prior to undergoing any human-made conversions or transformations) are needed to obtain one unit of a certain (secondary) energy source, such as electricity. The primary energy factor for natural gas is 1. Assuming an average electricity production efficiency (including transportation losses) of 40%, the primary energy factor for electricity equals 2.5 (=1/0.40). The primary energy factor allows you to compare two different energy sources. In this case, the primary energy use of the heat pump is compared to the natural gas use of the gas boiler.	

[9.13] Energy price considered

⚙️[N/A]	Restriction: Only applicable when bivalent or tank boiler is present. If an external heat source is available, the main heat source will be chosen based on a comparison between both efficiencies of the heat sources. The decision on which source to select depends on the setting [9.13] Energy price considered. This setting defines if the energy prices are considered or not. For more information, see "5.1 Energy price considered" [▶ 27] and "[5.14] Bivalent" [▶ 115].
▪ ON (enabled) ▪ OFF (disabled)	

[9.14] Demand response

**NOTICE**

Imposed power limit. You can define a maximum limit to the power consumption of the heat pump and the electrical heat sources in different ways.

1. Via hardware contact:

- Install a Smart Grid meter.
- Set [9.14.1] = **Smart Meter Contact**.
- Define the imposed power limit in [9.14.7] **Smart meter limit**.

2. Via Modbus:

- Use holding register 58: Imposed power limit.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikineurope.com>.

- Use the ONECTA cloud API to define the imposed power limit.

Note:

- The imposed power limit can be ignored when the unit runs protective functions (defrost, water pipe freeze prevention, start-up control, maintenance mode).
- If the power limit is too strict to allow start-up or defrost operation, the heat pump will not operate.
- If the power limit is not too strict to allow start-up or defrost operation, the heat pump will operate. However, if the limit is exceeded for too long during operation modes other than start-up or defrost, the unit will stop operating.
- If the backup heater needs to support for protective reasons, the backup heater will kick in with at least a capacity of 2 kW (to ensure reliable operation) even if the power limit would be exceeded.

**NOTICE**

Smart Grid operation mode. You can define the Smart Grid operation mode in different ways:

1. Via hardware:

- Install 2 incoming Smart Grid contacts.
- Set [9.14.1] = **Smart grid ready contacts**.
- In the selection box **Connection type**, select **Hardware**.
- Use the 2 incoming Smart Grid contacts to define the mode.

2. Via Modbus:

- Set [9.14.1] = **Smart grid ready contacts**.
- In the selection box **Connection type**, select **Modbus**.
- Use holding register 56: Smart Grid operation mode.

3. Via Cloud: Momentarily, only available for business-to-business integrators. For more information, see <https://developer.cloud.daikin.europa.com>.

- Set [9.14.1] = **Smart grid ready contacts**.
- In the selection box **Connection type**, select **Cloud**.
- Use the ONECTA cloud API to adjust the Smart Grid operation mode.

[9.14.1] Operation mode

⚙️[040]	Must match your system layout. Demand response mode setting.
0: None	The outdoor unit is connected to a normal power supply without external demands.
1: Heat pump tariff	The outdoor unit is connected to a preferential kWh rate power supply. ▪ When the preferential kWh rate signal is sent by the electricity company, the contact will open or close (depending on the Invert selection, which defines whether the logic of the component has to be inverted, in [13] Field IO) and the unit will go in forced OFF mode. Via settings [9.14.2] and [9.14.3] it is possible that other heat sources take over when enabled. ▪ When the signal is released again, the voltage-free contact will open or close and the unit will restart operation. Note: The Heat pump tariff is a Field IO connection: ▪ [13] Field IO (HP Tariff Contact)

2: Smart grid ready contacts (Smart Grid contacts)	A Smart Grid is connected to the system. See below table for the modes activated by the 2 incoming Smart Grid contacts. You also need to select the source of the Smart Grid contacts in the selection box Connection type, which appears when you select Smart grid ready contacts (or alternatively via field code ✱[179]): ▪ 0: Cloud ▪ 1: Modbus ▪ 2: Hardware Note: The Smart Grid contacts are Field IO connections: ▪ [13] Field IO (HV/LV Smart Grid Contact 1) ▪ [13] Field IO (HV/LV Smart Grid Contact 2)
3: Smart Meter Contact (Smart Grid meter)	A Smart Grid that allows a power limitation is connected to the system. You can set the power limitation in [9.14.7] Smart meter limit. ▪ On the system overview screen (see "2.2 Energy flow – System overview screen" [▶ 9]), the demand response mode will be shown as Reduced. ▪ The incoming Smart Grid contact activates the power limitation that reduces the power to the heat pump and the electrical heaters (which will be allowed if the limit allows it). ▪ It is possible that in some cases the power limitation towards the heat pump is ignored for reliability reasons (e.g. heat pump start-up and defrost operation). See [9.14.7] Smart meter limit. Note: The Smart Grid meter is a Field IO connection: ▪ [13] Field IO (Smart Meter Contact)

Smart Grid contacts > Modes:

The 2 incoming Smart Grid contacts can activate the following modes:

1	2	Mode
0	0	Free running The Smart Grid function is NOT active.
0	1	Forced off ▪ The unit forces OFF the compressor and the heaters (backup heater, booster heater). ▪ Water pipe freeze prevention by the backup heater will still be allowed during the forced off operation. ▪ Via settings [9.14.2] and [9.14.3] it is possible that other heat sources take over when enabled.

1	2	Mode
1	0	Recommended on - In case the space heating/cooling request is OFF and the tank temperature setpoint is reached, the unit can choose to buffer energy from the photovoltaic panels in the room (only in case of room thermostat control) or in the DHW tank instead of putting the photovoltaic panel energy on the grid. - In case of room buffering (see [9.14.4]), the room will heat up or cool down to the comfort setpoint. In case of tank buffering, the tank will heat up to the maximum tank temperature.
1	1	Forced on Similar to Recommended on , but in this case other electrical heat sources will be activated in parallel to support space heating or tank heat-up without limiting settings as we have in recommended ON ([9.14.5] / [9.14.6]). Note: Room buffering will happen independently from setting [9.14.4] Allow buffering space H/C .
Emergency mode (see "[5.23] Emergency selection" [▶ 121]). In case emergency mode is active, buffering is still allowed, even when emergency mode does NOT allow an automatic take-over by electrical heater for space heating or for DHW operation.		



INFORMATION

During the **Forced on** mode, the room buffering will happen independently from the **Allow buffering space H/C** [9.14.4] setting. During the **Recommended on** mode, the room buffering will only happen when the room buffering is enabled ([9.14.4] = On).

[9.14.2] SH heater take-over during forced off

⚙️[037]	Restriction: Only applicable if [9.14.1] = - Heat pump tariff - Smart grid ready contacts Defines whether another heat source can take over the space heating when the heat pump is not allowed to work because of an active limit or because of a forced OFF command.
0: No take-over: No other heat source can take over. 1: Fossil take over: If there is a bivalent boiler or tank boiler available, the bivalent boiler or tank boiler can take over. 2: Heater take over: Backup heater can take over.	

[9.14.2]	Booster heater	Backup heater	Bivalent boiler / tank boiler	Compressor
0: No take-over	OFF	OFF	OFF	OFF
1: Fossil take over	OFF	OFF	Take-over	OFF

[9.14.2]	Booster heater	Backup heater	Bivalent boiler / tank boiler	Compressor
2: Heater take over	OFF	Take-over	OFF	OFF

[9.14.3] DHW heater take-over during forced off

⚙️[071]	Restriction: Only applicable if [9.14.1] = ▪ Heat pump tariff ▪ Smart grid ready contacts Defines whether another heat source can take over the DHW operation when the heat pump is not allowed to work because of an active limit or because of a forced OFF command.
▪ 0: No take-over: No other heat source can take over. ▪ 1: Fossil take over: If there is a tank boiler available, the tank boiler can take over. ▪ 2: Heater take over: Backup heater and booster heater can take over if available. ▪ 3: Only booster heater take-over: Only booster heater can take over if available.	

[9.14.3]	Booster heater	Backup heater	Tank boiler	Compressor
0: No take-over	OFF	OFF	OFF	OFF
1: Fossil take over	OFF	OFF	Take-over	OFF
2: Heater take over	Take-over	Take-over	OFF	OFF
3: Only booster heater take-over	Take-over	OFF	OFF	OFF

[9.14.4] Allow buffering space H/C

⚙️[036]	Restriction: Only applicable if [9.14.1] = Smart grid ready contacts. Allows/disallows room buffering during recommended ON mode. Note: ▪ During forced on mode, room buffering will always be active. ▪ Buffering will be active in room thermostat control. In this case the buffering will happen towards the following setpoints: - [1.29] Heating comfort setpoint in heating - [1.30] Cooling comfort setpoint in cooling
---------	--

- 0: OFF (not allowed): The extra energy from the photovoltaic panels is only buffered in the DHW tank (i.e. heat up the DHW tank).
- 1: ON (allowed): The extra energy from the photovoltaic panels is buffered in the DHW tank, and in the space heating/cooling circuit (i.e. heat up or cool down the room).



INFORMATION

Tank/room buffering priority:

- The system starts tank buffering first. When tank buffering is at its maximum capacity, then the system switches to room buffering (if enabled).
- Tank buffering can switch to room buffering prior to reaching the maximal capacity because of internal unit logic. In normal operation, the maximum running time for domestic hot water is applicable.
- When room buffering is ongoing and the tank drops below its maximum capacity (e.g. someone takes a shower), then the system stays at room buffering for a certain amount of time before it switches back to tank buffering.

[9.14.5] BUH support during SH recommended on

[038]	Restriction: Only applicable if [9.14.1] = Smart grid ready contacts. Allows/disallows the backup heater for space heating support in recommended ON mode. Note: If the water temperature is too low to allow heat pump operation, and this setting is set to OFF (not allowed), then the electrical heater will NOT push the heat pump into the operation range (because the electrical heater is then not allowed).
▪ 0: OFF (not allowed) ▪ 1: ON (allowed)	

[9.14.6] BUH+BSH support during DHW recommended on

[039]	Restriction: Only applicable if [9.14.1] = Smart grid ready contacts. Allows/disallows the backup heater or booster heater for tank heat-up support in recommended ON mode. Note: If the tank temperature is too low to allow heat pump operation, and this setting is set to OFF (not allowed), then the electrical heater will NOT push the heat pump into the operation range (because the electrical heaters are then not allowed).
▪ 0: OFF (not allowed) ▪ 1: ON (allowed)	

[9.14.7] Smart meter limit

⚙️[135]	Restriction: Only applicable if [9.14.1] = Smart Meter Contact. Defines the applicable power limit in case of a Smart Grid meter. Note: If the Smart Grid meter limit is active, the heat pump and the additional electrical heat sources are allowed to operate if the limit allows it. However: ▪ It is possible that in some cases this limit towards the heat pump will be ignored for reliability reasons (e.g. heat pump start-up and defrost). ▪ If the backup heater needs to support for protective reasons, the backup heater will kick in with at least a capacity of 2 kW (to ensure reliable operation) even if the power limit would be exceeded.
	2~20 kW step: 0.1 kW


[10] Configuration wizard

After first power ON of the system, the user interface starts a configuration wizard. Use this wizard to set the most important initial settings for the unit to run properly.


- If needed, you can restart the configuration wizard via the menu structure: [10] **Configuration wizard**.
- If needed, you can afterwards configure more settings via the menu structure.

Configuration wizard – Overview

Depending on your unit type and the selected settings, some steps will not be visible.



After you completed all steps in the wizard, the user interface will show an error message instructing to enter the Digital Key (i.e. perform the unlocking procedure).



More information

For more information about the configuration wizard (and how to perform the unlocking procedure), see the installation manual of the indoor unit or the installer reference guide.

[11] Malfunctioning

See the troubleshooting chapter in the installer reference guide.

To display the help text in case of a malfunction

In case of a malfunction, the following icon will appear on the home screen depending on the severity:

- : Error
- : Warning
- : Information

You can get a short and a long description of the malfunction as follows:

1	Go to [11] Malfunctioning. Result: The ongoing malfunctions are shown with the following information: ▪ The Level icon: - : Error - : Warning - : Information ▪ The error code ▪ The Type icon: - : Safety: these are critical errors that can result in an unsafe situation (e.g. refrigerant leak). - : Protection: these are errors related to the protection of the user or the system (eg overheating/disinfection/undercooling). - : Technical: these are all other errors indicating a technical problem of the unit or peripherals (e.g. sensor abnormality).
2	Tap on the error message in the error screen. Result: A long description of the error is displayed on the screen.

[12] NOT USED

[13] Field IO

When connecting the electrical wiring, for certain components, you can choose which terminal pins to use. After connection, you must tell the user interface which terminal pins you used so that it matches your system layout:

- Preferably, via the breadcrumbs in [13] **Field IO**.
- Alternatively, via the field codes (see the field settings table in the installer reference guide).

For more information about **Field IO** connections, see the installation manual of the indoor unit or the installer reference guide.

