





# INSTALLATION MANUAL

## Room thermostat


EKRTW



1



2



3



Read this manual attentively before starting up the unit. Do not throw it away. Keep it in your files for future reference.



Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Be sure only to use accessories made by Daikin which are specifically designed for the use with the equipment and have them installed by a professional.

If unsure of installation procedures or use, always contact your dealer for advice and information.

## Contents

1. Introduction .....	1
2. Installation of EKRTW .....	2
3. Setting up codes in the installer menu .....	5
4. Technical characteristics .....	10

## 1. Introduction

The room thermostat EKRTW can be used to control floor heating-only applications and floor heating/cooling applications.

It is typically connected to the indoor unit. Refer to the "Typical application examples" in the Installation manual of the indoor unit.

- In case of floor heating-only applications the room thermostat can also be connected to the individual motorized valve of the floor heating loop.
- If a floor heating-only application is used in combination with fan coil units each fan coil unit should have its dedicated fan coil thermostat.

## 2. Installation of EKRTW


The EKRTW thermostat is wall-mounted, with supplied screws and plugs. Refer to [figure 1](#).

Cabling towards the indoor system (field supply) should be foreseen in advance taking the suggestions for an ideal installation location into account. Refer to [figure 2](#).




Before obtaining access to terminals, all power supply circuits must be interrupted.

- 1 At the left of the thermostat, gently push the lid.
- 2 Remove the front cover by pulling it towards you.
- 3 Unscrew the screw of the cable holder in the bottom left corner of the back part of the thermostat and remove the transparent cable protection.
- 4 Remove the battery insulator.



- 5 Drill holes in the wall taking the dimensions of the thermostat into account and insert the supplied plugs in the holes.  
Refer to [figure 3](#) (unit of measurement: mm).


- 6 Pass the indoor unit or motorized valve wiring through the back of the thermostat.




- 7 According your application, perform the wiring.

- 7a When connected to the indoor unit, wire the indoor unit and the thermostat as shown below.

EKHB(H/X)007AC\*\*\*



EKHB(H/X)008  
EKHB(H/X)016




H	Heating demand
C	Cooling demand

For heating-only applications, wire 17-C or 2-C is not to be installed.

Use wire size 0.75~1.50 mm<sup>2</sup>.

- 7b** When connected to the motorized valve, wire the motorized valve and the thermostat as shown below (for heating-only applications).



The output relays (H and C are voltage-free contacts) can handle a maximum load of 5 A - 230 VAC.

- 8** Fasten the thermostat with the supplied screws.



Be careful not to pinch the wiring when fastening.

- 
- 9** Put the transparent cable protection back into place and fix the cable protection with the screw.
- 10** Close the thermostat cover.
- 11** Remove the protective film from the LCD.


### 3. Setting up codes in the installer menu

You can set up codes, starting from the time and date menu (in advanced mode).

**NOTE** As a consequence of a customized configuration, it is not abnormal that some codes are no longer accessible.



- 1 Activate the advanced mode by pressing during 5 seconds in OFF mode ().
- 2 Navigate to the date and clock setting menu () by pressing .
- 3 Press and keep it pressed while now pressing during 10 seconds.  
 is displayed next to 4r.



- 4 Press or to consult the current settings of the codes.
- 5 To modify codes, press , or .
- The value is flashing when being modified.
- 6 Press or to increase or decrease the code value by 1 step.  
To put a code back to its default value, press and at the same time.
- 7 Press to save your selection.  
You can exit this code menu by going to the "End" code and pressing .



### 3.1. Set-up for heating/cooling applications

For heating/cooling applications, set the following codes:

1st code	2nd code	Description	Required setting
5r	01	Cooling mode present?	YES

### 3.2. Overview of all codes


Following codes can be changed in the installer menu:

1st code	2nd code	Description	Default	Range	Step
<b>Readout codes</b>					
4r	01 + 	Calibration of internal sensor. Actual temperature + offset are displayed. The  symbol appears when the offset deviates from 0.	Offset = 0	Offset: -5°C~5°C	0.1°C
<b>Installation codes</b>					
5r	01	Cooling mode present?	no	YES/no	—



1st code	2nd code	Description	Default	Range	Step
<b>Temperature control codes</b>					
Daikin advises not to change below temperature control parameters. They are set for an optimal use of the floor cooling/heating application.					
6r	02	Use proportional band control?	YES	YES (proportional band)/no (hysteresis)	—
	03	Hysteresis value	005	005~020	0.1°C
	04 + ☀	Duration proportional band (heating).	020	010~060	1 min.
	05 + ☀	Minimum "on" time (heat demand).	007	002~6r 04/2	1 min.
	06 + ☀	Minimum delay between 2 heating cycles.	003	001~6r 04/2	1 min.
	07 + ✱	Duration proportional band (cooling).	020	010~060	1 min.
	08 + ✱	Minimum "on" time (cool demand).	007	002~6r 07/2	1 min.
	09 + ✱	Minimum delay between 2 cooling cycles.	003	001~6r 07/2	1 min.
	10	Value of proportional band.	020	010~040	0.1°C
	11	Compensating value.	000	000~080	0.1°C


1st code	2nd code	Description	Default	Range	Step
8r	12	Upper setpoint limitation.	037	22.0~37.0	1°C
	13	Lower setpoint limitation.	004	04.0~20.0	1°C
<b>Schedule timer codes</b>					
8r	01	Enable cooling/heating link for the user-defined schedules U1 and U2? When enabled and a user-defined schedule is selected in the schedule timer setting menu: in heating mode, schedule U1 will be active; in cooling mode, schedule U2 will be active.	no	YES/no	—

1st code	2nd code	Description	Default	Range	Step
<b>Miscellaneous codes</b>					
9r	01	Daylight saving time implementation.	YES	YES/no	—
	02 + ☀	Forced heating (installation check).	no	YES/no	—
	03 + ❄	Forced cooling (installation check).	no	YES/no	—
	15 + RESETALL	Reset all settings back to factory configuration. Press  during 5 seconds. The complete LCD is shown to confirm all settings are reset.	—	—	—

## 4. Technical characteristics

Temperature read out	Steps of 0.1°C
Operating temperature	0°C~50°C
Setpoint temperature range	4°C~37°C in steps of 0.5°C
Electrical protection	Class II - IP30 (indoor use, pollution degree 2)
Feeding and autonomy	3 alkaline batteries AA.LR6 1.5 V approximately 2 years (depending on usage conditions)
Output relays	Maximum load 5 A - 230 VAC
Immunity against voltage surges	Category III (2.5 kV)
Type of automatic action of the thermostat	1C

## NOTES





\*4PW44896-1 C 000000Z\*

Copyright © Daikin

**DAIKIN EUROPE N.V.**

Zandvoordestraat 300, B-8400 Oostende, Belgium

4PW44896-1C